PRESTOLITE

MAINTENANCE PUBLICATIONS

For

AVCO LYCOMING AIRCRAFT ENGINES

SSP-1471-3

March 1, 1985

AVCO LYCOMING WILLIAMSPORT DIVISION 652 Oliver Street, Williamsport, Pennsylvania 17701 AVCO LYCOMING ENGINE GROUP



THE AIRCRAFT STARTING MOTOR USING GEAR REDUCTION DRIVE


The starting circuit is designed to carry high current with a minimum loss of voltage. This circuit includes the battery, solenoid starting switch, manual starting switch, starting motor, the connecting wiring and the vehicle frame. The starting motor cranks the engine for starting while the battery supplies the power. The manual switch and solenoid starting switch control the operation.

THE STARTING MOTOR

The starting motor must develop a high cranking torque for a limited period of time when the starting switch is closed. The starting motor has designed into it a means of engaging its pinion with the flywheel ring gear on the engine with which it is used, and disengaging the pinion as soon as the engine starts.

DESCRIPTION

The gear reduction starting motor consists of six major components: (1) The Commutator End Head Assembly, (2) The Armature, (3) The Frame and Field Assembly, (4) The Gear Housing, (5) The Pinion Housing, and (6) The Bendix Drive Assembly. See Figure 1.



THRUST WASHER PKG.



Form L-649A

OPERATION

When the starting circuit is energized, battery current is applied to the starting motor terminal. Current flows through the field coils creating a strong magnetic field. At the same time, current flows through the brushes to the commutator, through the armature windings to ground. The magnetic force created in the armature combined with that created in the field windings, begins to turn the armature.

The gear cut on the drive end of the armature shaft extends through the gear housing where it is supported by a roller bearing. The gear mates with the teeth of the reduction gear that drives the Bendix shaft. The shaft is keyed to the reduction gear. The Bendix drive is held in position on the shaft by a "spirol" pin. The shaft is supported in the gear housing by a closed end roller bearing and in the pinion housing by a graphitized bronze bearing.

When the armature turns the reduction gear, the Bendix drive pinion meshes with the flywheel ring gear by inertia and action of the screw threads within the Bendix sleeve. A detent pin engages in a notch in the screw threads which prevents demeshing if the engine fails to start when the starting circuit is de-energized.

When the engine reaches a predetermined speed, centrifugal action forces the detent pin out of the notch in the screw shaft and allows the pinion to demesh from the flywheel.

MAINTENANCE

The starting circuit should be inspected at regular intervals, the frequency of which should be determined by the amount of service and the conditions under which the vehicle is operated. It is recommended that such inspection be made at least twice a year and should include the following:

- 1. <u>Battery</u> The battery should be checked with a hydrometer to be sure it is fully charged, and filled to the proper level with approved water. A load test should be made to determine battery condition. If dirt and corrosion have accumulated on the battery, it should be cleaned with a solution of baking soda and water. Be sure none of the solution enters the battery cells.
- 2. <u>Wiring</u> The starting circuit wiring should be inspected to be sure that all connections are clean and tight and that the insulation is sound. A voltage loss test should be made to locate any high resistance connections that would affect starting motor efficiency. This test is made with a low reading voltmeter while cranking the engine or at approximately 100 amperes, then the following limits should be used:
 - (A) Voltage loss from insulated battery post to starting motor terminal 0.3 volt maximum.
 - (B) Voltage loss from battery ground post to starter frame 0.1 volt maximum.

If voltage loss is greater than the above limits, additional tests should be made over each part of the circuit to locate the high resistance connections.

- 3. <u>Lubrication</u> No lubrication is required on the starting motor except at the time of overhaul. Then lubricate the entire shaft under Bendix Drive, fill grooves in armature shaft at drive end and pack gear box with 1.3 to 2.0 ounces of Lithium Soap Base Grease #1925 Molytex "O" or equivalent.
- 4. <u>Drive Operation</u> The starting motor should be operated for a few seconds with the ignition switch off to make sure that the pinion engages properly and that it turns freely without binding or excessive noise. Then the engine should be started two or three times to see that the pinion disengages properly when the engine is turned off.

OVERHAUL

If, during the above inspection, any indication of starting motor difficulty is noted, the starting motor should be removed from the engine for cleaning and repair.

- 1. <u>Removal</u> To remove the starting motor from the engine, first disconnect the ground cable from the battery post to prevent short circuiting. Disconnect the lead from the starting motor terminal, then take out the mounting bolts. The motor can then be lifted off and taken to the bench for overhaul.
- 2. <u>Disassembly</u> Remove the frame screws from the commutator end head and pull end head and armature from frame. Lift the brushes and lock in elevated position with brush springs. Use a puller to remove the end head from the armature. Use a special bearing puller to remove the sealed ball bearing from the armature shaft.

Remove the frame screws that secure the gear housing to the frame. Remove bolts and nuts holding the gear housing to the pinion housing and separate the two units. Pull Bendix shaft from pinion housing. Do not lose the steel spacer that is located on the pinion end of the shaft. Remove reduction gear, woodruff key and steel spacer from shaft.

Turn the Bendix pinion until it locks in the extended position. Locate "spirol" pin and use a punch to remove. Slide drive assembly off the shaft. Do not attempt to disassemble the drive and do not dip it in cleaning solvent.

To remove the roller bearings from the gear housing, use an arbor press and the <u>correct</u> bearing arbor. DO NOT HAMMER OUT. Each part should be cleaned and inspected for excessive wear or damage. Bearings should be checked for proper clearance and evidence of roughness or galling. Oil and dirt should be removed from insulation and the condition of the insulation checked.

Form L-649A

- 3. <u>Brushes</u> Check the brushes to see that they slide freely in their holders and make full contact on the commutator. If worn to half their original length or less, they should be replaced.
- 4. <u>Armature</u> Check the commutator for uneven wear, excessive glazing or evidence of excessive arcing. If only slightly dirty, glazed or discolored, the commutator can be cleaned with 00 or 000 sandpaper. If the commutator is rough or worn, it

should be turned in a lathe. Figure 2. The armature shaft should be inspected for rough bearing surfaces and rough or damaged splines.

To test the armature for grounds, a set of test probes connected in series with a 110 volt light should be used. Touch one probe to a commutator segment and the other to the armature core. If the test lamp lights, the armature is grounded and should be replaced.

To test for shorted armature coils, a is placed on the growler and slowly rotated by hand while a steel strip is held over the core so that it passes over each armature core slot. If a coil is shorted, the steel strip will vibrate.

A quick check for opens can be made by inspecting the trailing edge (in direction of rotation) of the commutator segments for excessive discoloration. This condition indicates an open circuit.

5. <u>Field Coils</u> - Check the field coils for grounds (Figure 4) by placing one test probe on the frame and the other on the starter terminal. Be sure the brushes are not accidentally touching the frame. If the lamp lights, the fields are grounded. Repair or replace.

Inspect all connections to make sure they are clean and tight and inspect insulation for deterioration.

6. <u>Brush Holders</u> – To test brush holders, touch one test probe to the brush plate and the other to each brush holder.



Figure 2 - Turning Starting Motor Commutator

To test for shorted armature coils, a growler is used, Figure 3. The armature




Figure 3 - Testing Motor Armature for Shorts




Figure 4 - Testing Motor Fields for Grounds

The test lamp should light when the grounded brush holders are touched and should not light when the insulated brush holders are touched.

- 7. <u>Gear and Pinion Housing</u> Inspect housings for cracks and bearings for excessive wear. Remove rust, paint or grease from mounting surfaces.
- 8. <u>Bendix Drive</u> The Bendix Drive should be wiped clean with a dry cloth. The pinion should turn smoothly in one direction and should lock in the other direction. Replace drive if it fails to check as above or if the pinion teeth are excessively worn or damaged.
- 9. <u>Assembly</u> When assembling the starting motor, always use an arbor press and the proper bearing arbor for installing graphitized bronze and roller bearings. The Bendix shaft should have a thin film of Lubriplate #777 or equivalent on the Bendix portion of the shaft.


New brushes should be properly seated when installing by wrapping a strip of 00 sandpaper around the commutator (with the sanding side out) 1-1/4 to 1-1/2 times maximum. Drop brushes on sandpaper covered commutator and turn the armature slowly in the direction of rotation. Dust should be blown out of the motor after sanding.

Check the position of the pinion to be sure the unit will mesh properly with the flywheel ring gear. See specifications for particular unit for correct dimensions.

BENCH TESTS

After the starting motor is reassembled, it should be tested to see that the no load current at a certain voltage is within specifications. To make this test, connect as shown in Figure 5. If current is too high, check the bearing alignment and end play to make sure there is no binding or interference. Two or three sharp raps on the frame with a rawhide hammer will often help to align the bearings and free the armature.

If no difficulty is indicated in the above test, a stall torque test may be made to see if the starting motor is producing its rated cranking power. Make test connections as shown in Figure 6.






Figure 5 - No-Load Test Hook-up

Figure 6 - Stall-Torque Hookup

Form L-649A

If torque and current are not within specifications, check the seating of the brushes and internal connections for high resistance. If these checks are made and found to be in good order, replace frame and field assembly and retest starter.

STARTING MOTOR CONTROL CIRCUIT

Inspect the control circuit wiring between the battery, solenoid and manual starting switches for breaks, poor connections and faulty insulation. Tighten all connections and make sure solenoid is firmly mounted and makes a good ground connection.

Check the voltage loss across the switch contacts during normal starting. If loss is in excess of 0.2 volts per 100 amperes, the solenoid should be replaced.

If solenoid fails to operate when the manual switch is turned on or if it fails to release when the manual switch is released, it should be removed and tested to specifications. If either opening or closing voltages are not as specified, replace the solenoid.



MHB SERIES

STARTING MOTORS

ISSUED: 9-25-79(Rev.)

ORIG.EQUIP. MOTOR		SERVICE MOTOR	
PART NUMBER		PART NUMBER	APPLICATION
MHB-4001,R	USE	MHB-4016R	Lycoming
MHB-4002,R	USE	MHB-4017R	Lycoming
MHB-4003,R	USE	MHB-4019R	Lycoming
MHB-4004		MHB-4004	Franklin
MHB-4005,R		[*]	Lycoming
MHB-4006		MHB-4006	Continental
MHB-4007, R	USE	MHB-4018R	Lycoming
MHB-4008,R	USE	MHB-4008R	Lycoming
MHB-4009,R	USE	MHB-4014R	Lycoming
MHB-4010,R	USE	MHB-4016R	Lycoming
MHB-4011,R	USE	MHB-4017R	Lycoming
MHB-4012,R	USE	MHB-4019R	Lycoming
MHB-4013,R	USE	MHB-4018R	Lycoming
MHB-4014,R	USE	MHB-4014R	Lycoming
MHB-4015,R	USE	MMU-4001R	Lycoming
MHB-4016,R	USE	MHB-4016R	Lycoming
MHB-4017,R	USE	MHB-4017R	Lycoming
MHB-4018,R	USE	MHB-4018R	Lycoming
MHB-4019,R	USE	MHB-401 9R	Lycoming


[*] Available thru Lycoming only.



÷

10





MHB SERIES STARTING MOTOR PARTS LIST

ISSUED 10-13-81 (REV.) SHEET 2

Assembly	Armature	Brush Set	Frame & Field	Comm.End Head	C.E. Bearing	D.E.Head or	D.E. Bearing
		2	Assembly 3	Assembly 4	5	Pinion Hsg.	7
MHB-4001,R	MHB-2399S	MHB-2012S	MHB-2397S	MHB-2400	X-3991	[a]	[a]
MHB-4002,R	4	ш	11	н	н	[b]	[b]
MHB-4003,R	н	n	II	и	II.	[c]	[c]
MHB-4004	MHB-2383	MHB-2012AS	MHB-2384S	MBP-2002CS	[NR]	MZ-1147	MAB-124
MHB-4005,R[*]	MHB-2399 S	11	MHB-2418S	MHB-2400A	X-3991	[NR]	[NR]
мнв-4006	MHB-2420	MHB-2012S	MHB-2384AS	MBP-2002CS	[NR]	MHB-2137[e]	90-2118[f
MHB-4007,R	MHB-2399S	n	MHB-2397 S	MHB-2400	X-3991	[d]	[b]
MHB-4008,R	u	u	n	U U	u	[NR]	[NR]
MHB-4009,R	н	MHB-2012AS	MHB-2397As	п	11	[d]	[b]
MHB-4010,R	ш	MHB-2012S	MHB-2397S	н	н.	PS-1432C	MZ-298
MHB-4011,R	Ш	11	н	u ,	n	PS-1437B	н
MHB-4012,R	D.	и	и	н	Ш	PS-2432B	n
MHB-4013,R	и	П	п	11	11	PS-1432E	н
MHB-4014,R	н	MHB-2012AS	MHB-2397AS	п	н	H	0
MHB-4015,R	MMU-2386 S	10	MHB-2384BS	MBP-2002D	[NR]	PS-1435	MG-77A
MHB-4016,R	MHB-2399S	MHB-2012S	MHB-2397S	MHB-2400	X-3991	PS-1432C	MZ-298
MHB-4017,R		11	н	i ii	n	PS-1437B	u
MHB-4018,R	н	11	н	n	0	PS-1432E	u
MHB-4019,R	н	n	п	n	н	PS-2432B	u
PS-1432C [b] PS-1437BS PS-1437B [c] PS-2432BS PS-2432B [d] PS-1432ES PS-1432E [e] MZ-414S L [f] Bearing &	Pinion Hsg.,MZ ; Housing & Sha Pinion Hsg.,MZ ; Housing & Sha Pinion Hsg.,MZ ; Housing & Sha Pinion Hsg.,MZ D.E. Mtg. Screw & Seal Pkg. e thru Lycoming	-298 Bearing, M ft Pkg. must be -298 Bearing, M ft Pkg. must be -298 Bearing,MZ ft Pkg. must be -298 Bearing, M Gasket Pkg.(10	IZ-326 Bendix Dr used at time o IZ-326 Bendix Dr used at time o -326 Bendix Dri used at time o IZ-326 Bendix Dr	f first repair. ive Shaft may b f first repair. ive Shaft may b f first repair. ve Shaft may be f first repair. ive Shaft may b 91 Mtg. Screw P	e replaced ther Individual com e replaced ther Individual Com replaced there Individual Com e replaced ther	eafter. ponents- eafter. ponents- after. ponents- eafter.	

File in the OE-A1 AIRCRAFT MANUAL



MHB SERIES STARTING MOTOR PARTS LIST

Assembly	Bendix Drive	Bendix Drive Shaft	Intermed. Bearing Assembly	Brush Spring Set	Terminal Stud Package	Cover Band	0i1 Seal
	(8)	(9)	(10)		(12)	13	(14)
MHB-4001,R	EBB-75A[g]	[a]	[NR]	MZ-19S	90-2502	MZ-24A	[NR]
MHB-4002,R	н	[b]	[NR]	н	u	II	[NR]
MHB-4003,R	н	[c]	[NR]	н	н	11	[NR]
мнв-4004	EBB-133[h]	[NR]	[NR]	li li	11	н	XA-560
MHB-4005,R[*]	[NR]	[NR]	[NR]	н	n	п	[NR]
1HB-4006	[NR]	[NR]	[NR]	П	n	и	90-2118[f]
1HB-4007,R	EBB-75A[g]	[d]	[NR]	в	н	14	[NR]
IHB-4008,R	[NR]	[NR]	[NR]	н	u u	11	[NR]
HB-4009,R	EBB-142A[g]	[d]	[NR]	н	n	11	[NR]
HB-4010,R	EBB-75A[g]	MZ-326	[NR]	п	н	н	[NR]
HB-4011,R	н	u	[NR]	н	п ``	11	[NR]
1HB-4012,R	н	и	[NR]	n	11	н	[NR]
IHB-4013,R	н	n	[NR]	н	н	11	[NR]
HB-4014,R	EBB-142A[g]	u	[NR]		41	в	[NR]
HB-4015,R	EBB-124A[h]	[NR]	MZ-1236[j]	0	n	н	[NR]
HB-4016,R	EBB-131A[h]	MZ-326A	[NR]	н	п	ч	[NR]
HB-4017,R	н	(1	[NR]	н	n	н	[NR]
IHB-4018,R	u	н	[NR]	li li	a	u	[NR]
HB-4019,R	н		[NR]	H	II	п	[NR]
						•	
					 . Individual Comp pe replaced there		I
b] PS-1437BS PS-1437B F	Housing & Shaft Pinion Hsg.,MZ-2	t Pkg.must be 298 Bearing, M	used at time of Z-326 Bendix Driv	first repair. ve Shaft may b	Individual Compo be replaced there Individual Comp	onents- eafter.	

[C] PS-2432BS Housing & Shart Pkg. must be used at time of first repair. Individual Components-PS-2432B Pinion Hsg., MZ-298 Bearing,MZ-326 Bendix Drive Shaft may be replaced thereafter.
[d] PS-1432E Pinion Hsg., MZ-298 Bearing,MZ-326 Bendix Drive Shaft may be replaced thereafter.
[f] Bearing & Seal Pkg.
[g] 90-2140 Bendix Pin Pkg.(25 Pcs.) also available.
[h] 90-2139 Bendix Pin Pkg.(25 Pcs.) also available.
[j] MZ-339 Bushing also available.
[*] Available thru Lycoming only.

ISSUED: 8-3-81 (Rev.) SHEET 3

Assembly	Gear			Plate	Washer	Connector	Switch
	(15)	Housing Assembly (16)	Bearing	18	Package	20	21
1HB-4001,R	MZ-396	MZ-1390	[k]	MZ-393	90-601	[NR]	[NR]
1HB-4002,R	"	п	[k]	II	ü	[NR]	[NR]
1HB-4003,R			[k]	н	и	[NR]	[NR]
1HB-4004	[NR]	[NR]	[NR]	[NR]	90-2677	MZ-144	[m]
1HB-4005,R[*]		MHB-1030[*]	[k]	[NR]	90-601	[NR]	[NR]
1HB-4006	н	[NR]	[NR]	[NR]	90-2232	[NR]	[NR]
1HB-4007,R	MZ-396	MZ-1390	[k]	MZ-393	90-601	[NR]	[NR]
1HB-4008,R	[NR]	u .	[k]	[NR]	п	[NR]	[NR]
1HB-4009,R	MZ-396	н	[k]	MZ-393	11	[NR]	[NR]
4HB-4010,R		n	[K]	u	н	[NR]	[NR]
MHB-4011,R	и	a	[k]	u	It	[NR]	[NR]
MHB-4012,R	н	n	[k]	и	и	[NR]	[NR]
MHB-4013,R	и	u	[k]	ii ii	11	[NR]	[NR]
MHB-4013,R	u	u	[k]	u -	в	[NR]	[NR]
MHB-4014,R	[NR]	[NR]	[NR]	[NR]	90-2677	[NR]	[NR]
MHB-4015,R	MZ-396	MZ-1390	[k]	MZ-393	90-601	[NR]	[NR]
	11		[k]	a	п	[NR]	[NR]
MHB-4017,R	u	и	[k] .	и	0	[NR]	[NR]
MHB-4018,R MHB-4019,R		u	[k]	п	н	[NR]	[NR]
Im INO IODO	er available. le thru Lycomi	/2" O.D. and XA-9	998 is 13/16"	0.D.			

/



5



GENERAL INFORMATION

- VOLTAGE 24
- ROTATION Gear Reduction Units Except MHB-4005, R,-4009, R,-4014, R. Motor - CCWDE Drive - CWDE MHB-4005, R -4014, R Motor - CWDE MHB-4009, R Motor - CWDE Drive - CWDE Drive - CWDE Drive - CWDE Drive - CWDE
- BRUSHES 4
- POLES 4
- <u>SWITCH</u> Gear Reduction Units Separate Direct Drive Units - switch mounted on motor
- DRIVE ASSEMBLY

Rubber Folo Thru Type

GEAR REDUCTION

3.38 to 1 Gear Ratio (see following note).

DRIVE AND GEAR NOTE

Reduction gears, shafts, and drives used with the MHB-4005, 4005R, and 4006 are not manufactured or supplied by Prestolite.

SERVICE INFORMATION

LUBRICATION

GEAR REDUCTION UNITS Except MHB-4006

Thoroughly clean and repack needle bearings with Shell Alvania #2 or an equivalent bearing lubricant. Pack gear box with 1-1/4 to 2 ounces of Texaco #1925 Molytex "0" or an equivalent Lithium soap base grease. (Also see Drive Assembly servicing.)

MHB-4006

Saturate the felt oiling pad in the commutator end head with SAE 20 oil. Allow excess oil to drain out before installing end head on motor. Thoroughly clean and inspect the two needle bearings in the drive end head for wear or damage. Replace if necessary. Repack needle bearing with Shell Alvania #2 or an equivalent bearing lubricant.



MHB

AIRCRAFT STARTING MOTORS

Issued 4/1/83

Page 2 of 5



DIRECT DRIVE UNITS

Soak new absorbent bronze bearings in SAE 20 oil before installation. Saturate the felt oiling pad in the commutator end head with SAE 20 oil. Allow excess oil to drain out before installing end head on motor. Put a light film of Lubriplate #777, or equivalent, on the drive end of the armature shaft before installing the drive end head. (Also see Drive Assembly servicing.)

DRIVE ASSEMBLIES

The Drive Assembly should be throroughly cleaned and re-lubricated when the motor is overhauled. <u>Do Not</u> use carburetor cleaner or any cleaning solution that could damage the rubber block inside the Drive Assembly. Use only clean petroleum base cleaners such as kerosene or "varsol". Thoroughly clean the drive to remove all dirt, grease, and contamination from the screwshaft threads and control nut. The drive cup may also be removed to insure a thorough cleaning job. <u>Do Not</u> attempt to remove the control nut.

After the drive has been cleaned and blown dry with compressed air, lubricate the drive with a spray-on type silicone lubricant. Lubricate the motor shaft with the same silicone lubricant before installing the Drive Assembly. When reassembling the early style drive on the shaft, make sure the spirol pin does not project beyond the outside diameter of the pinion sleeve. When reassembling the late style drive, make sure the head washer covers both ends of the retaining pin.

BEARING REPLACEMENT

GEAR REDUCTION UNITS Except MHB-4006

When replacing needle bearings they must be pressed in flush with the edge of the casting. The armature bearing must be flush on the side toward the armature and the Drive Assembly shaft bearing flush on the side toward the Drive Assembly. Press the pinion housing bearing in flush with the outside edge of the casting.

MHB-4006

Press the armature shaft bearing into the housing until it is flush with the bearing bore. Press the oil seal in until it is flush with the edge of the casting. Press the gear reduction shaft bearing in so that the open end is flush with the edge of the casting.

DIRECT DRIVE UNITS

Press the drive end bearing in flush with the outside edge of the casting. Press the oil seal into the casting so that it bottoms against the oil seal counterbore.



INTERMEDIATE BEARING PLATE MHB-4015, R

Use "Loctite Grade A" on threads of bearing plate retaining screws. Torque screws to 25 - 35 in./lbs.

BRUSH REPLACEMENT

Brushes must be replaced when they have worn down to a length of 1/4" or less. Refer to service bulletin ASM-1 for brush replacement procedure.

BRUSH SPRING TENSION

32 to 40 ounces with new brushes. Measure with a spring scale hooked under the spring at the brush. Pull on a line opposite the line of force exerted by the spring and take the reading just as the spring leaves the brush.

END PLAY

GEAR REDUCTION UNITS Except MHB-4006

No dimensional specification necessary. Make sure the fiber thrust washer is on the drive end of the armature shaft and that a steel thrust washer is on each end of the Drive Assembly shaft. Refer to Parts List for thrust washer package number.

MHB-4006

Adjust to .005" to .050" with thrust washers on the commutator end of the shaft. Refer to Parts List for thrust washer package number.

DIRECT DRIVE UNITS

Adjust to .005" minimum with thrust washers. Maintain a clearance of 1/64" to 7/64" between the inside edge of the drive pinion and the outside edge of the drive end casting with the drive extended and the armature pushed toward the commutator end head. Refer to Parts List for thrust washer package number.


COMMUTATOR END HEAD

GEAR REDUCTION UNITS Except MHB-4005, R, 4009, R, 4014, R

Assemble the end head on the motor so that the letter "R" is directly in line with the motor terminal.

MHB-4005, R, 4009, R, 4014, R and DIRECT DRIVE UNITS

Assemble the end head on the motor so that the letter "L" is directly in line with the motor terminal.







MHB

AIRCRAFT STARTING MOTORS

Issued 4/1/83

Page 4 of 5



INFORMATION

COMMUTATOR REFINISHING

Minimum Diameter Undercut Total Indicator Runout Surface Finish

1.50" .003" max. .002" max. measure from bearing journals 50 microinch max.

TEST SPECIFICATION (75⁰F.)

See Figures 1 and 2 for no load and stall torque test connections.

GEAR REDUCTION UNITS

No Load Test (Motor Only) 20.0 volts, 35 max. amps., 4600 Min. RPM No Load Test (Complete Unit) 20.0 volts, 35 max. amps., 1300 Min. RPM Stall Torque Test 14.0 volts, 260 max. amps., 27.0 min. Ft. Lbs.

DIRECT DRIVE UNITS

No Load Test	20.0 volts,	36 max. amps.,	4600 min.	RPM
Stall Torque Test	14.0 volts,	260 max. amps.	, 8.0 min.	Ft. Lbs.

SHUNT FIELD CURRENT DRAW 8.7 to 10.4 amperes at 24.0 volts

		Internal	
<u>Unit</u>	Drive Type	Wiring	Application
MHB-4001, R	Gear Reduction	Fig. 3	Lycoming
MHB-4002, R	Gear Reduction	Fig. 3	Lycoming
MHB-4003, R	Gear Reduction	<u> </u>	Lycoming
MHB-4004	Direct	Fig. 4	Franklin
MHB-4005, R	Gear Reduction	Fig. 4	Lycoming
MHB-4006	Gear Reduction	Fig. 3	Continental
MHB-4007, R	Gear Reduction	Fig. 3	Lycoming
MHB-4008, R	Gear Reduction	Fig. 3	Lycoming
MHB-4009, R	Gear Reduction	Fig. 4	Lycoming
MHB-4010, R	Gear Reduction	Fig. 3	Lycoming
MHB-4011, R	Gear Reduction	Fig. 3	Lycoming
MHB-4012, R	Gear Reduction	Fig. 3	Lycoming
MHB-4013, R	Gear Reduction	Fig. 3	Lycoming
MHB-4014, R	Gear Reduction	Fig. 4	Lycoming
MHB-4015, R	Direct	Fig. 4	Lycoming
MHB-4016, R	Gear Reduction	Fig. 3	Lycoming
MHB-4017, R	Gear Reduction	Fig. 3	Lycoming
MHB-4018, R	Gear Reduction	Fig. 3	Lycoming
MHB-4019, R	Gear Reduction	Fig. 3	Lycoming



No Load

Stall Torque


WLE

BATTERY

VOLTMET

GROUND


STARTING MOTOR







GROUND











Tech. Data



MHJ SERIES

STARTIN	G MOTORS	
ISSUED:	5-15-81	(Rev.)

ORIG. EQUIP.MOTOR		SERVICE MOTOR	VOLTS: 24
PART NUMBER		PART NUMBER	APPLICATION
MHJ-4002 MHJ-4003,S MHJ-4004 MHJ-4004R MHJ-4005	USE USE USE USE	MHP-4101S MHP-4101S MHJ-4004R MHJ-4004R MHJ-4005R	Teledyne Continental Teledyne Continental Lycoming Service Motor Lycoming
MHJ-4005R		MHJ-4005R	Service Motor


Note:- Due to production design <u>of</u> the assemblies listed here-in the Field Coils being varnished and baked in place within the Frame; we have followed the advice of our Production Engineering Dept. and have recalled the servicing of the individual Field Coils. Commencing immediately, whenever Field Coils are required, the complete Frame & Field Assy. will be supplied.



File in the OE-A1 AIRCRAFT MANUAL



STARTING MOTOR SECTION



MHI SERIES STARTING MOTOR PARTS LIST

Assembly	Bendix Pin Pkg.	Brush Plate	Brush Spring	Term. Stud	0il Seal	Thru Bolt	Thrust Washer
	8 8	Assembly 9	Set 10	Package		Package	Package
MHJ-4002	[NR]	MDL-1064ES	MZ-19S	90-726	XA-1024	GJ-20DS	90-2677
MHJ-4003,S	[NR]	п	U U	11	u	и	u
MHJ-4004	90-2139	MDL-1064GS	Ш	U U	[NR]	GJ-20S	90-2232
MHJ-4004R	16	П		Ш	[NR]	u	U
MHJ-4005	n	u	н		[NR]	11	
MHJ-4005R	1	1 II	0		[NR]		
[NR]Not requ Assembly	ired. Gear	Gear Housing Assembly (16)	Needle Bearing	Retainer Plate (18)	Bendix Drive Shaft (19)		
		- マツ	<u>ــــــــــــــــــــــــــــــــــــ</u>	<u> </u>		····	
		Fun 7	[F	C		
MHJ-4002	[NR]	[NR]	[NR]	[NR]	[NR]		
MHJ-4003,S	[NR] [NR]	[NR]	[NR]	[NR]	[NR]		
	[NR] [NR] MZ-396	[NR] MHJ-1045	[NR] [a]	[NR] MZ-393	[NR] MHJ-44		
MHJ-4003,S	[NR] [NR] MZ-396 "	[NR] MHJ-1045 "	[NR] [a] [a]	[NR] MZ-393 "	[NR] MHJ-44 "		
MHJ-4003,S MHJ-4004	[NR] [NR] MZ-396	[NR] MHJ-1045	[NR] [a]	[NR] MZ-393	[NR] MHJ-44		

SECTION

η,

OE-A1 AIRCRAFT MANUAL



GENERAL INFORMATION

VOLTAGE 24

ROTATION MHJ-4002, 4003 - CWDE MHJ-4004, R, 4005, R - Motor CCWDE, Drive CWDE

BRUSHES 4

POLES 4

SWITCH Separate

DRIVE MHJ-4004, R, 4005, R - Rubber Folo Thru Type

GEAR REDUCTION

MHJ-4004, R, 4005, R - 3.38 to 1 Gear Ratio

SERVICE INFORMATION

LUBRICATION

MHJ-4002, 4003

Soak new bearings in SAE 20 oil before installation. Saturate the felt oiling pad in the commutator end head with SAE 20 oil. Allow excess oil to drain out before installing end head on motor. Put a light film of Lubriplate #777 on the armature shaft before assembling motor.

MHJ-4004, R, 4005, R

Thoroughly clean and repack needle bearings with Shell Alvania #2 or an equivalent bearing lubricant with 1-1/4 to 2 ounces or Texaco #1925 Molytex "0" or an equivalent Lithium soap base grease. (Also see Drive Assembly servicing).

DRIVE ASSEMBLY

The Drive Assembly should be thoroughly cleaned and relubricated when the motor is overhauled. <u>Do Not</u> use carburetor cleaner or any cleaning solution that could damage the rubber block inside the Drive Assembly. Use only clean petroleum base cleaners such as kerosene or "varsol". Thoroughly clean the Drive Assembly to remove all dirt, grease, and contamination from the screwshaft threads and control nut. The drive cup may also be removed to insure a thorough cleaning job. <u>Do Not</u> attempt to remove the control nut.

File in the



Tech. Data Aircraft Starting Motors Issued: 4/1/83



Page 2 of 4

INFORMATION

After the Drive Assembly has been cleaned and blown dry with compressed air, lubricate the drive with a spray on type silicone lubricant. Lubricate the motor shaft with the same silicone lubrcant before installing the Drive Assembly. When reassembling the drive on the shaft, make sure head washer covers both ends of the retaining pin.

BEARING REPLACEMENT

MHJ-4002, 4003

The drive end bearing must be pressed in flush with the oil seal counterbore. The oil seal must bottom against the counterbore.

MHJ-4004, R, 4005, R

Press the armature shaft needle bearing in approximately 3/16" below the edge of the casting on the side toward the armature. Press the Drive Assembly shaft needle bearing in flush with the casting on the side toward the Drive Assembly. Press the pinion housing bearing in flush with the outside edge of the casting.

BRUSH REPLACEMENT

Brushes must be replaced when they have worn down to a length of 1/4" or less. Refer to Service Bulletin ASM-1 for brush replacement procedure.

BRUSH SPRING TENSION

32 to 40 ounces with new brushes. Measure with a spring scale hooked under the spring at the brush. Pull on a line opposite the line of force exerted by the spring and take a reading just as the spring leaves the brush.

END PLAY (Armature Shaft Only)

Adjust to .005" to .050" with thrust washers on the commutator end of the shaft. Refer to Parts List for thrust washer package number.

POLE SHOE INSTALLATION

The pole shoes must be installed so that the longer tip is pointing in the same direction as armature rotation.

COMMUTATOR REFINISHING

Minimum Diameter

1.50" Undercut .003" max. Total Indicator Runout .002" max. measure from bearing journal • Surface Finish 50 microinch max.

TEST SPECIFICATIONS (75⁰F)

MHJ-4002, 4003

No Load Test 20.0 volts, 43 max. amps, 6200 min. RPM Stall Torque Test 8.0 volts, 210 max. amps, 8.0 min. Ft. Lbs.

MHJ

prestolite.	MHJ
SERVICE -	Aircraft Starting Motors
SERVICE -	Issued: 4/1/83
INFORMATION	Page 3 of 4

MHJ-4004, R, 4005, R- See Figures 1 and 2 for test connections.No Load Test (Motor Only)20.0 volts, 43 max. amps, 6200 min. RPMNo Load Test (Complete Unit)20.0 volts, 43 max. amps, 1800 min. RPMStall Torque Test8.0 volts, 210 max. amps, 27.0 min. Ft. Lbs.

SHUNT FIELD CURRENT DRAW 4.8 to 6.0 amperes at 24.0 volts.

Unit	Internal Wiring	Application
MHJ-4002	Figure 3	Continental
MHJ-4003,S	Figure 3	Continental
MHJ-4004, R	Figure 4	Lycoming
MHJ-4005, R	Figure 4	Lycoming

INSTALLATION NOTE

Prior to starting motor installation, clean any rust, corrosion or dirt from the mounting surfaces of the starting motor and engine. Also check all ground strap connections to make sure they are clean and tight.




Figure 1





Figure 2




MHJ		
Aircraft	Starting	Motors
Issued:	-	

Page 4 of 4





VIEWED FROM COMMUTATOR END



VIEWED FROM COMMUTATOR END

Figure 3

Figure 4



MMU SERIES

STARTING MOTORS ISSUED: 6-1-79

ORIG.EQUIP.MOTOR

SERVICE MOTOR

PART NUMBER

PART NUMBER


MMU-4001,R


USE MMU-4001R

APPLICATION

Lycoming







SHEET 2	ISSUED: 10-13-81(Rev.)					MMU SERIES		
Assembly	Armature	Brush Set	Frame & Field Assembly 3	Comm.End Head Assembly	Pinion Housing Assembly	D.E. Bearing 6	Brush Spring Set (7)	
MMU-4001,R	MMU-2386S	MHB-2012AS	MHB-2384BS	MBP-2002D	PS-1435	MG-77A	MZ-19S	
Assembly	Intermediate Bearing Assembly 8	Intermed. Bearing 9	Bendix Drive	Cover Band	Terminal Stud Package (12)	Thrust Washer Package		
MMU-4001,R	MZ-1236	MZ-339	EBB-124A[a]	MZ-24A	90-2502	90-2677		
a] 90-2139 E	3endix Pin Packa	ge(25 Pcs.) als	o available.					



GENERAL INFORMATION

VOLTAGE	24
ROTATION	CWDE
POLES	4

BRUSHES 4

DRIVE ASSEMBLY Rubber Folo-Thru Type

SERVICE INFORMATION

LUBRICATION

Soak new absorbent bronze bearings in SAE 20 oil before installation. Saturate the felt oiling pad in the commutator end head with SAE 20 oil. Allow excess oil to drain out before installing end head on motor. Put a light film of Lubriplate #777 on the drive end of the armature shaft before installing the intermediate bearing. (Also see Drive Assembly.)

DRIVE ASSEMBLY

The Drive Assembly should be thoroughly cleaned and re-lubricated when the motor is overhauled. <u>Do not</u> use carburetor cleaner or any cleaning solution that could damage the rubber block inside the Drive Assembly. Use only clean petroleum base cleaners such as kerosene or "Varsol". Thoroughly clean the Drive Assembly to remove all dirt, grease, and contamination from the screwshaft threads and control nut. The drive cup may also be removed to insure a thorough cleaning job. <u>Do not</u> attempt to remove the control nut.

After the Drive Assembly has been cleaned and blown dry with compressed air, lubricate the drive with a spray-on type silicone lubricant. Lubricate the motor shaft with the same silicone lubricant before installing the Drive Assembly. When reassembling the Drive on the shaft, make sure the head washer covers both ends of the retaining pin.

BEARING REPLACEMENT

Press the drive end bearing in flush with the outside edge of the casting. Press the intermediate bearing in flush to the side toward the armature.

File in the OE-A1 AIRCRAFT MANUAL



Tech. Data MMU

AIRCRAFT STARTING MOTOR Issued 4/1/83

Page 2 of 3



INTERMEDIATE BEARING PLATE

Use "Loctite Grade A" on threads of bearing plate retaining screws. Torque screws to 25 - 35 in/lbs.

BRUSH REPLACEMENT

Brushes must be replaced when they have worn down to a length of 1/4" or less. Refer to service ASM-1 for brush replacement procedure.

BRUSH SPRING TENSION

32 to 40 ounces with new brushes. Measure with a spring scale hooked under the spring at the brush. Pull on a line opposite the line of force exerted by the spring and take the reading just as the spring leaves the brush.

END PLAY

Adjust to .005" minimum with thrust washers on the commutator end of the armature shaft. Refer to Parts List for thrust washer package number.

COMMUTATOR END HEAD

Assemble the end head on the motor so that the letter "L" is directly in line with the motor terminal.

COMMUTATOR REFINISHING

Minimum Diameter	1.50"
Undercut	.003" max.
Total Indicator Runout	.002" max. measure from bearing journals
Surface Finish	50 microinch max.


TEST SPECIFICATIONS

20.0 volts, 35 max. amps., 3325 RPM No Load Test Stall Torque Test 14.0 volts, 250 max. amps., 10.4 min. Ft. Lbs.

SHUNT FIELD CURRENT DRAW 8.8 to 10.4 amperes at 24.0 volts

Unit	Drive Type	Application
MMU-4001, R	Direct	Lycoming





VIEWED FROM COMMUTATOR END





Tech. Data



MZ SERIES

STARTING MOTORS


ISSUED:12-31-80(Rev.)

ORIG.EQUIP.MOTO	R	SERVICE MOTOR	
PART NUMBER		PART NUMBER	APPLICATION
MZ-4203		MZ-4203	Franklin
MZ-4204,R	USE	MZ-4204R	Lycoming
MZ-4205,R	USE	MZ-4221R	Lycoming
MZ-4206,R	USE	MZ-4222R	Lycoming
MZ-4207,R	USE	MZ-4223R	Lycoming
MZ-4208,R	USE	MZ-4208R	Lycoming
MZ-4214		MZ-4214	Continental
MZ-4216,R	USE	MZ-4220R	Lycoming
MZ-4217,R	USE	MZ-4221R	Lycoming
MZ-4218,R	USE	MZ-4222R	Lycoming
MZ-4219,R	USE	MZ-4223R	Lycoming
MZ-4220,R	USE	MZ-4220R	Lycoming
MZ-4221, R	USE	MZ-4221R	Lycoming
MZ-4222, R	USE	MZ-4222R	Lycoming
MZ-4223,R	USE	MZ-4223R	Lycoming
MZ-4224,R	USE	MZ-4224R	Lycoming
MZ-4225,R	USE	MZ-4225R	Lycoming





STARTING MOTOR SECTION



MZ SERIES MOTOR PARTS LIST

ISSUED: 10-13-81(Rev.) SHEET 2

Ŋ

SECTION

			Assembly	Assembly	1	Pinion_Hsg.	
	<u> </u>	(2)	3	4	5	<u> </u>	
MZ-4203	MZ-2383	MZ-201 2AS	MZ-1005AS[*]	MZ-2002F	[NR]	MZ-1147	MZ-46A
MZ-4204,R	MZ-2386S	MBG-2012S	MZ-2385\$	MZ-2002U	[NR]	PS-1435	MG-77A
MZ-4205,R	MZ-23995	11	MZ-2397 S	MZ-2400	X-3991	[a]	[a]
MZ-4206,R	11	It	n	11	н	[b]	[b]
MZ-4207,R	ti	н	u	u	и	[c]	[c]
MZ-4208,R	U	16	u	n	н	[NR]	[NR]
MZ-4214	MZ-2412S	MBG-2012CS	MZ-2022DS	MZ-2002VS	[NR]	MZ-2413[d]	90-2018[e]
MZ-4216,R	MZ-2399S	MBG-2012S	MZ-2397 S	MZ-2400	X-3991	[b]	[b]
MZ-4217,R	11	IF	u	н	н	PS-2432B	MZ-298
MZ-4218,R	0	u	н	н	u	PS-1432C	н
MZ-4219,R	п	u	11		a	PS-1437B	п
MZ-4220,R	It	0 .	u	11	n	PS-1432C	н
4Z-4221,R	11	н	n	Ш	u	PS-2432B	н
MZ-4222,R	u	н	It	II	u	PS-1432C	п
MZ-4223,R	u	u u	n	н	н	PS-1437B	u
MZ-4224,R	ti	и	u	u	11	PS-1432C	н
MZ-4225,R	н	61		0	н	PS-1432F	и
[a] PS-2432BS PS-2432B [b] PS-1432CS PS-1432C [c] PS-1432BS PS-1437B [d] MZ-414S D	Housing & Shaf Pinion Hsg.,MZ- Housing & Shaf Pinion Hsg.,MZ- Housing & Shaf Pinion Hsg.,MZ- .E. Mounting Sc Seal Package.	t Pkg. must be 298 Bearing,MŽ t Pkg. must be 298 Bearing,MZ t Pkg. must be 298 Bearing,MZ	Assembly not ave used at time of -326 Bendix Driv used at time of -326 Bendix Driv used at time of -326 Bendix Driv kage is also ava	first repair. e Shaft may be f first repair. e Shaft may be f first repair. e Shaft may be f	replaced therea Individual Comp replaced therea Individual Comp	after. ponents- after. ponents-	

OE-A1 AIRCRAFT MANUAL

MZ SERIES MOTOR PARTS LIST

Assembly	Bendix Drive	Bendix Drive Shaft 9	Intermed. Bearing Assembly (10)	Brush Spring Set	Terminal Stud Package (12)	Cover Band	0i1 Sea1 (14)
MZ-4203	EBB-133[f]	[NR]	[NR]	MZ-19S	90-716	MZ-24A	XA-560
MZ-4204,R	EBB-124A[f]	[NR]	MZ-1236	н	90-877	11	[NR]
1Z-4205,R	EBB-75A[g]	[a]	[NR]	п	90-876	11	[NR]
IZ-4206,R		[b]	[NR]	n	6	u	[NR]
IZ-4207,R	п	[c]	[NR]	u		li I	[NR]
IZ-4208,R	[NR]	[NR]	[NR]	п	н	u	[NR]
Z-4214	[h]	[h]	[NR]	u	90-877	u u	[NR]
Z-4216,R	E8B-142A[g]	[b]	[NR]	н	90-876	n	[NR]
Z-4217,R	EBB-75A[g]	MZ-326	[NR]	н	n	п	[NR]
Z-4218,R	11	я	[NR]	U U	п	н	[NR]
Z-4219,R	n	ti.	[NR]	н	н	, u	[NR]
Z-4220,R	EBB-142A[g]	н	[NR]	н	н	n	[NR]
Z-4221,R	EBB-131A[f]	MZ326A	[NR]	u	u	u	[NR]
Z-4222,R		u	[NR]	п	и	н	[NR]
Z-4223,R	IJ	П	[NR]	п	u	- 11	[NR]
Z-4224,R	EBB-131A[j]	14	[NR]	п	11	п	[NR]
Z-4225,R		n	[NR]	u	u	et .	[NR]
PS-2432B [b] PS-1432C PS-1432C [c] PS-1437B PS-1437B [f] 90-2139 [g] 90-2140 [h] Not part	S Housing & Shafi Pinion Hsg.,MZ-2 S Housing & Shafi Pinion Hsg.,MZ-2 S Housing & Shafi Pinion Hsg.,MZ-2 Bendix Pin Packag Of this Motor; a endix Pin also an uired.	298 Bearing,MZ- t pkg. must be 298 Bearing,MZ- t Pkg. must be 298 Bearing,MZ- ge(25Pcs.) also ge(25Pcs.) also available thru	326 Bendix Driv used at time of 326 Bendix Driv used at time of 326 Bendix Driv available.	e Shaft may be first repair. e Shaft may be first repair. e Shaft may be	replaced therea Individual Com replaced therea Individual Com	after. ponents- after. ponents-	

MOTOD DADTE LICT

SHEET 3 $1001100, 0_{-}3_{-}01 (P_{-})$

	TOR PARTS LI	Gear	Needle	Retainer	Thrust	-3-81 (Rev.)	SHEET
Assembly	Gear	Housing Assembly	Bearing	Plate	Washer Package	Connector	Switch
	15	(16)	(17)	(18)	(19)	20	(21)
Z-4203	[NR]	[NR]	[NR]	[NR]	90-2677	MZ-144	[n]
Z-4204,R	[NR]	[NR]	[NR]	[NR]	90-2271	[NR]	[NR]
Z-4205,R	MZ-396	MZ-1390	[m]	MZ-393	90-601	[NR]	[NR]
Z-4206,R	11	11	[m]	и	н	[NR]	[NR]
Z-4207,R	н		[m]	n	Ð	[NR]	[NR]
Z-4208,R	[NR]	п	[m]	[NR]	н	[NR]	[NR]
Z-4214	[k]	[NR]	[NR]	[NR]	90-2006	[NR]	[NR]
Z-4216,R	MZ-396	MZ-1390	[m]	MZ-393	90-601	[NR]	[NR]
Z-4217,R	н	11	[m]	п	11	[NR]	[NR]
Z-4218,R	п	n	[m]	п	u	[NR]	[NR]
Z-4219,R	п	н	[m]	н	11	[NR]	[NR]
Z-4220,R	н	u	[m]	11	11	[NR]	[NR]
Z-4221,R	11	н	[m]	u		[NR]	[NR]
Z-4222,R	н	н	[m]	п	IF	[NR]	[NR]
Z-4223,R	11	п	[m]	н	u	[NR]	[NR]
Z-4224,R	и	п	[m]	п	al a	[NR]	[NR]
Z-4225,R	Ш	U U	[m]	u	n	[NR]	[NR]
k] Used with m] Two used- n] No longer R] Not requ	XA-997 is 1/2 vavailable.	of this Motor, " I.D. & XA-998	available thru is 13/16 I.D.	Continental #6	39153.		





GENERAL INFORMATION

- VOLTAGE 12
- <u>ROTATION</u> All Gear Reduction units except MZ-4216, R, 4220, R Motor CCWDE, Drive CWDE

MZ-4216, R, 4220, R - Motor CWDE, Drive CCWDE.

All Direct Drive units - CWDE.

- BRUSHES 4
- POLES 4
- <u>SWITCH</u> Gear Reduction Units Separate Direct Drive Units - Switch mounted on motor
- DRIVE MZ-4214 uses a Formsprag, Torque Limiting Drive

All others use Rubber Folo Thru Type Drives

GEAR REDUCTION

MZ-4214 - 7 to 1 Gear ratio All others 3.38 to 1 Gear ratio

SERVICE INFORMATION

LUBRICATION

GEAR REDUCTION UNITS Except MZ-4214

Thoroughly clean and repack needle bearings with Shell Alvania #2 or an equivalent bearing lubricant. Pack gear box with 1-1/4 to 2 ounces of Texaco #1925 Molytex "O" or an equivalent Lithium soap base grease. (Also see Drive Assembly servicing.)

DIRECT DRIVE UNITS AND MZ-4214

Soak new absorbent bronze bearings in SAE 20 oil before installation. Saturate the felt oiling pad in the commutator end head with SAE 20 oil. Allow excess oil to drain out before installing end head on motor. Put a light film of Lubriplate #777, or equivalent, on the drive end of the armature shaft before installing the intermediate bearing or drive end head. (Also see Drive Assembly servicing.)



Tech. Data AIRCRAFT STARTING MOTOR

Issued 4/1/83

Page 2 of 5

Prestolite. SERVICE

INFORMATION

FORMSPRAG DRIVE

These units are not serviceable. If the drive feels rough when rotated in its free direction, or if the gear rotates in both directions, the drive should be replaced. Never submerge the drive assembly in a cleaning solution. To do so will destroy or contaminate the internal lubrication which cannot be replaced.

DRIVE ASSEMBLY

The Drive Assembly should be thoroughly cleaned and re-lubricated when the motor is overhauled. Do not use carburetor cleaner or any cleaning solution that could damage the rubber block inside the drive assembly. Use only clean petroleum base cleaners such as kerosene or "Varsol". Thoroughly clean the Drive Assembly to remove all dirt, grease, and contamination from the screwshaft threads and control nut. The drive cup may also be removed to insure a thorough cleaning job. Do not attempt to remove the control nut. After the Drive Assembly has been cleaned and blown dry with compressed air, lubricate the drive with a spray-on type silicone lubricant. Lubricate the motor shaft with the same silicone lubricant before installing the drive assembly. When reassembling the early style drive on the shaft, make sure the spirol pin does not project beyond the outside diameter of the pinion sleeve. When reassembling the late style drive, make sure the head washer covers both ends of the retaining pin.

BEARING REPLACEMENT

GEAR REDUCTION UNITS

When replacing needle bearings they must be pressed in flush with the edge of the casting. The armature bearing must be flush on the side toward the armature and the Drive Assembly shaft bearing flush on the side toward the Drive Assembly. Press the pinion housing bearing in flush with the outside edge of the casting.

DIRECT DRIVE UNITS

Press the drive end bearing in flush with the outside edge of the casting. Press the oil seal into the casting so that it bottoms against the oil seal counterbore.

INTERMEDIATE BEARING PLATE MZ-4204, R

Use "Loctite Grade A" on threads of bearing plate retaining screws. Torque screws to 25-35 in/lbs.

ΜZ



BRUSH REPLACEMENT

Brushes must be replaced when they have worn down to a length of 1/4" or less. Refer to Service Bulletin ASM-1 for brush replacement procedure.

BRUSH SPRING TENSION

32 to 40 ounces with new brushes. Measure with a spring scale hooked under the spring at the brush. Pull on a line opposite the line of force exerted by the spring and take the reading just as the spring leaves the brush.

END PLAY

GEAR REDUCTION UNITS Except MZ-4214

No dimensional specification necessary. Make sure the fibre thrust washer is on the drive end of the armature shaft and that a steel thrust washer is on each end of the Drive Assembly shaft. Refer to Parts List for thrust washer package number.

DIRECT DRIVE UNITS

MZ-4203, adjust to .005" minimum with thrust washers. Maintain a clearance of 1/64" to 7/64" between the inside edge of the drive pinion and the outside edge of the drive end casting with the drive extended and the armature pushed toward the commutator end head. Refer to Parts List for thrust washer package number.

MZ-4204 and MZ-4214, adjust to .005" minimum with thrust washers on the commutator end of the armature shaft. Refer to Parts List for thrust washer package number.

COMMUTATOR END HEAD

GEAR REDUCTION UNITS Except MZ-4216, R, 4220, R

Assemble the end head on the motor so that the letter "R" is directly in line with the motor terminal.

DIRECT DRIVE UNITS AND MZ-4216, R, 4220, R

Assemble the end head on the motor so that the letter "L" is directly in line with the motor terminal.





MZ

AIRCRAFT STARTING MOTOR

Issued 4/1/83 Page 4 of 5

Fage 4 UI S

🔔 prestolite.

INFORMATION

SERVICE

COMMUTATOR REFINISHING

Minimum Diameter1.50"Undercut.003" max.Total Indicator Runout.002" max. measure from bearing journalsSurface Finish50 microinch max.

TEST SPECIFICATION (75° F.)

(See Figures 1 and 2 for no load and stall torque test connections.)

GEAR REDUCTION UNITS

No Load Test (Motor Only)10.0 volts, 50 max. amps., 8000 min. RPMNo Load Test (Complete Unit)10.0 volts, 75 max. amps., 1600 min. RPMStall Torque Test4.0 volts, 560 max. amps., 37.5 min. Ft. Lbs.

DIRECT DRIVE UNITS No Load Test Stall Torque Test

10.0 volts, 75 max. amps., 5500 min. RPM 4.0 volts, 560 max. amps., 11.1 min. Ft. Lbs.

MZ-4214 - MOTOR ONLY No Load Test Stall Torque Test

10.0 volts, 50 max. amps., 8000 min. RPM 4.0 volts, 560 max. amps., 11.1 min. Ft. Lbs.

		Internal	
Unit	Drive Type	Wiring	Application
MZ-4203	Direct	Fig. 3	Franklin
MZ-4204, R	Direct	Fig. 3	Lycoming
MZ-4205, R	Gear Reduction	Fig. 4	Lycoming
MZ-4206, R	Gear Reduction	Fig. 4	Lycoming
MZ-4207, R	Gear Reduction	Fig. 4	Lycoming
MZ-4208, R	Gear Reduction	Fig. 4	Lycoming
MZ-4214	*	Fig. 4	Continental
MZ-4216, R	Gear Reduction	Fig. 3	Lycoming
MZ-4217, R	Gear Reduction	Fig. 4	Lycoming
MZ-4218, R	Gear Reduction	Fig. 4	Lycoming
MZ-4219, R	Gear Reduction	Fig. 4	Lycoming
MZ-4220, R	Gear Reduction	Fig. 3	Lycoming
MZ-4221, R	Gear Reduction	Fig. 4	Lycoming
MZ-4222, R	Gear Reduction	Fig. 4	Lycoming
MZ-4223, R	Gear Reduction	Fig. 4	Lycoming
MZ-4224, R	Gear Reduction	Fig. 4	Lycoming
MZ-4225, R	Gear Reduction	Fig. 4	Lycoming

*Formsprag Torque Limiting Drive used with, but not a part of, this motor.

INSTALLATION NOTE

Prior to starting motor installation, clean any rust, corrosion or dirt from the mounting surfaces of the starting motor and engine. Also check all ground connections to make sure they are clean and tight.






Figure 1






Figure 2



VIEWED FROM COMMUTATOR END

File in the













(Early Production Type) **BELT DRIVEN** AIRCRAFT **ALTERNATORS**

BELT DRIVEN AIRCRAFT ALTERNATOR


Prestolite Belt Driven Aircraft Alternators (Figure 1) have been designed and constructed to provide extended periods of trouble-free operation with a minimum amount of maintenance. They have also been designed and constructed to withstand the vibration and extreme temperature changes encountered in aircraft applications.

DESCRIPTION

The principal components (Figure 2) of the alternator are (1) the stator, (2) the rotor, (3) the slip ring end head, (4) the drive end head and (5) the rectifiers.









1. The stator consists of a laminated iron core on which the three phase windings are wound in slots around the inside circumference. Leads are connected to each of the three points of the phase windings and each lead is connected to a pair of rectifiers, one negative and one positive.

2. The rotor consists of a single field coil encased between two four-poled, interleaved iron sections assembled on the shaft. The ends of the field coil are connected to a pair of slip rings which are insulated from each other and from the shaft.

3. The slip ring end head supports the rectifier mounting plate and rectifiers, a prelubricated bearing in which the rotor shaft rotates, the brush holders and brushes, the field and output terminals, and a blast tube assembly. 4. The drive end head supports a sealed, prelubricated ball bearing in which the drive end of the rotor shaft rotates.

5. The negative rectifiers are pressed into the slip ring end head and the positive rectifiers are pressed into the rectifier mounting plate and are connected to the stator leads. The rectifiers are rated at 150 PIV minimum for transient voltage protection.

OVERHAUL

When repairing the alternator, complete disassembly may not be required. In some cases it will only be necessary to perform those operations which are required to effect the repair.

However, in this section, the complete overhaul is covered step by step to provide detailed information on each operation. In actual service practice, these operations may be used as required.

DISASSEMBLY

<u>CAUTION</u>: To prevent damage to the blast tube assembly, it should be removed before any servicing is attempted.

1. Using a strap wrench, remove the pulley nut. The pulley must be removed with a puller. Remove the fan, woodruff key, and spacer from the shaft. Now remove the four through bolts. Tap the drive end head lightly with a rawhide hammer and separate the end head and rotor assemblies from the stator and slip ring end head. Be careful not to lose the brush springs when separating the assemblies.

2. Remove the nuts, lockwashers, and flatwashers from the output terminal and remove the rectifier mounting plate mounting screw. Note carefully the correct assembly of the insulator washers and bushings. Using the same special tools shown in Figure 3, support the end head and press out the three negative rectifiers. The stator can now be separated from the slip ring end head.

3. To remove the slip ring bearing, support the end head and press bearing out, using the proper tools shown in Figure 4.





Figure 3

4. If necessary, press the rectifiers out of the rectifier mounting plate as shown in Figure 3. To disconnect the rectifier from the stator leads, use pliers to grip the rectifier leads and touch the soldered end of the connector with a hot soldering iron. Pull the connector off the three leads when the solder is melted.

5. To remove the drive end head from the rotor shaft, use a puller that grips on the bearing retainer plate as shown in Figure 5. Do not attempt to remove by supporting the end head and pressing on the shaft, as this may result in distortion of the end head or stripping of the retainer plate screws. Remove the three retainer plate screws and press the bearing out of the end head. Figure 6.






Figure 6


INSPECTION AND TESTING OF COMPONENTS

Upon completion of the disassembly, all parts should be cleaned and visually inspected for cracks, wear or distortion and any signs of overheating or mechanical interference.

1. Rotor - The rotor should be tested for grounded or shorted windings. The ground test can be made with test probes, connected in series with a 110 volt test lamp, an ohmmeter or any type continuity tester. Figure 7. There must not be any continuity between the slip rings and the rotor shaft or poles.

To test for shorted turns in the rotor winding, connect a voltmeter, ammeter and rheostat as shown in Figure 8, or use an ohmmeter. Rotor current draw and resistance are listed on individual specification pages. Excessive current draw or a low ohmmeter reading indicates shorted windings. No current draw or an infinite ohmmeter reading would indicate an open winding.







2. Rectifiers - A diode rectifier tester will detect and pinpoint open or shorted rectifiers without going through the operation of disconnecting the stator leads. However, if a tester is not available, test probes and a #57 bulb, connected in series with a 12 volt battery, can be used in the following manner. Touch one test probe to a rectifier heat sink and the other test probe to a lead from one of the rectifiers in that heat sink. Then reverse the position of the leads. The test bulb should light in one direction and not light in the other direction. If the test bulb lights in both directions, one or more of the rectifiers in that heat sink is shorted. To pinpoint the defective rectifier, the stator leads must be disconnected and the above test repeated on each rectifier. Open rectifiers can only be detected, when using the test bulb, by disconnecting the stator leads. The test bulb will fail to light in either direction if the rectifier is open.

3. Stator - The stator can be tested for open or grounded windings with a 12 volt test bulb, described in the rectifier section, or an ohmmeter, in the following manner. Separate the stator from the slip ring end head just far enough to insert a couple of rags or blocks of wood. In other words, insulate the stator from the end head. To test for grounded windings, touch one test bulb or ohmmeter probe to any stator lead, and the other test bulb or ohmmeter probe to the stator frame. If the test bulb lights, or the ohmmeter indicates continuity, the stator is grounded. To test for open windings, connect one test probe to the stator is double. To test for open windings, connect one test bulb must light, or the ohmmeter must show continuity.

Due to the low resistance in the stator windings, shorted windings are almost impossible to locate. However, shorted stator windings will usually cause the alternator to "growl" or be noisy during operation and will usually show some signs of overheating.

If all other electrical checks are normal and the alternator fails to supply its rated output, the stator should be replaced to determine whether or not it is the faulty component.

Check the bearings for roughness or excessive clearance to determine if they should be replaced. Note: New bearings are prelubricated; additional lubrication is not required.

If excessively dirty, the end housings may be wiped clean with a cloth dampened in solvent.

ASSEMBLY

1. Press the ball bearing into the drive end head using a flat block approximately 2" square so that the pressure is exerted on the outer race of the bearing. Install the

6

retainer plate. With the snap ring and retainer cup in place on the rotor shaft, use a tool that fits over the shaft and against the inner bearing race, and press until the inner bearing race is against the snap ring retainer cup. Figure 9.

2. To install the rectifiers in the slip ring end head or rectifier mounting plate, support the end head or mounting plate and press the rectifiers in with a special driver tool. Figure 10. (Use arbor press - do not hammer.)




Figure 9

Figure 10

Strip the insulation back approximately 1/4" on the stator leads and reconnect them to the rectifiers. The connector sleeves should be soldered on the rectifier and stator leads. WHEN SOLDERING THESE CONNECTIONS, USE PLIERS AS A HEAT-DAM ON THE LEAD BETWEEN THE SOLDER JOINT AND THE RECTIFIER. TOO MUCH HEAT WILL DAMAGE THE RECTIFIERS.

3. To spread the brushes when installing the rotor, use an Allen wrench or equivalent to hold insulated brush. (Use hole in the end head just below the field terminal.) The ground brush is held with a hook made out of stiff wire. Figure 11.

4. Spread the brushes and manually press the stator and slip ring end head assemblies and the drive end head and rotor assemblies together. Be sure the through bolt holes line up. (There are no locator pins used.) Install and tighten through bolts. After releasing brushes, check to be sure that the rotor does not rub the stator or brush leads and that the rotor turns freely when rotated by hand.




Figure 11

5. Install spacer, woodruff key, fan, pulley, lockwasher and nut. Tighten nut using a strap wrench. (Do not install blast tube assembly on the alternator until after the unit has been bench tested.)

ALTERNATOR BENCH TEST

Upon completion of assembly, the alternator should be tested for output. This test is made to determine whether the alternator is capable of delivering rated output. The alternator must meet output specifications before regulator tests are attempted.

Wiring connections for bench testing the alternator are shown in Figure 12. Refer to the individual specification pages for output test figures. Adjust the carbon pile, if necessary, to obtain the specified voltage.

After bench testing the alternator, install the safety wire in the through bolts and install the alternator on the engine.

Note: Always refer to the airframe manufacturers wiring diagram when installing the alternator or testing the alternator on the aircraft.




Figure 12

PRECAUTIONS TO BE OBSERVED WHEN TESTING OR SERVICING THE ELECTRICAL SYSTEM

- 1. DISCONNECT THE BATTERY, before connecting or disconnecting test instruments (except voltmeter) or before removing or replacing any unit or wiring. Accidental grounding or shorting at the regulator, alternator, ammeter or accessories, will cause severe damage to the units and/or wiring.
- 2. THE OUTPUT LEAD MUST NOT BE REMOVED FROM THE ALTERNATOR WHILE THE ROTOR WINDING IS ENERGIZED AND THE ALTERNATOR IS OPERATING
- 3. DO NOT ATTEMPT TO POLARIZE THE ALTERNATOR. No polarization is required. Any attempt to do so may result in damage to the alternator, regulator or circuits.
- 4. GROUNDING OF THE ALTERNATOR OUTPUT TERMINAL MAY DAMAGE THE ALTERNATOR AND/OR CIRCUIT AND COMPONENTS.
- 5. REVERSED BATTERY CONNECTIONS MAY DAMAGE THE RECTIFIERS, VEHICLE WIRING OR OTHER COMPONENTS OF THE CHARGING SYSTEM. Battery polarity should be checked with a voltmeter before connecting the battery. MOST VEHICLES ARE NEGATIVE GROUND.
- 6. IF A BOOSTER BATTERY OR FAST CHARGER IS USED, ITS POLARITY MUST BE CONNECTED CORRECTLY TO PREVENT DAMAGE TO THE ELECTRICAL SYSTEM COMPONENTS.

SOLID STATE AIRCRAFT ALTERNATOR REGULATOR





THE AIRCRAFT ALTERNATOR REGULATOR

Alternator output voltage can, within the limits of the design capability of the alternator, be controlled by properly varying the average level of current flow in the rotor winding and the PRESTOLITE full electronic solid state regulator is well suited for this purpose.

The Prestolite alternator, due to its design, has self-limiting current characteristics and needs no current-limiting unit in the regulator.

THE REGULATOR COMPONENTS

THE TRANSISTOR

The transistor is an electronic switch which can turn on and turn off the flow of current in an electric circuit. It has no mechanical or moving parts to wear out.

THE RECTIFIER DIODE

The rectifier diode will pass current in one direction only (forward direction); and in this respect, it may be compared to a one-way check valve.

THE ZENER DIODE

The Zener diode, in addition to passing current in the forward direction, will pass current in the reverse direction only when a particular value of voltage is applied in the reverse direction. It is this Zener action which makes it adaptable for use as a voltage sensing device in the regulator.

THE RESISTOR

The resistor is a device which is used to limit current flow.

HOW THE REGULATOR OPERATES

When ignition switch is turned on, battery voltage is applied to the "I" (ignition) terminal of the regulator.




Figure 1.

 $\mathbf{2}$

The NPN power transistor, T3, is turned on by current flow from the ignition terminal through R-6 and the collector emitter junction of T2 through D2 through the base emitter junction of T3 to ground.

Whenever the power transistor, T3, is on, T2 is also on and T1 is off, current will flow from the ignition terminal, through the field winding, through the collector - emitter of T3 to ground.

With the ignition switch on, current will flow from the "I" terminal regulator ground through a voltage dividing network consisting of R-1, R-2 and P-1. This network determines the system operating voltage relative to the Zener diode, Z1, reverse conducting voltage.

When the system voltage connected to "I" terminal reaches a value at which the Zener diode connected to the divider network conducts, current will flow from the "I" terminal through R-1 through Z1 and through the base emitter junction of T1 to ground. This causes the collector emitter junction of T1 to conduct which diverts the base current of T2 flowing from "I" terminal through R-4 to ground, turning off T2 which turns off T3, de-energizing the rotor winding; then, when the alternator output voltage falls to a value which permits Z1 to cease conduction, T1 will turn off which turns on T2 and T3, re-energizing the rotor winding.

This sequence is performed so rapidly that the rotor current average appears as a value usually less than full rotor current depending on rotor RPM and system load connected.

Each time the power transistor, T3, is turned off, current flow in the rotor winding is reduced. This causes the rotor magnetic field to collapse which would generate high voltage at the power transistor, T3, if a path were not provided so that the field current can decay at a slower rate, field suppression diode, D1, provides this path, thus protecting the system and regulator from possible damage.

Temperature compensation is flat which means the regulator will hold the alternator output voltage constant with temperature increase or decrease after initial warm-up.

The PRESTOLITE solid state regulator uses three NPN silicon transistors.

Capacitor, C1 is used to filter ripple and alternator diode switching spike when operating batteryless.

Neon lamp, L-1, provides transient voltage protection acting as a surge suppressor.

Control P1 is used to provide a limited range of voltage adjustment.

PREPARATION FOR TESTING

- Caution: Do Not Interchange Regulator Leads. This will destroy regulator and void warranty.
- 1. The aircraft technician or other electrical systems specialist, must disconnect the battery ground cable at the battery before connecting or disconnecting a test ammeter or other test equipment or before making wiring changes in the electrical system.
- 2. When a voltmeter only is to be used for circuit testing, the battery need not be disconnected, provided caution is used when connecting or disconnecting the voltmeter.
- 3. When installing a battery in a vehicle, be sure that the battery negative terminal is in a position so that this terminal can be connected to the battery ground cable for negative ground systems.
- 4. The regulator, when installed in a vehicle, should be mounted on a metal area, and in a place where it will not be subjected to excessive temperature.
- 5. To insure a good regulator ground, a permanent ground lead should be connected between the regulator mounting bolt and the alternator frame.
- 6. The alternator does not need to be polarized; therefore, never connect ground, even momentarily, to either the regulator field terminal or to the alternator field terminals. Do not interchange I and F leads to regulator as this will destroy the regulator.
- 7. The alternator should be in good condition and capable of producing full output, and the alternator drive belt must be adjusted tight enough to prevent slippage.
- 8. The battery must be in good condition and should be fully charged.
- 9. The voltmeter and the ammeter should be of the best quality and should be accurate.
- 10. A carbon-pile connected across the battery may be used to load the charging circuit while testing the regulator.

TESTING THIS REGULATOR

- 1. The procedure for testing this regulator, whether on the vehicle or on the test bench, remains the same. Connect test meters as shown in Fig. 2.
- 2. All circuit connections should be clean and tight. This includes the test instrument connections which must not come loose or open the charging circuit at any time while the system is operating.




Figure 2.

- 3. The voltmeter will not indicate the true regulator setting until the regulator has been operating in the charging system or on the test bench for at least 1 minute, at a charge rate of from 10 to 15 amperes.
- 4. Connect the voltmeter and the ammeter as shown in Figure 2. Start the engine and adjust its speed to obtain 3,000 to 4,000 alternator RPM. Turn on accessories as needed to establish 10 to 15 ampere electrical load, or use a carbon-pile across the battery to obtain this charge rate.
- 5. After 1 minute operating time, check the regulator operating voltage as indicated by the voltmeter. SEE THE SERVICE SPECIFICATIONS for the correct operating voltage. The operating voltage is shown for the ambient temperature in which the regulator is operating.
- 6. If the voltmeter reading indicates that the operating voltage is not within limits, lift the plastic plug from top of regulator and adjust the voltage to the desired value. Replace the plug after adjustment. Before condemning the regulator, recheck the alternator and the battery; making sure that they are in good condition. Recheck all circuit connections and all wiring for unwanted resistance (voltage drop test). Recheck the voltmeter for accuracy and repeat the entire operating test.

L-652A

10/68

Prestolite Technical Service Toledo, Ohio 43601

restolite 1 **BELT DRIVEN** AIRCRAFT

ALTERNATORS

Form L-655A

Prestolite Belt Driven Aircraft Alternators (Figure 1) have been designed and constructed to provide extended periods of trouble-free operation with a minimum amount of maintenance. They have also been designed and constructed to withstand the vibration and extreme temperature changes encountered in aircraft applications.

DESCRIPTION

The principle components (Figure 2) of the Aircraft Alternator are (1) the Brush Holder Assembly, (2) the Slip Ring End Head, (3) the Rectifiers, (4) the Stator, (5) the Rotor and (6) the Drive End Head.








Figure 2

1. The brush and holder assembly contains two brushes, two brush springs, a brush holder and insulators. Each brush is connected to a separate terminal stud and is insulated from ground. The brush and holder assembly can easily be removed for inspection or brush replacement purposes.

2. The slip ring end head provides the mounting for the rectifiers and rectifier mounting plate, output and auxiliary terminal studs, and the brush and holder assembly. The slip ring end head contains a roller bearing and outer race assembly and a grease seal.

3. The rectifiers used in these units are rated at 150 P.I.V. minimum for transient voltage protection. Three positive rectifiers are mounted in the rectifier mounting plate while the three negative rectifiers are mounted in the slip ring end head. Each pair of rectifiers is connected to a stator lead with high temperature solder. The stator leads are anchored to the rectifier mounting plate with epoxy cement for vibration protection.

4. The stator contains a special lead which is connected to the center of the three phase windings and is used to activate low voltage warning systems or relays. The stator has been treated with a special epoxy varnish for high temperature resistance.

5. The rotor contains the slip ring end bearing inner race and spacer on the slip ring end of the shaft. The rotor winding and winding leads have been specially treated with a high temperature epoxy cement to provide vibration and temperature resistance characteristics. High temperature solder is used to secure the winding leads to the slip rings.

6. The drive end head supports a sealed, prelubricated ball bearing in which the drive end of the rotor shaft rotates.

OVERHAUL

When repairing the alternator, complete disassembly may not be required. In some cases it will only be necessary to perform those operations which are required to effect the repair.

However, in this section, the complete overhaul is covered step by step to provide detailed information on each operation. In actual service practice, these operations may be used as required.

DISASSEMBLY

1. Remove the two #10-24 screws holding the brush holder assembly in the slip ring end head. Remove the brush and holder assembly from the end head.

2. Remove the safety wire from the through bolts. Hold the pulley with a strap wrench and remove the pulley nut. The pulley must be removed with a puller. Remove the fan, woodruff key and spacer from the shaft.

3. Remove the four through bolts and tap the drive end head lightly to separate the drive end head and rotor, as a unit, from the stator and slip ring end head.

4. Remove the nuts, lock washers, flatwashers and insulators from the output and auxiliary terminal studs. Note carefully the correct assembly of the insulator washers and bushings. Using the special tools shown in Figure 3, support the end head and press out the three negative rectifiers. The end head can now be separated from the stator assembly.

5. To remove the slip ring end bearing and grease seal, it will be necessary to have a hook type or impact type bearing puller as shown in Figure 4. Do not remove the bearing unless replacement is necessary.

3



Figure 3


The inner race of the slip ring end bearing is pressed onto the rotor shaft. When bearing replacement is necessary, always replace the complete bearing assembly, including the inner race.

6. To remove the drive end head from the rotor shaft, use a puller that grips on the



Figure 4

bearing retainer plate as shown in Figure 5. Do not attempt to remove by supporting the end head and pressing on the shaft, as this may result in distortion of the end head or stripping of the retainer plate screws. Remove the three retainer plate screws and press the bearing out of the end head. Figure 6.








INSPECTION AND TESTING OF COMPONENTS

Upon completion of the disassembly, all parts should be cleaned and visually inspected for cracks, wear or distortion and any signs of overheating or mechanical interference.

1. Rotor - The rotor should be tested for grounded or shorted windings. The ground test can be made with test probes, connected in series with a 110 volt test lamp, an ohmmeter or any type of continuity tester. Figure 7. There must not be any continuity between the slip rings and the rotor shaft or poles.

To test for shorted turns in the rotor winding, connect a voltmeter, ammeter and rheostat as shown in Figure 8, or use an ohmmeter. Rotor current draw and resistance are listed on the individual specification pages. Excessive current draw or a low ohmmeter reading indicates shorted windings. No current draw or an infinite ohmmeter reading would indicate an open winding.



2. Rectifiers - A diode rectifier tester will detect and pinpoint open or shorted rectifiers without going through the operation of disconnecting the stator leads. However, if a tester is not available, test probes and a #57 bulb, connected in series with a 12 volt battery, can be used in the following manner. Touch one test probe to a rectifier heat sink and the other test probe to a lead from one of the rectifiers in that heat sink. Then reverse the position of the leads. The test bulb should light in one direction and not light in the other direction. If the test bulb lights in both directions, one or more of the rectifiers in that heat sink is shorted. To pinpoint the defective rectifier, the stator leads must be disconnected and the above test repeated on each rectifier. Open rectifiers can only be detected, when using the test bulb, by disconnecting the stator leads. The test bulb will fail to light in either direction if the rectifier is open.

3. Stator - The stator can be tested for open or grounded windings with a 12 volt test bulb, described in the rectifier section, or an ohmmeter, in the following manner. Separate the stator from the slip ring end head just far enough to insert a couple of rags or blocks of wood. In other words, insulate the stator from the end head. To test for grounded windings, touch one test bulb or ohmmeter probe to the auxiliary terminal or any stator lead, and the other test bulb or ohmmeter probe to the stator frame. If the test bulb lights, or the

6

ohmmeter indicates continuity, the stator is grounded. To test for open windings, connect one test probe to the auxiliary terminal or the stator winding center connection and touch each of the three stator leads. The test bulb must light, or the ohmmeter must show continuity.

Due to the low resistance in the stator windings, shorted windings are almost impossible to locate. However, shorted stator windings will usually cause the alternator to "growl" or be noisy during operation and will usually show some signs of overheating.


If all other electrical checks are normal and the alternator fails to supply its rated output, the stator should be replaced to determine whether or not it is the faulty component.

4. Bearings and Seals - Whenever the alternator is overhauled, new bearings and oil or grease seals are recommended, even though the bearings and seals appear to be in good condition. A faulty seal can cause an alternator to fail within a very short period of time.

ASSEMBLY

1. Press the ball bearing into the drive end head using a flat block approximately 2" square so that the pressure is exerted on the outer race of the bearing. Install the retainer plate. With the snap ring and retainer cup in place on the rotor shaft, use a tool that fits over the shaft and against the inner bearing race, and press until the inner bearing race is against the snap ring retainer cup. Figure 9.


2. Carefully install the rectifiers in the slip ring end head or rectifier mounting plate by supporting the unit and using the special tools illustrated in Figure 10.



(Use arbor press - do not hammer.) Reconnect the stator leads to the rectifiers. WHEN SOLDERING THESE CONNECTIONS, USE PLIERS AS A HEAT DAM ON THE LEAD BETWEEN THE SOLDER JOINT AND THE RECTIFIER. TOO MUCH HEAT WILL DAMAGE THE RECTIFIERS. Reassemble the rectifier mounting plate studs and insulators, making sure they are in the correct order. See Figure 11.

After the slip ring end head is completely assembled, the stator and rectifier leads must be secured to the rectifier mounting plate with epoxy. Make sure the stator leads are positioned so that they do not interfere with the rotor.

3. Install the slip ring end bearing and oil seal. Make sure the lip of the oil seal is toward th bearing. Correct assembly of bearing, seal, inner race and spacer is shown in Figure 12.




4. Assemble the alternator and install the through bolts. Spin the rotor to make sure there is no mechanical interference. Torque the through bolts to 30 to 35 in. lbs. Safety wire should be installed after the unit has been bench tested for output. Install spacer, woodruff key, fan, pulley, lockwasher and nut. Torque the nut to 35 Ft. Lbs. using a strap wrench to hold the pulley. Do not install the blast tube assembly until after the unit has been bench tested.

5. Install the brush and holder assembly and retaining screws. Spin the rotor and check for interference between the brush holder and rotor. Check across the field terminals with an ohmmeter. The ohmmeter must indicate the amount of rotor resistance listed on the individual specification page.

Wiring connections for bench testing the alternator are shown in Figure 13. Refer to the individual specification pages for output test figures. Adjust the carbon pile, if necessary, to obtain the specified voltage.


After bench testing the alternator, install the safety wire and blast tube and install the alternator on the engine.



Note: Always refer to the airframe manufacturers wiring diagram when installing the alternator or testing the alternator on the aircraft.

PRECAUTIONS TO BE OBSERVED WHEN TESTING OR SERVICING THE ELECTRICAL SYSTEM

- 1. DISCONNECT THE BATTERY, before connecting or disconnecting test instruments (except voltmeter) or before removing or replacing any unit or wiring. Accidental grounding or shorting at the regulator, alternator, ammeter or accessories, will cause severe damage to the units and/or wiring.
- 2. THE OUTPUT LEAD MUST NOT BE REMOVED FROM THE ALTERNATOR WHILE THE ROTOR WINDING IS ENERGIZED AND THE ALTERNATOR IS OPERATING
- 3. DO NOT ATTEMPT TO POLARIZE THE ALTERNATOR. No polarization is required. Any attempt to do so may result in damage to the alternator, regulator or circuits.
- 4. GROUNDING OF THE ALTERNATOR OUTPUT TERMINAL MAY DAMAGE THE ALTERNATOR AND/OR CIRCUIT AND COMPONENTS.
- 5. REVERSED BATTERY CONNECTIONS MAY DAMAGE THE RECTIFIERS, VEHICLE WIRING OR OTHER COMPONENTS OF THE CHARGING SYSTEM. Battery polarity should be checked with a voltmeter before connecting the battery. MOST VEHICLES ARE NEGATIVE GROUND.
- 6. IF A BOOSTER BATTERY OR FAST CHARGER IS USED, ITS POLARITY MUST BE CONNECTED CORRECTLY TO PREVENT DAMAGE TO THE ELECTRICAL SYSTEM COMPONENTS.





FLANGE MOUNTED AIRCRAFT ALTERNATOR

Prestolite Flange Mounted Aircraft Alternators (Figure 1) have been designed and constructed to provide extended periods of trouble-free operation with a minimum amount of maintenance. They have also been designed and constructed to withstand the vibration and extreme temperature changes encountered in aircraft applications.

DESCRIPTION

The principle components (Figure 2) of the Aircraft Alternator are (1) The drive end head, (2) The rotor, (3) The stator, (4) The rectifiers, (5) The slip ring end head and (6) The brush and holder assembly.








Figure 2

1) The drive end head contains a prelubricated bearing, an oil seal, collar and shaft seal and a blast tube connection for ventilation.

2) The rotor contains a ventilating fan on the drive end of the shaft (ALX series only) and the slip ring end bearing inner race and spacer on the other end of the shaft. The rotor winding and winding leads have been specially treated with a high temperature epoxy cement to provide vibration and temperature resistance characteristics. High temperature solder is used to secure the winding leads to the slip rings.

3) The stator contains a special lead which is connected to the center of the three phase windings and is used to activate low voltage warning systems or relays. The stator has been treated with a special epoxy varnish for high temperature resistance.

4) The rectifiers used in these units are rated at 150 P.I.V. minimum for transient voltage protection. Three positive rectifiers are mounted in the rectifier mounting plate while the three negative rectifiers are mounted in the slip ring end head. Each pair of rectifiers is connected to a stator lead with high temperature solder. The stator leads are anchored to the rectifier mounting plate with epoxy cement for vibration protection.

5) The slip ring end head provides the mounting for the rectifiers and rectifier mounting plate, output and auxiliary terminal studs, and the brush and holder assembly. The slip ring end head contains a roller bearing and outer race assembly and a grease seal.

6) The brush and holder assembly contains two brushes, two brush springs, a brush holder and insulators. Each brush is connected to a separate terminal stud and is insulated from ground. The brush and holder assembly can easily be removed for inspection or brush replacement purposes.

OVERHAUL

When repairing the alternator, complete disassembly may not be required. In some cases it will only be necessary to perform those operations which are required to effect the repair.

However, in this section, the complete overhaul is covered step by step to provide detailed information on each operation. In actual service practice, these operations may be used as required.

DISASSEMBLY

1. Remove the two #10-24 screws holding the brush holder assembly in the slip ring end head. Remove the brush and holder assembly from the end head.

2. Remove the safety wire from the thru bolts and remove the thru bolts.

3. Tap the drive end head lightly and separate the drive end head and rotor, as a unit, from the stator and slip ring end head.

4. Remove the nuts, lock washers, flatwasher and insulators from the output and auxiliary terminal studs. Note carefully the correct assembly of the insulator washers and bushings. Using the special tools shown in Figure 3, support the end head and press out the three negative rectifiers. The end head can now be separated from the stator assembly.

K



Figure 3

5. To remove the slip ring end bearing and grease seal, it will be necessary to have a hook type or impact type bearing puller as shown in Figure 4. Do not remove the bearing unless replacement is necessary.

The inner race of the slip ring end bearing is pressed onto the rotor shaft. When bearing replacement is necessary, always replace the complete bearing assembly, including the inner race.



Figure 4


6. Clamp the rotor in a vise and remove the cotter pin, nut, drive gear assembly and woodruff key. Note: The drive gear assembly is not a Prestolite part and is serviced by the engine manufacturer. Support the drive end head and carefully press out the rotor assembly. Remove the retainer plate screws and retainer plate. Support the drive end head and press out the bearing. Once the bearing is removed, the oil seal can be knocked or pressed out from the inside of the housing.

INSPECTION AND TESTING OF COMPONENTS

Upon completion of the disassembly, all parts should be cleaned and visually inspected for cracks, wear or distortion and any signs of overheating or mechanical interference.

1. Rotor - The rotor should be tested for grounded or shorted winding. The ground test can be made with test probes, connected in series with a 110 volt test lamp, an ohmmeter or any type of continuity tester. Figure 5. There must not be any continuity between the slip rings and the rotor shaft or poles.

To test for shorted turns in the rotor winding, connect a voltmeter, ammeter and rheostat as shown in Figure 6, or use an ohmmeter. Rotor current draw and resistance are listed on



individual specification pages. Excessive current draw or a low ohmmeter reading indicates shorted windings. No current draw or an infinite ohmmeter reading would indicate an open winding.

2. Rectifiers – A diode rectifier tester will detect and pinpoint open or shorted rectifiers without going through the operation of disconnecting the stator leads. However, if a tester is not available, test probes and a #57 bulb, connected in series with a 12 volt battery, can be used in the following manner. Touch one test probe to a rectifier heat sink and the other test probe to a lead from one of the rectifiers in that heat sink. Then reverse the position of the leads. The test bulb should light in one direction and not light in the other direction. If the test bulb lights in both directions, one or more of the rectifiers in that heat sink is shorted. To pinpoint the defective rectifier, the stator leads must be disconnected and the above test repeated on each rectifier. Open rectifiers can only be detected, when using the test bulb, by disconnecting the stator leads. The test bulb will fail to light in either direction if the rectifier is open.

3. Stator - The stator can be tested for open or grounded windings with a 12 volt test bulb, described in the rectifier section, or an ohmmeter, in the following manner. Separate the stator from the slip ring end head just far enough to insert a couple of rags or blocks of wood. In other words, insulate the stator from the end head. To test for grounded windings, touch one test bulb or ohmmeter probe to the auxiliary terminal or any stator lead, and the other test bulb or ohmmeter probe to the stator frame. If the test bulb lights, or the ohmmeter indicates continuity, the stator is grounded. To test for open windings, connect one test probe to the auxiliary terminal or the stator winding center connection and touch each of the three stator leads. The test bulb must light, or the ohmmeter must show continuity.

1

Due to the low resistance in the stator windings, shorted windings are almost impossible to locate. However, shorted stator windings will usually cause the alternator to "growl" or be noisy during operation and will usually show some signs of overheating.


If all other electrical checks are normal and the alternator fails to supply its' rated output, the stator should be replaced to determine whether or not it is the faulty component.

4. Bearings and Seals - Whenever the alternator is overhauled, new bearings and oil or grease seals are recommended, even though the bearings and seals appear to be in good condition. A faulty seal can cause an alternator to fail within a very short period of time.

ASSEMBLY

1. Drive End Head – Install the oil seal with the lip toward the outside of the end head. Press the oil seal in approximately 1/16" below the edge of the casting. Install the ball bearing with the seal toward the inside of the end head. Press only on the outer race of the bearing when installing. Install bearing retainer and screws. Support the bearing inner race and press in rotor. Reassemble oil seal collar, "O" ring seal, woodruff key, drive gear assembly, nut and cotter pin. Torque rotor shaft nut to 37 to 41 Ft. Lbs. Correct assembly of drive end oil seals is shown in Figure 7.

2. Carefully install the rectifiers in the slip ring end head or rectifier mounting plate by supporting the unit and using the special tools illustrated in Figure 8.






Figure 7

15%


Figure 8

9

(Use arbor press -- do not hammer.) Reconnect the stator leads to the rectifiers. WHEN SOLDERING THESE CONNECTIONS, USE PLIERS AS A HEAT DAM ON THE LEAD BETWEEN THE SOLDER JOINT AND THE RECTIFIER. TOO MUCH HEAT WILL DAMAGE THE RECTIFIERS. Reassemble the rectifier mounting plate studs and insulators, making sure they are in the correct order. See Figure 9.

After the slip ring end head is completely assembled, the stator and rectifier leads must be secured to the rectifier mounting plate with epoxy. Make sure the stator leads are positioned so that they do not interfere with the rotor.

Install the slip ring end bearing and oil seal. Make sure the lip of the oil seal is toward the bearing. Correct assembly of bearing, seal, inner race and spacer is shown in Figure 10.



Assemble the alternator and install the through bolts. Spin the rotor to make sure there is no mechanical interference. Torque the through bolts to 30 to 35 in. lbs. Safety wire should be installed after the unit has been bench tested for output.

Install the brush and holder assembly and retaining screws. Spin the rotor and check for interference between the brush holder and rotor.

Check across the field terminals with an ohmmeter. The ohmmeter must indicate the amount of rotor resistance listed on the individual specification page.

TESTING

Upon completion of assembly, the alternator should be tested to determine if it is capable of delivering its full rated output. Caution: All flange mounted alternators require a source of ventilation. Do not test these alternators at full rated output for more than 30 seconds unless adequate air pressure for cooling is supplied.

The internal fan used on the ALX series provides some ventilation; however, the same rule applies to these units.

Wiring connections for bench testing the alternator are shown in Figure 11. Refer to the individual specification pages for output test figures. Adjust the carbon pile, if necessary, to obtain the specified voltage.

After bench testing the alternator, install the safety wire in the through bolts and install the alternator on the engine.

Note: Always refer to the airframe manufacturers wiring diagram when installing the alternator or testing the alternator on the aircraft.




Figure 11

PRECAUTIONS TO BE OBSERVICED WHEN TESTING OR SERVICING THE ELECTRICAL SYSTEM

- 1. DISCONNECT THE BATTERY, before connecting or disconnecting test instruments (except voltmeter) or before removing or replacing any unit or wiring. Accidental grounding or shorting at the regulator, alternator, ammeter or accessories, will cause severe damage to the units and/or wiring.
- 2. THE ALTERNATOR MUST NOT BE OPERATED ON OPEN CIRCUIT WITH THE ROTOR WINDING ENERTIZED.
- 3. DO NOT ATTEMPT TO POLARIZE THE ALTERNATOR. No polarization is required. Any attempt to do so may result in damage to the alternator, regulator or circuits.
- 4. GROUNDING OF THE ALTERNATOR OUTPUT TERMINAL MAY DAMAGE THE ALTERNATOR AND/OR CIRCUIT AND COMPONENTS.
- 5. REVERSED BATTERY CONNECTIONS MAY DAMAGE THE RECTIFIERS, VEHICLE WIRING OR OTHER COMPONENTS OF THE CHARGING SYSTEM. Battery polarity should be checked with a voltmeter before connecting the battery. MOST VEHICLES ARE NEGATIVE GROUND.
- 6. IF A BOOSTER BATTERY OR FAST CHARGER IS USED, ITS POLARITY MUST BE CONNECTED CORRECTLY TO PREVENT DAMAGE TO THE ELECTRICAL SYSTEM COMPONENTS.

 \checkmark

Form L-664



AIRCRAFT ALTERNATOR

THE PRESTOLITE 24 VOLT 100 AMPERE AIRCRAFT ALTERNATOR


The Prestolite 24 volt, 100 ampere aircraft alternators (Figure 1) are manufactured for both flange mounting and double foot, hinge mounting, belt-driven applications. Both types are designed and constructed to provide heavy duty service for extended periods of trouble-free operation with a minimum amount of maintenance. They are constructed to withstand the vibration and extreme temperature changes encountered in aircraft applications.

DESCRIPTION

All 100 amp, 24 volt aircraft alternators are identified by the prefix ALV in the part number. The 8000 series identifies the double



Figure 1



riguro a

foot, hinge mounted, belt-driven units, while the 9000 series identifies the flange mounted, gear-driven units.

The principle components (Figure 2) of these alternators are (1) the slip ring head, (2) the heat sink and rectifier assemblies, (3) the stator, (4) the rotor and (5) the drive end head assembly.

(1) The slip ring end head provides the mounting for the rectifier-heat sink assemblies, the output, auxiliary and ground terminal studs, brush holder and brush assemblies and the slip ring end bearing. The 8000 series units attach the blast tube assembly to the slip ring end head.

(2) The rectifier and heat sink assemblies (Figure 3), used in these units, are different in construction from those used in any other Prestolite aircraft alternator. Each heat sink has six (6) rectifiers of one polarity attached to it. Each stator lead connects to four




Figure 3

Figure 4

rectifiers (two positive and two negative). This can best be illustrated with an internal wiring diagram. (Figure 4). Each rectifier is rated at 150 P.I.V. minimum for transient voltage protection. All soldered connections are made with high temperature solder. The stator and rectifier leads are anchored to the heat sink with epoxy cement to provide vibration protection. Because of this construction, special service procedures must be followed. Refer to the rectifier section of Inspection and Testing of Components.

(3) The stator contains a center tap lead which is connected to the center of the three phase windings and is used to activate low voltage warning systems or relays. The stator has been treated with a special epoxy varnish for high temperature resistance and vibration protection.

(4) The rotor winding and winding leads have been specially treated with a high temperature varnish and epoxy cement to provide vibration and temperature resistant characteristics. High temperature solder is used to secure the winding leads to the slip rings.

(5) The drive end head, on both series, contains a prelubricated bearing. The 9000 series end head also contains an oil seal, collar and shaft seal, and a blast tube connection for ventilation.

OVERHAUL

When repairing the alternator, complete disassembly may not be required. In some cases, it will be necessary to perform only those operations which are required to effect the repair. However, in this section, the complete overhaul is covered step by step to provide detailed information on each operation. In actual service practice, these operations may be used as required.

OVERHAUL NOTE

When overhauling the alternator, we recommend the following components be replaced:

- 1. Brushes.
- 2. Drive end bearing.
- 3. Slip ring end bearing.
- 4. Oil seal (9000 Series).
- 5. Shaft seal "O" ring (9000 Series).
- 6. Lock tab washers.

DISASSEMBLY

(1) (8000 Series) Straighten the ears on the lock tab washers and remove the three through bolts and blast tube assembly.

(2) (9000 Series) Straighten the ears on the lock tab washers and remove the six through bolts.

(3) Remove the slip ring end bearing cover. This can be accomplished by wedging a small, sharp object, such as a small, sharp chisel or knife blade, between the cover and the slip ring end head.

(4) Use a puller, as shown in Figure 5, to press the rotor shaft out of the slip ring end bearing. Separate the drive end head and rotor, as a unit, from the stator and slip ring end head, being careful not to lose the brush springs while separating the units.

(5) Remove the nuts, lockwashers, flat washers and insulators from the output, ground, and auxiliary terminal studs. The end head can now be separated from the stator and heat sink assemblies. The slip ring end bearing can be pushed out from the inside of the end



Figure 5


head.

(6) Each brush is connected to a terminal stud that is insulated and mounted through the slip ring end head. Service brushes come attached to terminal studs. The brush holder is attached to the slip ring end head with two screws and can be easily serviced once the alternator is disassembled.

(7) Clamp the rotor in a vise, being careful not to distort the rotor poles, and remove the drive components from the rotor shaft.

<u>NOTE:</u> The pulley, used on the 8000 series units, and the drive assembly, used on the 9000 series units, are not manufactured or serviced by Prestolite but are available from the engine manufacturer.

The drive end head and rotor on the 8000 series units must be separated with a puller as shown in Figure 6. Do not attempt to press the rotor out of the end head or the end head may be damaged. The drive end head and rotor on the 9000 series units can be separated by supporting the end head and pressing out the rotor.



Remove the bearing retainer plate screws and retainer. Support the end head and carefully press out the bearing. The oil seal, on the 9000 series units, can then be knocked or pressed out from the inside of the end head.

INSPECTING AND TESTING COMPONENTS

Upon completion of disassembly, all parts should be thoroughly cleaned and visually inspected for cracks, wear or distortion, and any signs of overheating or mechanical interference.

(1) Rotor - The rotor should be tested for a grounded, shorted, or open winding. The ground test can be made with a 110 volt test lamp, an ohmmeter, or any type of continuity tester. (Figure 7). There must not be any continuity from the slip rings to the rotor shaft or poles.

To test for shorted turns in the rotor winding, connect an accurate voltmeter, ammeter and rheostat as shown in Figure 8, or use an accurate ohmmeter. Rotor current draw and resistance are listed on the individual specification page. Excessive current draw or a low ohmmeter reading would indicate shorted windings. No current draw or an infinite ohmmeter reading would indicate an open winding.

(2) Rectifiers – A rectifier tester can be used to detect shorted rectifiers and open pairs of rectifiers. The construction of the alternator (two rectifiers connected to one stator lead) makes it impossible to check for a single open rectifier without going through the operation of unsoldering and separating the rectifier leads.

When soldering and unsoldering the rectifier connections, use pliers as a heat dam on the rectifier leads, between the solder joint and rectifier. Too much heat will damage rectifiers.






Figure 8

(4)

If a shorted or open rectifier is located, the heat sink assembly containing that rectifier must be replaced. The individual rectifiers are not replaceable and no attempt should be made to unsolder them from the heat sink.

(3) Stator - The stator can be tested for open or grounded windings with test probes and a #57 bulb connected in series with a 12 volt battery, an ohmmeter, or any type continuity tester except 110 volt test bulb.

To test for grounded windings, connect one test probe to the auxiliary terminal stud or any stator lead. Connect the other test probe to the stator frame. If the test bulb lights or any continuity is indicated, the stator is grounded and must be replaced.

To test for open windings, connect one test probe to the auxiliary terminal stud and touch each stator connection with the other test probe. The test bulb must light or continuity must be indicated between all connections. If the stator is open, it must be replaced. Check flexible leads for possible opens before replacing the stator.

Due to the low resistance of the stator windings, shorted windings are almost impossible to locate. However, shorted stator windings will usually cause the alternator to be noisy or "growl" during operation and will usually show signs of overheating.

If all other electrical checks are normal and the alternator fails to supply its rated output, the stator should be replaced to determine whether or not it is the faulty component.

(4) Stator And/Or Rectifier Heat Sink Replacement – When soldering or unsoldering the rectifier connections, pliers should be used as a heat dam between the solder joint and the rectifiers. Too much heat will damage rectifiers.

ASSEMBLY

After thoroughly cleaning, inspecting, testing, and replacing any faulty components, reassemble and test the unit. Reassembly is, basically, the reverse of disassembly.

However, the following assembly procedures must be observed to obtain a properly assembled unit.


Drive End Head-8000 Series Units - Install the bearing with the sealed side toward the rotor by pressing on the outer race only.

Install the bearing retainer and screws. Support the rotor shaft and press the end head onto the shaft using the tool shown in Figure 9. Do not attempt to press the rotor into the end head without supporting the bearing inner race or the end head and bearing may be damaged. Install the spacer, fan, woodruff key, pulley, lockwasher, and nut. Torque the pulley retaining nut to 35 to 45 Ft. Lbs.



Figure 9

Drive End Head-9000 Series Units - Install the oil seal with the lip toward the outside of the end head. Press the oil seal in approximately 1/16" below the outside edge of the casting. Install the bearing with the sealed side toward the rotor. When installing the bearing, press only on the outer race. Install the bearing retainer and screws. Support the rotor shaft and press the end head assembly onto the shaft, using the same tool shown in Figure 9 and being careful not to damage the oil seal.



CORRECT ASSEMBLY OF OIL SEALS

Reassemble the oil seal collar, being careful not to fold the oil seal lip under. A small amount of oil on the collar will make installation easier. Install the "O" ring seal, being careful not to cut the "O" ring on the shaft keyway. Use a small, blunt instrument to push the "O" ring seal into the shaft collar. A small amount of oil on the "O" ring seal will make installation easier. Make certain the "O" ring seal is fully installed before assembling the remainder of the drive assembly. Figure 10 shows the correct assembly of the drive end head components. Torque the drive retaining nut to 37 to 42 Ft. Lbs.

Slip Ring End Assembly - Assemble the brush and terminal stud assemblies in the end head prior to assembling the heat sinks and stator. Make sure brush holder retaining screws are tight.


A small amount of Lock-Tite on the retaining screw threads, prior to assembly, will provide additional vibration protection.

Assemble the stator and rectifier heat sink assemblies in the end head, making certain the insulators are correctly assembled as shown in Figures 11 and 12.

Position the stator leads so they will not interfere with the rotor.

<u>NOTE</u>: If it was necessary to replace the stator or either rectifier heat sink, position the stator leads so they will not interfere with the rotor and secure the leads to the heat sinks with epoxy cement.

Position the snap ring, in the end head, so that one of the holes is directly in line with the brushes. Install the brush springs and brushes in the brush holder. Insert a small drill






Figure 12 (9000 Series)

(6)

Figure 10

or metal rod through the snap ring hole to hold the brushes in place.

Assemble the alternator and install a couple of through bolts to hold the unit together. Remove the brush holding tool and make sure the brushes are contacting the slip rings. Visually check to make sure the brush leads are free and cannot bind against anything. Make sure the shaft snap ring retainer is in place and install the slip ring end bearing. The bearing must be installed with the sealed side toward the rotor. Use a tool that fits against the bearing inner race and press the bearing onto the rotor shaft while supporting the drive end of the shaft.

Install the remaining through bolts. Do not install the blast tube assembly on the 8000 Series Units, or secure the lock tab washers until the unit has been tested.

Torquing Specifications – After the alternator is fully assembled, the components should be torqued to the listed specifications:

Through Bolts	30-35 In. Lbs.
1/4 Inch Term. Stud Nuts	70-85 In. Lbs.
#10-32 Term. Stud Nuts	30-35 In. Lbs.
9000 Series Coupling Retaining Nut	37-42 Ft. Lbs.
8000 Series Pulley Retaining Nut	35-45 Ft. Lbs.

TESTING

Upon completion of assembly, the alternator should be tested to determine if the unit is capable of delivering its full rated output.


<u>CAUTION</u>: The 9000 Series, flange mounted units, require a source of ventilation. <u>Do Not</u> test these units at full rated output for more than 20 seconds unless adequate air pressure for cooling is supplied.

Wiring connections for bench testing the alternator are shown in Figure 13. The alternator must meet or exceed the specifications listed below. Adjust carbon pile, if necessary, to obtain the specified voltage.

Volts	Output	<u>RPM</u>	
25.8	10.0 Amps.	Min.	2000
28.4	100.0 Amps.	Min.	5000

After bench testing the alternator, install the blast tube on the 8000 Series Units and secure the lock tab washers.

Install the alternator on the engine, making sure all mounting surfaces, especially on the 9000 Series, are free of corrosion or foreign materials. Torque the alternator retaining bolts to the specifications listed in the engine manufacturer's manual.



NOTE: Always refer to the airframe manufacturer's wiring diagram when installing or testing the alternator on the aircraft.

PRECAUTIONS TO BE OBSERVED WHEN TESTING OR SERVICING THE ELECTRICAL SYSTEM

- 1. DISCONNECT THE BATTERY, before connecting or disconnecting test instruments (except voltmeter) or before removing or replacing any unit or wiring. Accidental grounding or shorting at the regulator, alternator, ammeter, or accessories, will cause severe damage to the units and/or wiring.
- 2. THE ALTERNATOR OUTPUT LEAD MUST NOT BE REMOVED FROM THE ALTER-NATOR WITH THE FIELD CIRCUIT ENERGIZED AND THE ALTERNATOR OPERATING.
- 3. DO NOT ATTEMPT TO POLARIZE THE ALTERNATOR. No polarization is required. Any attempt to do so may result in damage to the alternator, regulator or circuits.
- 4. GROUNDING OF THE ALTERNATOR OUTPUT TERMINAL MAY DAMAGE THE ALTERNATOR AND/OR CIRCUIT AND COMPONENTS.
- 5. REVERSED BATTERY CONNECTIONS MAY DAMAGE THE RECTIFIERS, VEHICLE WIRING OR OTHER COMPONENTS OF THE CHARGING SYSTEM. Battery polarity should be checked with a voltmeter before connecting the battery. MOST VEHICLES ARE NEGATIVE GROUND.
- 6. IF A BOOSTER BATTERY OR FAST CHARGER IS USED, ITS POLARITY MUST BE CONNECTED CORRECTLY TO PREVENT DAMAGE TO THE ELECTRICAL SYSTEM COMPONENTS.
- 7. WHEN USING AN AUXILIARY POWER UNIT, MAKE SURE THE VOLTAGE AND POLAR-ITY ARE SET TO CORRESPOND WITH THE VEHICLE SYSTEM VOLTAGE AND POLAR-ITY.



FORM L-670



ALV-9400 SERIES 24 VOLT, 100 AMPERE — OVERHAUL PROCEDURES —

Section 1 INSPECTION AND ELECTRICAL CHECKS

1.1 Visual and Mechanical Inspection

- 1.1.1 Housings and Shaft Verify no damage. Replace any damaged housings and rotor (if shaft damaged).
- 1.1.2 **Thru-Bolts and Lock Tabs** Verify installation of six thru-bolts and lock tabs. See Figure 2-12 for installation at one place and Figure 2-13 for the other five places. Bolt torque value is 30-35 inch-pounds. Bolts are high strength type (120,000 psi) which can be identified by a raised "Y" mark on heads as shown in Figure 2-13.
- 1.1.3 **Terminals and insulators** Verify no damage and installation as per Figures 2-10 and 2-11. Refer to paragraph 2.5.10 for terminal mounting nut torque values. Replace damaged parts.
- 1.1.4 **Shaft Spacer and O-Ring Seal** Verify no damage/wear to shaft spacer surface finish (20 microinch maximum) and O-ring seal. Replace damaged or worn parts.
- 1.1.5 **Oil Seal** Verify no damage or wear to oil seal. See Figure 1-1 for typical installation. Replace damaged or worn parts.



Figure 1-1

1.1.6 Slip Ring End Bearing, Housing and Shaft End Condition —

- 1. Remove bearing cover from end head as shown in Figure 1-2. CARE MUST BE TAKEN NOT TO DAMAGE END HEAD. IF COVER IS DAM-AGED A NEW COVER MUST BE INSTALLED.
- Inspect cover for rust accumulation on inside surface and if so, replace with new cover, bearing and housing.
- 3. Inspect end housing bearing bushing for signs of corrosion, gouges, scratches and burrs and if so, replace housing and bearing. (New bushing has 30 micro-inch surface finish).

- 4. Inspect bearing and shaft end for discoloration indicating overheating or wear (See Figure 1-3) and if so, replace bearing and rotor.
- 5. Inspect bearing inner race for evidence of turning on shaft (See Figure 1-3) and if so, replace bearing and rotor.




Figure 1-2



Figure 1-3

- 6. Inspect bearing outer race for evidence of turning in housing bushing (See Figure 1-3) and if so, replace bearing and housing.
- Inspect bearing for wear and grease contamination as indicated by darkening or change in original grease color and presence of dirt or metal particles. The original Chevron SRI #2 grease has a dark green color. Replace bearing and housing if bearing grease is so contaminated.

1.1.7 **Bearing Check** — Hand spin the rotor shaft. A defective bearing may be heard or felt. To determine which bearing is defective will require disassembly of alternator to separate the drive end head and rotor assembly from the slip ring end head and stator assembly. The check can then be repeated with the drive end head and rotor assembly to determine which bearing is defective and should be replaced.

1.2 Electrical Checks

1.2.1 **Positive Rectifier Heat Sink Assembly:**

- 1. Using a VOM on the RX1 range, make forward and reverse rectifier resistance measurements between the (+) terminal and the AUX terminal.
- 2. One reading should be low and the other very high (no meter movement).
- 3. Abnormal readings indicate one or more rectifiers are defective and the assembly must be replaced. Individual rectifiers are not replaceable.
- 1.2.2 Negative Rectifier Heat Sink Assembly:
 - 1. Repeat test as in 1.2.1 with VOM connections to the (-) terminal and the AUX terminal.

1.2.3 Field Circuit:

- 1. Using VOM, measure resistance between F1 and F2 terminals.
- 2. Resistance should be 9.9 to approximately 15 ohms at 20-27°C (70°-80°F). This resistance is measured through the brushes and some variation is expected for the specified maximum value. An open circuit will be much higher than this value. If measured resistance is less, this indicates possible shorted rotor, slip rings or RFI capacitor (ALV-9407 only, disconnect one lead for check). If measured resistance is greater this indicates possible dirty slip rings, bad brushes or open rotor. Replace defective parts or clean slip rings as indicated.

1.2.4 Ground Checks:

- 1. Using VOM on RX100 range, make resistance measurements between the slip ring end housing and the AUX, (+), (-), F1, and F2 terminals. Meter should indicate infinite resistance (no meter movement).
- 2. Abnormal readings indicate a fault condition at the housing terminal mounting interface or internal to the alternator.

1.2.5 **Performance Test;**

Using a test stand, verify alternator output performance of 28.0 volts at 6000 r/min for minimum output

current of 83.0 amperes. Alternator must be connected as shown in Figure 1-4 for full field operation, i.e. - field terminals F1 and F2 jumpered to the (+) and (-) output terminals (use #16 or #18 AWG wire for the 2-3 ampere field current and a field control switch). Approximately 6 hp will be required to drive the alternator at the specified load condition. Prepare test setup so that operation time at the loaded condition does not exceed 20 seconds. This is required for two reasons. The stated performance is based on room temperature and extended test time will increase winding resistance, due to temperature increase, and prevent proper check to the stated limits. Also, the alternator must not be operated without required air cooling for more than 20 seconds at the loaded condition or damage will result. Therefore, to minimize operation time required at the loaded condition, the following test sequence is suggested -

- 1. With field control switch open, adjust speed to specified value.
- 2. Close field switch, adjust load to give specified output voltage at specified speed, record load current, open field switch and decrease load and speed to zero.
- 3. Refer to Page 9, Table 1-1 as required for trouble analysis.




Figure 1-4

Section 2 OVERHAUL PROCEDURE

2.1 General

This section contains information required to completely disassemble and reassemble the alternator. In addition, this section includes inspection and test procedures for the individual components and subassemblies.

When repairing the alternator, complete disassembly may not be required. In some cases, it will be necessary to perform only those operations which are required to effect the repair.

$\mathbf{2.2}$

Recommended Replacement Parts

It is recommended that original equipment service parts be used for parts replacement. Refer to the Prestolite OE-A1 Aircraft Manual Alternator Section for available service parts.

2.3 Disassembly

- 2.3.1 Remove Rear Housing Stator and Rectifier Heat Sinks Assembly from Rotor Drive End Housing Assembly.
 - 1. Place the alternator on a wood "V" block stand.

- 2. Straighten the lock tabs on each of the six (6) thru bolts. (Use new lock tabs when reassembling.)
- Using a socket wrench, remove the six (6) thru bolts and lock tabs. Inspect bolts for any damage. Replace if required at reassembly.

NOTE

Verify removed thru-bolts are high strength bolts as identified by the raised "Y" mark on the heads. (See Figure 2-13.) If not, the bolts must be replaced at reassembly with the required bolts.

- 4. Remove the slip ring end head bearing cover (see paragraph 1.1.6).
- 5. Place alternator on wood holding block having a clearance hole for the shaft diameter (including shaft spacer) and shaft length so that it rests on the front surface of the machined circular part of drive end housing. Scribe mark across housings and stator to indicate alignment for ease of reassembly.
- 6. Using a puller (Proto Co. #4029 recommended, other may cause spine damage) installed on the slip ring end head housing as shown in Figure 2-1 to prevent damage to housing, separate the slip ring end housing and stator-rectifier assembly. Retrieve brush springs if they fall out during this operation. Place the removed slip ring end head and stator assembly on a pad to protect exposed stator winding pending further disassembly.




Figure 2-1

2.3.2 Remove Stator and Rectifier — Heat Sinks Assembly From Slip RingEnd Head.

- 1. Position the assembly on holding block.
- 2. Using socket wrench, remove nuts, washers and insulators from the (+) output terminal, (-)

ground terminal, AUX terminal and the other auxiliary terminal. Note location to facilitate reassembly.

- 3. Separate rectifier-stator assembly from the slip ring end housing, pushing terminals (step 2) through the housing and remove housing.
- Remove remaining insulators and washers from terminals and housing. Note location to facilitate reassembly.

2.3.3 Remove Brush Holder, Brushes and Capacitor (ALV-9407 only) from Slip Ring End Housing.

- Using socket wrench, remove nuts, washers and insulators from field terminals. Note location to facilitate reassembly.
- 2. Remove terminals with integral brushes.
- 3. Remove internal insulators from brush terminals. Note location for reassembly.
- On ALV-9407, remove capacitor clamp screw, clamp and capacitor.
- Remove brush holder fastening hardware, including brush springs if not removed.

2.3.4 Remove Slip Ring End Head Bearing

- Remove bearing snap ring retainer using required removal pliers.
- 2. Position end housing in a press with rear of housing towards press table. Using a 1½ inch diameter × 8 inch long bar on inner race of bearing and with the end housing bearing boss area supported by a tube 2% inch O.D. × 1% inch I.D. × 2 inch long, press bearing from housing (DO NOT HAM-MER). Discard bearing.
- Remove bearing O-ring seal from housing and discard seal.

2.3.5 Separate Rotor and Drive End Housing

- 1. Remove shaft cotter key and nut.
 - 2. Remove shaft shipping sleeve and shipping washer or drive gear assembly if installed.
 - 3. Remove woodruff key.
 - 4. Remove rotor shaft spacer and O-ring seal. Discard seal.
 - Position assembly vertically in a press with slip ring end towards press table and housing supported above press table by two/three vertical support plates between housing and press table.
 - 6. Apply press ram to shaft end and press rotor out of housing (DO NOT HAMMER), being careful not to allow housing or rotor to drop and be damaged.

2.3.6 Remove Drive End Bearing

- 1. Remove three screws that secure bearing retainer and remove retainer.
- 2. Place housing in press as shown in Figure 2-2 and using the bearing removal tools shown, **press** bearing from housing (DO NOT HAMMER). **Discard bearing.**

2.3.7 Remove Oil Seal from Drive End Housing

- Position housing in press with front of housing towards press table and supported on a 2½ inch I.D. pipe at housing oil seal pocket.
- 2. Using a 1% inch diameter bar between press ram and rear of oil seal, **press** oil seal from housing (DO NOT HAMMER). **Discard oil seal**.

2.3.8 Remove Rectifier — Heat Sinks from Stator Assembly

This procedure applies to removal of either heat sink assembly from the stator assembly as required for replacement or testing of individual assemblies. Figure 2-3 shows one of the rectifier heat sinks as wired to the stator leads. The other heat sink has similar type connections.




Figure 2-2



Figure 2-3

NOTE

Too much heat can damage rectifiers or shorten their service life. Use long nose pliers between rectifiers and solder joint as a heat sink during soldering or unsoldering operations. Complete operation as quickly as possible. A 100 watt soldering iron with clean tip is adequate.

- 1. Unsolder all stator leads from both rectifier-heat sink assemblies. Tag stator leads and rectifier connection point to facilitate reassembly.
- 2. Remove and discard metal tubing used over each rectifier pair leads and stator lead.

- 3. Remove epoxy cement holding each stator lead to heat sink.
- 4. Remove the AUX output terminal and spacer from the negative heat sink assembly.
- 2.4 Inspection and Testing of Removed Components Refer to paragraph 2.6 for alternator servicing and testing precautions.

2.4.1 Front and Rear Housing

- 1. Clean both housings using Dow Chemical-Chlorothene VG solvent to remove grease and dirt.
- 2. Air dry with filtered low pressure compressed dry air or wipe dry with clean cloth.
- 3. Inspect both housings for stripped threads, cracks on exterior and interior surfaces, and wear and corrosion in the bearing mounting area.
- 4. Replace housing at reassembly if any of the above faults are noted.

2.4.2 Mounting Hardware

- 1. Inspect any removed metallic hardware, i.e., screws, lockwashers, flatwashers, nuts, bearing retainer plate, bearing snap ring retainer, shaft spacer, bearing cover, shaft key, etc., for any damage, wear, corrosion or distortion. Replace any faulty parts at reassembly.
- 2. Hardware that will be reused shall be cleaned as required, using Dow Chemical-Chlorothene VG. Air dry parts using filtered low pressure compressed dry air or wipe dry with clean, lint free, cloth.

2.4.3 Insulators — (Washers and Spacers)

- 1. Inspect parts for cracks, deformation and burn marks.
- 2. Parts that are suitable for reuse, shall be cleaned as required using isopropyl alcohol. (CAUTION: ANY OTHER CLEANER MAY DAMAGE IN-SULATORS). Air dry parts with filtered low pressure compressed dry air or wipe dry with clean lint free cloth.

2.4.4 RFI Capacitor (ALV-9407 only)

- Inspect capacitor for cracks in insulation and broken/damaged leads. Replace capacitor at reassembly if any faults are noted.
- 2. Test capacitor for a short or leakage condition using an ohmmeter. Use meter RX100 scale and check from lead to lead. Replace capacitor if it is shorted/leaky.

2.4.5 Brushholder, Brushes and Springs

- 1. Inspect brushholder for cracks and breaks in plastic and bent metal bracket. Replace if damaged, at reassembly.
- 2. Inspect the two brush and terminal assemblies for damaged terminals, insulation damage, broken/cracked or oil soaked brush material and minimum brush length of 0.45 inch. Replace brushes at reassembly if any of the above faults are noted.

NOTE

It is advisable to change brushes if length is 0.5 inch or less to eliminate later disassembly for brush wear replacement.

3. Inspect two stainless steel brush springs for any deformation, change in length or spring force. Service springs have a free length of about 1.2 inches, 0.29 inch maximum diameter and a spring force of 0.54 pounds at compressed length of 0.87 inches. Replace springs if they are damaged.

2.4.6 Rotor Assembly

- 1. Inspect rotor for any <u>of</u> the following faults and replace rotor if any are detected (with the exception of the slip ring repair noted in step G). ROTOR IS NOT SERVICEABLE IN PARTS AND MUST BE REPLACED AS A WHOLE.
 - A. Stripped shaft threads.
 - B. Worn key slots/holes (woodruff and cotter).
 - C. Worn and/or corroded bearing journal surfaces drive end and slip ring end.
 - D. Loose slip ring assembly or pole pieces on shaft.
 - E. Gouged, bent, cracked or excessive corrosion of pole pieces.
 - F. Bent, gouged or excessive corrosion of shaft.
 - G. Slip rings which are rough or out of round may be trued in a lathe (do not chuck shaft on bearing journals). Concentricity of slip rings, with respect to bearing journal, must not exceed 0.001 inch total indicator reading. Remove only enough material to make slip rings smooth and round. Final surface finish shall be 50 micro-inches maximum. The finished slip ring diameter must not be less than 1.350 inches, otherwise rotor must be replaced. Insure there are no burrs or metal particles on or between slip rings.

NOTE:

Clean dirty slip ring using Dow Chemical Chlorothene VG and wipe residue away with a clean lint free cloth.

- H. Burned/discolored coil (insulation will flake off burned coil). Damaged varnish coating is not repairable.
- 2. Rotor Resistance Test
 - A. Using a VOM measure resistance between slip ring terminals, point A and B of Figure 2-4. DO NOT CONNECT TO SLIP RING SUR-FACE. Coil resistance should be 9.9 to 11.8 ohms at 20°-27°C (70°-80°F).
 - B. If resistance is higher, inspect soldered connections at slip ring terminals. Repair if necessary using a high temperature solder per the specification shown in Figure 2-5 with rosin and alcohol flux. Repeat test of Part A.
 C. Replace rotor if coil fails resistance test.
- 3. Rotor Ground Test
 - A. Using a VOM on RX100 range, measure resistance between slip ring terminal and pole piece, points A and C of Figure 2-4. No meter movement should occur (infinite resistance). NOTE:

Inspect slip ring and solder connections to make certain they are not touching shaft. Repair and retest as required.

B. Replace rotor if any meter movement is detected.

2.4.7 Rectifier-Heat Sinks and Stator Assembly

- 1. Inspect terminals for stripped threads bent/burnt shafts. Faulty terminals require replacement.
- 2. Inspect for broken rectifier leads, damaged stator leads, loose or cracked epoxy (securing stator leads to heat sinks) and discoloration of stator windings. See following list for action required if faults are detected.
 - A. Broken rectifier leads require replacement of the associated rectifier-heat sink assembly. RECTIFIERS ARE NOT SERVICEABLE INDIVIDUALLY.



Figure 2-4

Size:	¹ /16 Diameter × Spool
Contents:	95.35% Tin 4.65% Silver (Minimum)
Plastic Temperature:	232°C approx.
Liquid Temperature:	238°C approx.
Vendor Source:	J. W. Harris Co. Cinneinnati, Ohio or

Equivalent

Figure 2-5

- B. Loose/cracked epoxy, securing stator leads, may be removed and new epoxy (3M Co. Scotchcast #10 resin) applied.
- C. Damaged stator leads require stator replacement and electrical testing as specified in step 3 to determine possible damage to rectifiers.
- D. Discoloration of stator windings indicates overheating that may be caused by shorted coils or grounded winding. Perform electrical tests on stator as specified in step 4.
- E. If stator shows wear or damage to epoxy coating of windings, the stator must be replaced.
- Perform electrical tests of the Positive and Negative Rectifier-Heat Sink Assemblies as noted in paragraphs 1.2.1 and 1.2.2.
- Stator testing can be performed as follows after disassembly per paragraph 2.3.8:
 A. Using a VOM on RX100 range, measure resis-
 - A. Using a VOM on RX100 range, measure resistance between a stator lead and bare metal surface of stator core. No meter movement should occur (infinite resistance). If a slight movement is detected or if meter indicates full scale, the stator must be replaced.
 - B. Using VOM on RX1 range, measure resistance (continuity) between AUX terminal and each stator lead (6 total). Resistance should be 0.5 ohm or less otherwise replace stator. Check flexible leads for possible opens before replacing stator.

2.5 Assembly

2.5.1 Install Drive End Oil Seal

- 1. Position drive end housing on press with front of housing on press table.
- 2. Position new oil seal squarely in housing with lip towards outside of end head.
- 3. Using a length of 1% inch diameter bar stock, press oil seal squarely into end head to a distance of approximately ¹/₁₆ inch from outside face of casting. DO NOT HAMMER.

2.5.2 Install Drive End Bearing

- 1. Position drive end housing on press with front of housing on press table.
- 2. Position new bearing squarely into bearing pocket of housing with SEALED SIDE OF BEARING TOWARDS INSIDE OF HOUSING. CARE MUST BE TAKEN TO PREVENT CONTAMINATION OF BEARING.
- Using a 2⁷/₁₆ inch O.D. pipe with ⁵/₃₂ inch wall, press bearing into housing up to the housing bearing stop. Apply pressure to outer race only. Pressure on inner race will damage bearing. DO NOT HAMMER.
- 4. Install bearing retainer and screws. Torque 25-30 inch-pounds.

2.5.3 Install Drive End Housing to Rotor Assembly

- 1. Lubricate oil seal lip with Chevron SRI #2 grease.
- 2. Position rotor assembly in press with flat surface at slip ring end of shaft against a flat and true surface of press.
- 3. Position drive end housing and bearing assembly on rotor shaft. The bearing must be square with rotor shaft. Take care not to damage oil seal as shaft passes through oil seal.
- 4. Install the shaft oil seal spacer (collar) on shaft, being careful not to fold the oil seal lip under, up to contact with the bearing inner race. The collar O-ring groove should be on the outside. SURFACE DAMAGE NOT TOLERABLE, SURFACE HAS 10-20 MICRO-INCH FINISH.
- Position bearing installation tool (1³/₁₆ inch O.D. pipe × ¼ inch wall × 2½ inch long) on shaft in contact with end of shaft collar as shown in Figure 2-6 and press bearing onto the shaft up to shaft stop.



Figure 2-6

6. Install a new O-ring seal onto shaft and position into groove of shaft collar. Use a small blunt instrument to push O-ring into groove. A small amount of Dow Corning DC4 grease on the O-ring seal will make installation easier. Make certain the seal is fully installed before assembling the remainder of the drive assembly. Figure 1-1-and 2-7 show correct assembly of oil seal and drive end head components.




Figure 2-7

2.5.4 Assemble Rectifier-Heat Sink Assemblies and Stator Assembly

This procedure applies when replacing the rectifierheat sink assemblies and/or the stator assembly. Applicable steps should be used if only one of the rectifier-heat sinks is being replaced. Figure 2-3 shows typical completed assembly. Use previous tagged connecting points to insure proper wiring of stator leads to rectifiers. INDIVIDUAL RECTIFIERS ARE NOT SERVICEABLE.

NOTE:

Too much heat can damage rectifiers or shorten their service life. Use long nose pliers between rectifiers and solder joint as a heat sink during soldering operations. Complete the operation as quickly as possible consistent with producing a good solder connection. A 100 watt soldering iron with clean tip is adequate. Use a high temperature solder as per Figure 2-5 with rosin and alcohol flux. NEVER USE ACID CORE SOL-DER FOR ELECTRICAL CONNECTIONS. THE USE OF ANY OTHER FLUX OTHER THAN ROSIN IS PROHIBITED.

1. With reference to Figure 2-3, form stator leads and rectifier-heat sink rectifier leads (minimum of ¼ inch bend radius) as shown, (pre-tin stator leads) install new solder tubing over leads (apply heat sink pliers between rectifier and joint to be soldered) and solder. Repeat this until all stator leads have been connected to the positive and negative heat sink rectifiers.

NOTE:

The stator leads will be cemented to the heat sinks using 3M Company Scotchcast #10 resin, at assembly to the slip ring end housing, with heat sinks in position in the end head.

2.5.5 Assemble Slip Ring End Head, Brush Holder and Brushes

- 1. Install brushholder in end head using screws and lockwashers. Tighten screws to 15-20 inch pounds.
- 2. Install bearing snap ring retainer, positioning gap in retainer relative to brushholder as shown in Figure 2-8.




Figure 2-8

3. Install two brush springs and brushes into holder. Depress brushes (with leads in holder slots) and insert a small drill or metal rod through the snap ring hole to hold the brushes in place (see Figure 2-9).




Figure 2-9

4. With reference to Figures 2-10A and B, assemble brush terminal insulators and install to housing using insulators and hardware shown. The RFI capacitor used on the ALV-9407 only, should also be installed at this time, as shown in Figures 2-10A and B.




Figure 2-10A




Figure 2-10B

- 5. (ALV-9407) Install capacitor clamp and mounting screw. Torque screw to 15-20 inch pounds.
- (ALV-9407) Apply Dow Corning #1890 sealer to clamp as shown to secure capacitor to clamp. Follow manufacturers instructions for sealer application.
- 7. Torque field (brush) terminal stud nuts to 25-30 inch pounds.
- 2.5.6 Install Stator and Rectifier-Heat Sink Assemblies to Slip Ring End Housing
 - 1. Assemble the stator and rectifier heat sink assemblies into the end head assembly of paragraph 2.5.5 making certain terminals, insulators and hardware are correctly assembled as shown in Figure 2-11. Align housing and stator with previous scribe marks to insure alignment of thru-bolt holes. Final torque of terminal nuts will be done at complete assembly of alternator.




Figure 2-11

NOTE:

- A. Insure that the mating surfaces of housing and stator are clean and free of any dirt, burrs or foreign material.
- B. If it was necessary to replace the stator/rectifier heat sink(s), position the stator leads so that they will not interfere with the rotor and secure leads at six places to heat sinks with 3M Company Scotchcast #10 Resin, following manufacturers instructions. See Figure 2-3 for typical epoxy application points.

2.5.7 Assemble Rear Housing-Stator Assembly to Drive End Housing and Rotor Assembly

1. Assemble the rear housing-stator assembly to the drive end housing and rotor assembly, aligning the sections with previous scribe marks on sections.

NOTE:

Insure that the mating surfaces of housing and stator are clean and free of any dirt, burrs or foreign material.

- 2. Temporarily install two thru-bolts to hold unit together.
- 3. Remove the brush retraction tool and verify brushes seat against slip rings. Visually check that brush leads are free and cannot bind against anything.
- 4. Install bearing O-ring seal into the rear housing bearing sleeve groove. Lubricate O-ring with Dow Corning DC-4 grease before installation.

2.5.8 Install Slip Ring End Bearing.

- 1. Position assembly of paragraph 2.5.7 in arbor press with flat surface of drive end shaft against a flat and true surface of press.
- 2. Position new bearing squarely into bearing pocket of housing with SEALED SIDE OF BEARING TOWARDS ROTOR. CARE MUST BE TAKEN TO PREVENT CONTAMINATION OF BEAR-ING.
- 3. Use a length of % inch diameter bar stock to press bearing into housing onto shaft and up to shaft stop. Apply pressure to inner race only. Pressure on outer race will damage bearing. (DO NOT HAMMER.)
- 4. Install slip ring end bearing cover.

2.5.9 Install Thru-Bolts and Lock Tabs

1. Install the six thru-bolts and new lock tabs. Figure 2-12 shows lock tab installation at depressed position on end head. Figure 2-13 shows lock tab installation at the five other points. The longest thru-bolt is installed in the hole between F1 and



Figure 2-12



Figure 2-13

F2 and passes through the blast tube of the drive end housing.

- 2. Tighten bolts evenly, while maintaining lock tab orientation, each a little bit at a time in sequence until all are tight and torqued to 30-35 inch pounds.
- 3. Bend six (6) lock tabs as shown in Figure 2-12 and 2-13 as applicable.

2.5.10 Terminal Torquing

1. Tighten the terminal mounting nuts to the following torque values:

Terminal	Screw Size	Torque (inch-pounds)
F1	#10-32	25-30
F2	#10-32	25-30
AUX	#10-32	25-30
(-)	1/4"-28	70-85
(+)	1/4"-28	70-85
AUX (+)	1/4"-28	70-85

2.5.11 Post Assembly Test

Perform test on completed assembly as outlined in section 1, paragraph 1.2.5.

- 2.5.12 Installation of Drive Shaft Shipping Hardware
 - 1. Install #5 woodruff key on shaft.
 - 2. Install shipping washer (ALK-50) on shaft and flush to shaft collar.
 - 3. Install shipping spacer (GJT-40C) to shaft so spacer passes over and covers key.
 - 4. Install retaining nut on shaft hand tight.
- 2.5.13 Installation of Drive Coupling
 - 1. Refer to engine manufacturer's specifications. Note that shipping washer and shipping spacer must be removed.
- 2.5.14 **Installation of Alternator to Engine** Follow engine manufacturer's instructions.

2.6 Alternator Servicing and Testing Precautions

- 1. Always refer to airframe manufacturer's wiring diagram when installing or testing the alternator on the aircraft.
- 2. Disconnect the battery, before connecting or disconnecting test instruments (except voltmeter) or replacing any unit or wiring. For negative ground applications, disconnect the negative lead first. CAUTION: ALWAYS RECONNECT BATTERY PRIOR TO OPERATING ALTERNATOR.

- 3. Alternator output lead MUST NOT be removed from alternator with field circuit energized and unit operating.
- 4. Do not attempt to polarize the alternator. No polarization is required. ANY ATTEMPT TO DO SO MAY RESULT IN DAMAGE TO ALTER-NATOR, REGULATOR OR CIRCUITS.
- 5. Grounding alternator output terminal may damage alternator and/or circuit and components.
- 6. Reversed battery connections will damage the rectifiers, wiring or other components of charging system. Battery polarity must be checked with a voltmeter before connecting battery. Most systems are negative ground.
- 7. If a booster battery or fast charger is used, its polarity must be connected correctly to prevent damage to the battery and electrical system. Provide adequate ventilation around battery and keep sparks and flame away from batteries.
- 8. When using auxiliary power unit, make sure voltage and polarity are set to correspond with vehicle system voltage and polarity.
- 9. Never use acid solder for electrical connections. Rosen flux is only type permitted.

TABLE 1-1 TROUBLE SHOOTING CHART						
TROUBLE	PROBABLE CAUSE					
LOW/NO ALTERNATOR OUTPUT	 Loose terminal connections. Worn/broken brush. Dirty/worn rotor slip rings. Short/leakage from field terminals to housing. Shorted/open rotor field. Shorted/open stator windings. Shorted/open rectifiers on positive and/or negative rectifier-heat sinks. Shorted/leaky RFI capacitor (on ALV-9407 only). 					
NOISY ALTERNATOR	 Defective bearings at drive end and/or slip ring end. Loose frame thru-bolts. Shorted rectifiers (magnetic noise). 					
INTERMITTENT OUTPUT	 Worn brushes/dirty slip rings. Loose connections/corroded terminals. 					



ALE SERIES


ALTERNATOR

ISSUED: 2-18-75(Rev.)

ORIG. EQUIP.ALTER	NATOR	SERVICE ALTERNATOR	VOLTS-12
ENG.		ENG.	
NUMBER		NUMBER	APPLICATION
ALE-6406	USE	ALE-6406R	Lycoming
ALE-6406G	USE	ALE-6406R	Lycoming
ALE-6406R		ALE-6406R	Service
ALE-6406RG	USE	ALE-6406R	Service
ALE-6420	USE	ALE-6420R	Lycoming
ALE-6420G	USE	ALE-6420R	Lycoming
ALE-6420R		ALE-6420R	Service
ALE-6420RG	USE	ALE-6420R	Service
ALE-8105A	USE	ALE-8408R	Lycoming
ALE-8406	USE	ALE-8406R	Lycoming
ALE-8406G	USE	ALE-8406R	Lycoming
ALE-8406R		ALE-8406R	Service
ALE-8406RG	USE	ALE-8406R	Service
ALE-8408	USE	ALE-8408R	Lycoming
ALE-8408R		ALE-8408R	Service
ALE-8420	USE	ALE-8420R	Lycoming
ALE-8420G	USE	ALE-8420R	Lycoming
ALE-8420R		ALE-8420R	Service
ALE-8420RG	USE	ALE-8420R	Service
ALE-8421	USE	ALE-8421R	Lycoming
ALE-8421R		ALE-8421R	Service

1.15





	Rotor Assembly	Brush Set	Brush,Holder & Spring	Slip Ring End Head	S.R.E. Bearing	Drive End Head	D.E. Bearing
Assembly		,	Assembly	Assembly	(5)	Assembly 6	
		2	<u> </u>				$+ \bigcirc -$
ALE-6406,R	90-2396[d]		ALU-1045BS[b]	90-2396[d]	90-2014[a]	ALE-1003K	X-3416
ALE-6406G,RG	н		**	н	4	51	11
ALE-6420,R	ALE-21735-1	ALE-1013AS	ALU-1045BS	ALK-1132BS-1		u	II.
ALE-6420G,RG		It	11	u	**	0	11
ALE-8105A	ALE-2016	ALE-1012LS[c]		ALE-1002LS	X-3417	н	II II
ALE-8406,R	90-23 9 6[d]		ALU-1045BS[b]	90-2396[d]	90-2014[a]	u	
ALE-8406G,RG	п		**	16	\$1		
ALE-8408,R	u		ALE-1045BS[b]	u	16	n	н
ALE-8420,R	ALE-21735-1	ALE-1013AS	ALU-1045BS	ALK-1132BS-1		U	11
ALE-8420G,RG	88	11	Ш	61	10		
ALE-8421,R	11	11	ALE-1045BS	11			H
		1					
			н. - С С С С С С С С				
	ļ	1	Ĭ			1	1
- FIJ ALE 30108	C Canadius Daur	so included with sh & Spring Set			•		
units alr Bruch Hol	eady having the	nis design. Earl Brushes or Sprin	ier units must r as are required.	eptace the comp	lete		
[c] Brush Set	only; Brush S	Spring Set ALA-1	95 also avallabi ne must be used	e. at time of firs	st repair.		
[Individua	1 Components(S	See Sheet #3 for r Pkg, (10 Pcs.)	CONTENTS OF PRO	.) may be used	thereafter.		
		File in the				NATOR SECT	ION
Printed in U.S.A.	OE-/	A1 AIRCRAFT A	AANUAL			SALOR JECH	

 \mathcal{P}_{i}

ALE SERIES ALTERNATOR PARTS LIST

Assembly	Stator Assembly 8	Pos.Rectifier & Plate Assembly 9	Negative Rectifier (Pkg.of3)	Term. Stud Package	D.E. Retainer	Slip Ring End Cover (13)	Eyelet Package
ALE-6406,R	ALE-2008AD	ALE-1054A	XA-944JS	90-2030	GR-32		90-818
ALE-6406G,RG	п	р н	п		н		"
ALE-6420,R	IV	н		U	н		u
ALE-6420G,RG	a i	ŧ		13	n		u
ALE-8105A	ALE-2008Z	ALE-1004	łt.	90-2359	п	ALE-1062	н
ALE-8406,R	ALE-2008AD	ALE-1054A	U.	90-2030	п	ALU-1062A	и
ALE-8406G,RG	u		н	u		11	14
LE-8408,R		п	н	11	п		н
LE-8420,R	n		0	11	n		h
LE-8420G,RG	Iŧ	ii -	н	11			U,
LE-8421,R	u	н	и	16	п	н .	

OD DADTE LICT

ISSUED:	3_5_70	(REV.)	SHEET	3
1330601	2-2-/9	(NEV+)	SHELL	-

ALE SERIES A	LTERNATOR PA	RTS LIST			ISSUED:	3-5-79 (Rev.)	SHEET
Assembly	Thru Bolt Package	Nut & Washer Package	Rotor Shaft Spacer	Vent Fan (2 Pc.)	Drive Pulley	Regulator	
	(15)	(16)	17	(18)	(19)	20	
ALE-6406,R	ALA-20JS	90-33	ALD-21	90-2241	PU-672A	VSF-7203S	
ALE-6406G,RG	84	u	И	II		FVR-4011A	
ALE-6420,R	н	п	11	11	0	VSF-7203S	
ALE-6420G,RG	It	5Å	н	IL		FVR-4011A	
ALE-8105A	ALA-20FS	п	н	"	н		
ALE-8406,R	ALA-20JS	u	ii	υ	u	VSF-7203S	
ALE-8406G,RG	11	u	н	n.		FVR-4011A	
ALE-8408,R	64	14	П	**	u		
ALE-8420,R	0	11	u	\$1		VSF-7203S	
ALE-8420G,RG	11	0	u	u		FVR-40T1A	
ALE-8421,R	88	п	u		п		
Į							
[d] <u>Contents</u>	of S.R.E. Hea	d & Rotor Pkg.	-				
90-2396	s s	.R.E. Hd. & Ro	tor Pkg.				
90-2014		Bearing Pkg	•				
	BS-1	Head Assy.	S.R.E.				
ALK-1132							
ALK-1132 ALE-2173	S-1	Rotor					

File in the • **OE-A1 AIRCRAFT MANUAL**



(_v



ALTERNATOR DESCRIPTION

RATED VOLTAGE 12

RATED OUTPUT

40 Amperes

ROTATION Bi-Directional

GROUNDED POLARITY

Negative

APPROXIMATE WEIGHT See Tabulation

SERVICE INFORMATION

Detailed service procedures covering disassembly, component testing, component replacement, assembly, and bench testing, are contained in the service publications in the front of the Alternator Section. Refer to the following service publications when detailed service information is required.

ALTERNATOR SERIES	SERVICE PUBLICATION
ALE 8100	L-651A
ALE 6400 - 8400	L-655A

SERVICE BULLETINS

Refer to the Service Bulletin Section of this manual for bulletins pertaining to the ALE series alternators.

SERVICE SPECIFICATIONS

DRIVE PULLEY

Torque the drive pulley retaining nut to 35 Ft. Lbs. minimum to 40 Ft. Lbs. maximum.

ROTOR OHMMETER TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Ohmmeter must be accurate and batteries must be fresh. Frequently check ohmmeter accuracy by measuring a known resistance such as a 10.0 ohm resistor.
- 3. Ohmmeter must be checked to zero before and after rotor test.
- 4. Slip rings and ohmmeter test probes must be clean. Ohmmeter test probe leads must be in good condition.



AIRCRAFT ALTERNATORS Issued 4/1/83 Page 2 of 4



ROTOR OHMMETER TEST SPECIFICATION

Rotor winding resistance - 3.0 to 5.0 ohms.

ROTOR CURRENT DRAW TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Voltmeter and ammeter must be accurate.
- 3. Refer to service publication for test wiring diagram.

ROTOR CURRENT DRAW TEST SPECIFICATION

Current draw at 12.0 volts - 2.4 to 4.0 amperes.

SLIP RING REFINISHING

Minimum Diameter1.350"Total Indicator Runout.002" max. measure from bearing journalsSurface Finish50 microinch max.

ALTERNATOR OUTPUT TEST CONDITIONS

- 1. Alternator to be room temperature 70° to 80° F. before beginning test.
- 2. Alternator connected so it is supplying its own field current. Refer to service publication for bench test wiring diagram.
- 3. Output voltage to be controlled by an adjustable load.
- 4. Alternator not to be run more than 2 minutes for each test point.

VENTILATION

All units except the 6400 series, use a slip ring end cover that has a hose type connection for air pressure ventilation. Remove this cover when bench testing the alternator.

ALE



	TEST	SPECIFICATIONS	(Without	Regulator)
UUIFUI	16.01	01 2011 2011 20110	(

Alternator	Output	Output	Minimum
Series	Voltage	Amperage	Alternator RPM
ALE 6400, 8100,	14.0	19	2000
and 8400	14.0	32	4000

Alternator	Approx. Weight	Internal Wiring	Orig. Equip. Regulator	Replacement Regulator
ALE-6406, R	10 Lb. 6 Oz.	Figure 1	VSF-7201 or 7203	VSF-7203S
ALE-6406G, RG	10 Lb. 6 Oz.	Figure 1*	FVR-4004+	
ALE-6420, R	10 Lb. 6 Oz.	Figure 1	VSF-7203	VSF-7203S
ALE-6420G, RG	10 Lb. 6 Oz.	Figure 1*	FVR-4004+	
ALE-8105A	10 Lb.	Figure 2		
ALE-8406, R	10 Lb. 12 Oz.	Figure 1	VSF-7201 or 7203	VSF-7203S
ALE-8406G, RG	10 Lb. 12 Oz.	Figure 1*	FVR-4004+	
ALE-8408, R	10 Lb. 12 Oz.	Figure 3		
ALE-8420, R	10 Lb. 12 Oz.	Figure 1	VSF-7203	VSF-7203S
ALE-8420G, RG	10 Lb. 12 Oz.	Figure 1*	FVR-4004+	
ALE-8421, R	10 Lb. 12 Oz.	Figure 3		VSF-7203S

* Same as Figure 1 except field terminal F-2 externally grounded with a strap connector. Lycoming applications only.


+ Wico - Prestolite part number.



ALE	
AIRCRAF	T ALTERNATOR
Issued	4/1/83

Page 4 of 4








Figure 1

Figure 2




Figure 3



ALT SERIES


ALTERNATOR

ISSUED: 10-19-79(Rev.)

ORIG.EQUIP.ALTERN	IATOR	SERVICE ALTERNATOR	VOLTS-24
ENG. <u>NUMBER</u>		ENG. <u>NUMBER</u>	APPLICATION
ALT-5101A		ALT-5101A	Franklin
ALT-5102S		ALT-5102S	Franklin
ALT-8403	USE	ALT-8420	Teledyne Continental
ALT-8404	USE	ALT-8421R	Lycoming
ALT-8404LS	USE	ALT-8421RS	Lycoming
ALT-8404R	USE	ALT-8421R	Service
ALT-8404RS	USE	ALT-8421RS	Service
ALT-8407	USE	ALT-8420	Teledyne Continental
ALT-8420		ALT-8420	Teledyne Continental
ALT-8421	USE	ALT-8421R	Lycoming
ALT-8421LS	USE	ALT-8421RS	Lycoming
ALT-8421R		ALT-8421R	Service
ALT-8421RS		ALT-8421RS	Service
ALT-9405	USE	ALT-9422	Teledyne Continental
ALT-9422	1.000	ALT-9422	Teledyne Continental







2

ALT	SERIES	ALTERNATOR	PARTS	LIST

SHEET 2 ISSUED 10-10-70 (D.

Rotor Assembly 1 ALT-2006 " 90-2397[e] " " ALU-2128S-1	Brush Set 2 ALE-1012LS[b] ALB-1013BS[b] [c] [c] [c] [c]	Brush,Holder & Spring Assembly (NA] [NA] ALU-1045BS[c] "	Slip Ring End Head Assembly 4 * ALH-1002CS ALH-1002DS 90-2397[e]	S.R.E. Bearing 5 X-3417 " 90-2014[a]	Drive End Head Assembly 6 ALE-1033	D.E. Bearing 7 <u>x-5077</u>
ALT-2006 " 90-2397[e] " " ALU-21285-1	ALE-1012LS[b] ALB-1013BS[b] [c] [c] [c]	3 [NA] [NA] ALU-1045BS[c] "	(4) * ALH-1002CS ALH-1002DS	X-3417 "	ALE-1033	χ <i>-</i> 5077
" 90-2397[e] " " ALU-2128S-1	ALB-1013BS[b] [c] [c] [c]	[NA] ALU-1045BS[c] "	ALH-1002DS	58		
90-2397[e] " " N ALU-2128S-1	[c] [c] [c]	ALU-1045BS[c] "			u .	u
" " ALU-2128S-1	[c] [c]	10	90-2397[e]	90-2014[-3]	- I	
" " ALU-21285-1	[c]		1	Ing FALAT	ALE-1003K	X-3416
" ALU-21285-1		п	"	н		U
ALU-21285-1	[c]		н		u	8
		н	11	u	н	
	ALE-1013AS	ALU-1045BS	ALK-1132AS-1	н	н	
u	н	n	11	0	и	11
u	н	u	11	н	u .	8
90-2398[e]	[c]	ALU-1045BS[c]	90-2398[e]	n	ALU-1043[d]	X-4087
ALU-2138S-1	ALE-1013AS	ALU-1045BS	ALE-1142AAS-1	и	41	и
					, .	
eal Pkg. ; als sh Spring Set Captive Brush ing this desig . if Brushes o . 011 Seal als . Pator Pkg (o included with Also available. & Spring Set al n. Earlier unit r Springs are r o available. omplete Package	Rotor & Slip R so individually s must replace equired.	available for u the Complete Bru t time of first	nits sh repair.	ų I	
	90-2398[e] ALU-2138S-1 ALU-2138S-1 ALU-2138S-1 Sh Spring Set Captive Brush ing this desig . if Brushes O . 011 Seal als & Rotor Pkg. C Components (See ble.	90-2398[e] [c] ALU-2138S-1 ALE-1013AS 49BS) Cover Pkg. (10 Pcs.) AI eal Pkg.; also included with sh Spring Set Also available. Captive Brush & Spring Set al ing this design. Earlier unit . if Brushes or Springs are r . 011 Seal also available. & Rotor Pkg. Complete Package Components (See Sheet #3 for c ble, File in the	90-2398[e] [c] ALU-1045BS[c] ALU-2138S-1 ALE-1013AS ALU-1045BS 49BS) Cover Pkg. ALE-1013AS ALU-1045BS 49BS) Cover Pkg. (10 Pcs.) Also available. ALU-1045BS cal Pkg.; also included with Rotor & Slip R Sh Spring Set Also available. Captive Brush & Spring Set also individually ing this design. Earlier units must replace . if Brushes or Springs are required. . Oil Seal also available. . Oil Seal also available. Components (See Sheet #3 for contents of Pkg. ble.	90-2398[e] [c] ALU-1045BS[c] 90-2398[e] ALU-2138S-1 ALE-1013AS ALU-1045BS ALE-1142AAS-1 ALU-2138S-1 ALE-1013AS ALU-1045BS ALE-1142AAS-1 49BS) Cover Pkg. (10 Pcs.) Also available. - eal Pkg.; also included with Rotor & Slip Ring End Head Ass sh Spring Set Also available. captive Brush & Spring Set also individually available for u - 1011 Seal also available. - & Rotor Pkg. Complete Package must be used at time of first Components(See Sheet #3 for contents of Pkg.)may be replaced ble.	90-2398[e] [c] ALU-1045BS[c] 90-2398[e] " ALU-2138S-1 ALE-1013AS ALU-1045BS ALE-1142AAS-1 " ALU-2138S-1 ALE-1013AS ALU-1045BS ALE-1142AAS-1 " AUU-2138S-1 ALE-1013AS ALU-1045BS ALE-1142AAS-1 " AUU-2138S-1 ALE-1013AS ALU-1045BS ALE-1142AAS-1 " 4985) Cover Pkg. (10 Pcs.) Also available. - - - 4985 Cover Pkg. (10 Pcs.) Also available. - - - eal Pkg. ; also included with Rotr & Slip Ring End Head Assy. - - - sh Spring St Also available. - - - - Captive Brush & Spring St Also individually available for units ing this design. Earlier units must replace the Complete Brush - - - . 11 Seai also available. - - - - - - . 12 Seai also available. - - - - - - . 13 Seai also available. - - - - - - . 14 Testhes or Springs are required.	90-2398[e] [C] ALU-104585[C] 90-2398[e] " ALU-1043[d] ALU-21385-1 ALE-1013AS ALU-104585 ALE-1142AAS-1 " " 4985) Cover Pkg. (10 Pcs.) Also available. " " " 4985) Cover Pkg. (10 Pcs.) Also available. " " " 4985) Cover Pkg. (10 Pcs.) Also available. " " " 61 Pkg.; also included with Rotor & Slip Ring End Head Assy. " " " 61 Pkg.; also included with Rotor & Slip Ring End Head Assy. " " " 62 Pkg.; also included with Rotor & Slip Ring End Head Assy. " " " 63 Pkg.; also included with Rotor & Slip Ring End Head Assy. " " " 64 Pkg.; also included with Rotor & Slip Ring End Head Assy. " " " 62 Pkg.; also included with Rotor & Slip Ring End Head Assy. " " " 63 Pkg.; also included with Rotor & Slip Ring End Head Assy. " " " 64 Pkg.; also available. " " " " 65 Pkg.; Complete Package must_be used at time of first repair. " "

OE-A1 AIRCRAFT MANUAL

f,

ALT SERIES ALTERNATOR PARTS LIST

Assembly	Stator Assembly	Pos.Rectifier & Plate Assembly 9	Negative Rectifier (Pkg.of3)	Terminal Stud Package	D.E. Retainer	Thru Bolt Package (13)	Eyelet Package
ALT-5101A	ALE-2008R	ALE-1004	XA-944JS	90-2359	GGW-91	ALA-20ES	90-818
ALT-5102S	II.	41	u	90-990	"	"	90-010
ALT-8403	ALE-2008AA	ALE-1054A	u	90-2043	GR-32	ALA-20GS	u
ALT-8404,R	н	u	54	90-2030		"	n
ALT-8404LS,RS	11	н	n	11		н	0
ALT-8407	u	u	14	90-2043	п		n
ALT-8420	u	11	16		n	It	
ALT-8421,R	11	31	ii	90-2030		ш	
ALT-8421LS,RS	lī	n	u	n	н	n	
ALT-9405	u	n	н	90-2043	н	11	u
ALT-9422	n	11	H	0	u	n	14

ALT SERIES ALTERNATOR PARTS LIST

Printed in U.S.A.

OE-A1 AIRCRAFT MANUAL

ISSUED: 10-19-79(Rev.) SHEET 3

1

STATES SILLI S
gulator
20
-7401C
-7403S
n
n j
t
u l
9
1
n -
1
ł



ALTERNATOR DESCRIPTION

RATED VOLTAGE 24

RATED OUTPUT 50 Amperes

Negative

ROTATION Bi-Directional

APPROXIMATE WEIGHT See Tabulation

SERVICE INFORMATION

GROUNDED POLARITY

Detailed service procedures covering disassembly, component testing, component replacement, assembly and bench testing are contained in the service publications in the front of the Alternator Section. Refer to the following service publication when detailed service information is required.

ALTERNATOR SERIES	SERVICE PUBLICATION
ALT 5100	L-651A
ALT 6400 - 8400	L-655A
ALT 9400	L-663

SERVICE BULLETINS

Refer to the Service Bulletin Section of this manual for bulletins pertaining to the ALT series alternators.

SERVICE SPECIFICATIONS

DRIVE PULLEY

Torque the drive pulley retaining nut to 35 Ft. Lbs. minimum to 40 Ft. Lbs. maximum.

ROTOR OHMMETER TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Ohmmeter must be accurate and batteries must be fresh. Frequently check ohmmeter accuracy by measuring a known resistance such as a 10.0 ohm resistor.
- 3. Ohmmeter must be checked to zero before and after rotor test.
- 4. Slip rings and ohmmeter test probes must be clean. Ohmmeter test probe leads must be in good condition.



ALT

AIRCRAFT ALTERNATORS	
Issued 4/1/83	

SERVICE

Page 2 of 4

ROTOR OHMMETER TEST SPECIFICATION

Rotor winding resistance - 10.5 to 12.5 ohms.

ROTOR CURRENT DRAW TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Voltmeter and ammeter must be accurate.
- 3. Refer to service publication for test wiring diagram.

ROTOR CURRENT DRAW TEST SPECIFICATION

Current draw at 24.0 volts - 1.9 to 2.3 amperes.

SLIP RING REFINISHING

Minimum Diameter1.350"Total Indicator Runout.002" max. measure from bearing journalsSurface Finish50 microinch max.

ALTERNATOR OUTPUT TEST CONDITIONS

- 1. Alternator to be room temperature 70° to 80° F. before beginning test.
- 2. Alternator connected so it is supplying its own field current. Refer to service publication for bench test wiring diagram.
- 3. Output voltage to be controlled by an adjustable load.
- 4. Alternator not to be run more than 2 minutes for each test point.

VENTILATION

The 8400 series alternators use a slip ring end cover that has a hose type connection for air pressure ventilation. Remove this cover when bench testing the alternator.

The 9400 series alternators are cooled entirely by air pressure through a hose type connection on the drive end head. When bench testing this type of alternator, make output tests as short as possible unless adequate air pressure for cooling is supplied.

AIRCRAFT ALTERNATORS

Issued: 4/1/83

Page 3 of 4

ALTERNATOR OUTPUT TE	EST SPECIFICATIONS	(Without R	egulator)	
Alternator Series	Output Voltage	Output Amperage	Minimum Alternator	RPM
ALT 5100, 6400 and 8400	, 28.0 28.0	20 43	3000 6000	
ALT 9400	28.0 28.0	17 43	3000 6000	
	Approx. Weight	Internal Wiring	Orig. Equip. Regulator	Replacement Regulator
ALT 5101A, S	12 Lb. 2 Oz.	Figure 1	VSB-7401C	
ALT 5102S	12 Lb. 2 Oz.	Figure 2	VSF-7401	VSF-7403S
ALT 6408	11 Lb. 12 Oz.	Figure 3	VSF-7404	VSF-7403S

restolite.__ Service ____

INFORMATION


ALT 6408	11 Lb. 12 Oz.	Figure 3	VSF-7404	VSF-7403S
ALT 8403	12 Lb. 2 Oz.	Figure 3	VSF-7402S or VSF-7404	VSF-7403S
ALT 8404, LS, R, RS, S	12 Lb. 2 Oz.	Figure 3	VSF-7401 or VSF-7403	VSF-7403S
ALT 8407	12 Lb. 2 Oz.	Figure 3	VSF-7404	VSF-7403S
ALT 8420	12 Lb. 2 Oz.	Figure 3	VSF-7404	VSF-7403S
ALT 8421, LS, R, RS, S	12 Lb. 2 Oz.	Figure 3	VSF-7403	VSF-7403S
ALT 9405	11 Lb. 6 Oz.	Figure 3	VSF-7401 or VSF-7403S	VSF-7403S
ALT 9422	11 Lb. 6 Oz.	Figure 3	VSF-7404	VSF-7403S



Printed in U.S.A.

 ALT
AIRCRAFT ALTERNATORS
Issued: 4/1/83
 Page 4 of 4








Figure 1

Figure 2




Figure 3



ALU SERIES

ALTERNATOR


ISSUED: 2-27-75(Rev.)

ORIG.EQUIP.ALTERNATOR		SERVICE ALTER	NATOR VOLTS-24
ENG. NUMBER		ENG. NUMBER	APPLICATION
ALU-8403 ALU-8403LS ALU-8403R ALU-8403RS ALU-8421	USE USE USE USE USE	ALU-8421R ALU-8421RS ALU-8421R ALU-8421RS ALU-8421RS ALU-8421R	Lycoming Lycoming Service Service Lycoming
ALU-8421LS ALU-8421R ALU-8421RS ALU-9404L ALU-9404R	USE USE	ALU-8421RS ALU-8421R ALU-8421RS ALU-9404R ALU-9404R	Lycoming Service Service Lycoming Service
ALU-9422L ALU-9422R	USE	ALU-9422R ALU-9422R	Lycoming Service




File in the OE-A1 AIRCRAFT MANUAL

ALTERNATOR SECTION



ALU SERIES ALTERNATOR PARTS LIST					ISSUED: 3-5-79 (Rev.) SHEET 2				
	Rotor Assembly	Brush Set	Br.,Holder & Spring	Slip Ring End Head	S.R.E. Bearing &	Drive End Head	D.E. Bearing		
Assembly			Assembly	Assembly	Seal Pkg.	Assembly	$\overline{7}$		
	()	(2)			<u></u>				
ALU-8403,R	90-2397[d]		ALU-104585[b]	90-2397[d]	90-2014[a]	ALE-1003K	X-3416		
ALU-8403LS,RS	н		10	u	<u>н</u>	Ш			
ALU-8421,R	ALU-21285-1	ALE-1013AS	ALU-1045BS	ALK-1132AS-1		U			
ALU-8421LS,RS	**	ii	U U	H		"			
ALU-9404L,R	90-2398[d]		ALU-1045BS[b]		0	ALU-1043[c]	X-4087 "		
ALU-9422L,R	ALU-21385-1	ALE-1013AS	ALU-1045BS	ALE-1142AAS-1	1				
					•				
[*] 35-781 (GJC-49BS) Cover	r Pkg. (10 Pcs.) Also availabl	e. Ding End Head A	ssv				
				Ring End Head As 11y available for ce the Complete					
already Holder A	having this de ssy if Brushe	sign. Earlier (s or Springs at		ce the Complete					
[c] XA-1026	D.E.Oil Seal a	iso available.	and much be use	d at time of fi	rst repair. aced thereafter	` .			
- Individu	al components(See Sheet #3 fo	or contents of P	kg.)may be repla	acta viter tar ber	•			
File in the ALTERNATOR SECTION									





ALU SERIES ALTERNATOR PARTS LIST

Assembly	Stator Assembly	Pos.Rect. & Plate Assembly 9	Negative Rectifier Package 10	Term Stud Package	S.R.E. Cover	D.E. Retainer	Thru Bolt Package
LU-8403,R	ALE-2008AB	ALE-1054A	XA-944JS	90-2030	ALU-1062A	GR-32	ALA-20GS
LU-8403LS,RS	0	н		п	n	н	u
LU-8421,R	н	п	n	"		u	n
LU-8421LS,RS	н	u	н	u	п	н	
LU-9404L,R	11	н	н	90-2043		n	
LU-9422L,R	n	ii ii	4	ii		U	u
-							
:							

ALL SERIES ALTERNATOR PARTS LIST

ISSUED: 2-27-75(Rev.) SHEET 3

ALU SENIES	ALTERNATOR F	ARIS LIST				2-27-75(Rev.)	SHEET 3
Assembly	Eyelet Package	Nut & Washer Package	Rotor Shaft Spacer	Vent. Fan (2 Pc.)	Drive Pulley	Regulator	
	(15)	(16)	(17)	18	(19)	(20)	· • · · · ·
LU-8403,R	90-818	90-33	ALD-21	90-2241	PU-672A	VSF-7403S	
LU-8403LS,RS	0	u	н	н		n	
NLU-8421,R	u	И	11	u	PU-672A	11	
LU-8421LS,RS	u	н	0	н		u	
LU-9404L,R		8X-4075[f]	ALU-23[e]			n	
ALU-9422L,R	11	u	11			11	
[d] Contents	o_f S.R.E. Head	& Rotor Pkg.					
S.R.E.Hea	ad & Rotor Pkg.		90-2398				
Bearin	ng Pkg.	90-2014	90-2014				
Head A	Assy.,S.R.E.	ALK-1132AS-1	ALE-1142AA	5-1			
Rotor		ALU-21285-1	ALU-2138S-1				
[0] XA-744AZ	Shaft Spacer	O-Ring also ava equired.	ilable.				
[f] Nut only	, washer not re						

.



Page 1 of 3

ALTERNATOR DESCRIPTION

24 RATED VOLTAGE

RATED OUTPUT 70 Amperes

ROTATION **Bi-Directional** GROUNDED POLARITY Negative

See Tabulation APPROXIMATE WEIGHT

SERVICE INFORMATION

Detailed service procedures covering disassembly, component testing, component replacement, assembly, and bench testing are contained in the service publications in the front of the Alternator Section. Refer to the following service publication when detailed service information is required.

ALTERNATOR SERIES	SERVICE PUBLICATION
ALU 6400 - 8400	L-655A
ALU 9400	L-663

SERVICE BULLETINS

Refer to the Service Bulletin Section of this manual for bulletins pertaining to the ALU series alternators.

SERVICE SPECIFICATIONS

DRIVE PULLEY

Torque the drive pulley retaining nut to 35 Ft. Lbs. minimum to 40 Ft. Lbs. maximum.

ROTOR OHMMETER TEST CONDITIONS

- Rotor to be room temperature 70° to 80° F. 1.
- Ohmmeter must be accurate and batteries must be fresh. 2. Frequently check ohmmeter accuracy by measuring a known resistance such as 10.0 ohm resistor.
- Ohmmeter must be checked to zero before and after rotor test. 3.
- Slip rings and ohmmeter test probes must be clean. Ohmmeter 4. test probe leads must be in good condition.



Tech.

ALU

AIRCRAFT ALTERNATORS

Issued 4/1/83

1354Ca 1/1/5

Page 2 of 3

ROTOR OHMMETER TEST SPECIFICATION

Rotor winding resistance - 10.5 to 12.5 ohms.

ROTOR CURRENT DRAW TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Voltmeter and ammeter must be accurate.
- 3. Refer to service publication for test wiring diagram.

ROTOR CURRENT DRAW TEST SPECIFICATION

Current draw at 24.0 volts - 1.9 to 2.3 amperes.

SLIP RING REFINISHING

Minimum Diameter1.350"Total Indicator Runout.002" max. measure from bearing journalsSurface Finish50 microinch max.

prestolite.

SERVICE

INFORMATION

ALTERNATOR OUTPUT TEST CONDITIONS


- 1. Alternator to be room temperature 70° to 80° F. before beginning test.
- 2. Alternator connected so it is supplying its own field current. Refer to service publication for bench test wiring diagram.
- 3. Output voltage to be controlled by an adjustable load.
- 4. Alternator not to be run more than 2 minutes for each test point.

VENTILATION

The 8400 series alternators use a slip ring end cover that has a hose type connection for air pressure ventilation. Remove this cover when bench testing the alternator.

The 9400 series alternators are cooled entirely by air pressure through a hose type connection on the drive end head. When bench testing this type of alternator, make output tests as short as possible unless adequate air pressure for cooling is supplied. ALUAIRCRAFT ALTERNATORSSERVICEINFORMATIONPage 3 of 3

ALTERNATOR OUTPUT TEST	SPECIFICATIONS	(Without Regula	ator)
Alternator Series	Output Voltage	Output Amperage	Minimum Alternator RPM
ALU 6400, 8400	28.0 28.0	23.0 61.0	4000 8000
ALU 9400	28.0 28.0	21.0 60.0	4000 8000
Alternator	Approx. Weight	Orig. Equip. Regulator	Replacement Regulator
ALU-6404	11 Lb. 12 Oz.	VSF-7404	VSF-7403S
ALU-8401	12 Lb. 2 Oz.	VSF-7401	VSF-7403S
ALU-8403, LS, R, RS, S	12 Lb. 2 Oz.	VSF-7403	VSF-7403S
ALU-8421, LS, R, RS, S	12 Lb. 2 Oz.	VSF-7403	VSF-7403S
ALU-9404, L, R	11 Lb. 6 Oz.	VSF-7403	VSF-7403S
ALU-9422, L, R	11 Lb. 6 Oz.	VSF-7403	VSF-7403S



Internal Wiring Diagram

File in the



ALV SERIES

ALTERNATORS

ISSUED: 11-10-82 (Rev.)


ORIG.EQUIP.ALTER	RNATOR	SERVICE ALTERNATOR	VOLTS-24
PART NUMBER		PART NUMBER	APPLICATION
ALV-6403LS	USE	ALV-8512R	Lycoming
ALV-6403RS	USE	ALV-8512R	Service Alternator
ALV-8402	USE	ALV-8511R	Teledyne Cont.,Service
ALV-8402L	USE	ALV-8511R	Lycoming
ALV-8511	USE	ALV-8511R	Lycoming
ALV-8511R		ALV-8511R	Service Alternator
ALV-8512	USE	ALV-8512R	Lycoming
ALV-8512R		ALV-8512R	Service Alternator
ALV-9401	USE	ALV-9510R	Teledyne Cont.
ALV-9401L	USE	ALV-9510R	Lycoming
ALV-9401R	USE	ALV-9510R	Service Alternator
ALV-9405L	USE	ALV-9405R	Lycoming
ALV-9405R	UUL	ALV-9405R	Service Alternator
ALV-9406L	USE	ALV-9406R	Lycoming
ALV-9406R	UUL	ALV-9406R	Service Alternator
ALV-9407	USE	ALV-9510R	Teledyne Cont.
ALV-9407S	USE	ALV-9510R	Service Alternator
ALV-9510	USE	ALV-9510R	
ALV-9510L	USE	ALV-9510R	Lycoming
ALV-9510R	USL	ALV-9510R	Service Alternator
ALV-JJION		11ET 30101	

NOTE: SEE TABLE FOR ALTERNATOR BEING SERVICED WHEN COMPONENT PARTS ARE REQUIRED.



File in the **OE-A1 AIRCRAFT MANUAL**

ALTERNATOR SECTION



Assembly	Rotor Assembly	Brush Set	Slip Ring End Head Assembly	S.R.E. Bearing	Drive End Head Assembly 5	D.E. Bearing	Stator Assembly
N V 640216		ALV-1012S	ALV-10225	X-4087	ALB-2003A	X-4086	ALV-2008AS
ALV-6403LS	AL V-2026AS "	ALV-10125	ALV-10223	л-4007 II	ALD-2003A		11
ALV-6403RS	и И	n		н	u	u	u
ALV-8402	н	и	11	и	п	н	
ALV-8402L		II.		X-3626A	ALB-2003B	11	
ALV-8511	u	11	ALV-1022BS "	₩ 1	ALB=20038	11	
ALV-8511R			"	41			u
ALV-8512					II	n	
ALV-8512R	μ	II.					
ALV-9401	AL V-2006AS		ALV-1002S	X-4087 "	ALV-1003[a] "		
ALV-9401L		11					
ALV-9401R	п	Ш	11	0			
ALV-9405L	14	11	11	11	ALV-1003A[a]	11	
ALV-9405R	U	11	**				
ALV-9406L	н	11	14	n	ALV-1003[a]	н	u
ALV-9406R	0	н	11	Ш	11	U.	u
ALV-9407		11	ALV-1002AS	11	u	п	ш
ALV-9407S	н	11	u	U			41
ALV-9510	н	11	ALV-1102AS	X-3626A	ALV-1003[a]		11
ALV-9510L	н	11	n	II	н	n	
ALV-9510R	н	н	u	н		п	п
					1		
							-
						1	



ç.

Neg.Rect.& Plate S.R.E. S.R.E. Pos.Rect.& Vent. Brush Br.Holder Bearing Retainer Cover Assembly & Bkt. Spring Plate Assembly Set Assembly Assembly Cover Assembly (13)(14) [6] 9 (10)(11) (12) 8 AMA-19S ALV-1004 ALV-1004A [NR] GJT-47 GR-32 ALV-6403LS ALV-1015 н н н n U. [NR] ... ALV-6403RS " " ч ALV-1031 u 15 ALV-8402 11 н н н н н u a ALV-8402L л [NR] п н н н ... ALV-8511 u п ar. 16 [NR] н n ALV-8511R н a [NR] n [NR] ALV-8512 н п 11 [NR] п 11 33 n [NR] ALV-8512R ш ... GR-32 ß а н [NR] ALV-9401 п n п п 0 [NR] р ALV-9401L u 11 ... н н [NR] ALV-9401R п н п н н п в [NR] ALV-9405L n ... 13 0 н [NR] п ALV-9405R н п ALV-1031 н в 11 п ALV-9406L п 0 н 0 п л ALV-9406R I н u, u 11 ALV-9407 ш ... [NR] н ALV-9407S 0 а н п [NR] н н п [NR] л [NR] n н ALV-9510 0 п [NR] 0 н [NR] n. ALV-9510L р ł1 u. [NR] л [NR] ALV-9510R п [b] Used only on Early Production units having Snap Ring at Slip Ring End of Rotor Shaft. [NR] Not required.

ALV SERIES ALTERNATOR PARTS LIST

ALV SERIES ALTERNATOR PARTS LIST

ISSUED: 11-10-82 (Rev.)

SHEET 3

Assembly	Capacitor Assembly	Term. Stud Package 16	Lock Tab Package	Eyelet Package	Thru Bolt Package	Bearing O Ring Seal 20	Nut & Washer Package 21
ALV-6403LS	[NR]	90-2040	MES-98S	90-818	ALB-20AS	XA-744AB	90-33
ALV-6403RS	[NR]		н	u	и	0	н
ALV-8402	[NR]	н	н	н	, n	II	u
ALV-8402L	[NR]	н	11	н	п	11	н
ALV-8511	[NR]	11	1F	11	n	XA-1540S	Ш
ALV-8511R	[NR]	"	11	u u	n	ii .	II
ALV-8512	[NR]	н	11	14	n	11	п
ALV-8512R	[NR]	11	11	н	п	ti	II
ALV-9401	[NR]	90-2046	Ш	н	ALB-20AS-1	XA-744AB	8X-4075[c]
ALV-9401L	[NR]	11	11	11	u	н	"
ALV-9401R	[NR]	н	11	18	u	н	U
ALV-9405L	[NR]	U	Ш	н	и	н	и
ALV-9405R	[NR]	81	п	11	0	u	н
ALV-9406L	[NR]	90-2040	н	н	и	n	u
ALV-9406R	[NR]	н	0	н	a	0	11
ALV-9407	ALV-1038S	90-2046	11	n	ii I	н	н
ALV-9407S	u.	\$1	П	н	u	н	a
ALV-9510	ALV-1038S	U	н	u	н	XA-1540S	11
ALV-9510L	u	a	н	n	п	II	0
ALV-9510R	u		н	u	н	н	11
[c] Nut only NR] Not requ	r; Washer not re jred.	quired.					



ξ.,

ALV SERIES ALTERNATOR PARTS LIST

Г

Assembly	Rotor Shaft Spacer 22	Vent. Fan	Regulator
	22	23	24
ALV-6403LS	ALB-21 *	PU-1609A	VSF-7403S
ALV-6403RS	0	н	n
ALV-8402	п	*1	u
ALV-8402L	0	н	U
ALV-8511	n	н	u
ALV-8511R	и	ш	п
ALV-8512	н	11	11
ALV-8512R	н	u .	н
ALV-9401	ALV-21[d]*	[NR]	н
ALV-9401L	u .	[NR]	u
ALV-9401R	U U	[NR]	n
ALV-9405L		[NR]	н
ALV-9405R	н	[NR]	11
ALV-9406L	н	[NR]	u
ALV-9406R	н	[NR]	u
ALV-9407	н	[NR]	н
ALV-9407S	н	[NR]	ц
ALV-9510	90-2822[e]	[NR]	н
LV-9510L	н	[NR]	u
LV-9510R	н	[NR]	н
	s,		
		1	
I	I		
Spacer only.			

[d] XA-744AZ Shaft Spacer O-Ring Seal is also available.

[e] Includes XA-744AZ Shaft Spacer O-Ring Seal.

[NR] Not required.



Page 1 of 3

ALTERNATOR DESCRIPTION

24 RATED VOLTAGE

RATED OUTPUT 100 Amperes

Bi-Directional ROTATION

GROUNDED POLARITY Insulated System

APPROXIMATE WEIGHT See Tabulation

SERVICE INFORMATION

Detailed service procedure covering disassembly, component testing, component replacement, assembly, and bench testing, are contained in the service publications in the front of the Alternator Section. Refer to the following service publications when detailed service information is required.

ALTERNATOR	SERVICE
SERIES	PUBLICATION
ALV-6400 - 8400	L-664
ALV-9400	L-670
ALV-9500	L-680

SERVICE BULLETINS

Refer to the Service Bulletin Section of this manual for bulletins pertaining to the ALV series alternators.

SERVICE SPECIFICATIONS

- Torque the drive pulley retaining nut to 35 Ft. Lbs. DRIVE PULLEY minimum to 45 Ft. Lbs. maximum.
- Torque the drive gear retaining nut to 37 Ft. Lbs. DRIVE GEAR minimum to 42 Ft. Lbs. maximum.

ROTOR OHMMETER TEST CONDITIONS

- Rotor to be room temperature 70° to 80° F. 1.
- Ohmmeter must be accurate and batteries must be fresh. 2. Frequently check ohmmeter accuracy by measuring a known resistance such as a 10.0 ohm resistor.
- Ohmmeter must be checked to zero before and after rotor 3. test.



ALV

AIRCRAFT ALTERNATORS Issued: 4/1/83



Page 2 of 3

ROTOR OHMMETER TEST CONDITIONS CONT'D.

4. Slip rings and ohmmeter test probes must be clean. Ohmmeter test probe leads must be in good condition.

ROTOR OHMMETER TEST SPECIFICATION

Rotor winding resistance - 9.9 to 11.8 ohms.

ROTOR CURRENT DRAW TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Voltmeter and ammeter must be accurate.
- 3. Refer to service publication for test wiring diagram.

ROTOR CURRENT DRAW TEST SPECIFICATION

Current draw at 24.0 volts - 2.03 to 2.42 amperes.

SLIP RING REFINISHING

Minimum Diameter1.350"Total Indicator Runout.002" max. measure from bearing journalsSurface Finish50 microinch max.

ALTERNATOR OUTPUT TEST CONDITIONS

- 1. Alternator to be room temperature 70° to 80° F. before beginning test.
- 2. Alternator connected so it is supplying its own field current. Refer to service publication for bench test wiring diagram.
- 3. Output voltage to be controlled by an adjustable load.


VENTILATION

The 8400 series alternators use a slip ring end cover that has a hose type connection for air pressure ventilation. Remove this cover when bench testing the alternator.

The 9400 and 9500 series alternators are cooled entirely by air pressure through a hose type connection on the drive end head. When bench testing this type of alternator, make output tests as short as possible unless adequate air pressure for cooling is supplied.



ALTERNATOR OUTPUT TEST	SPECIFICATIONS	(Without Regula	tor)	
Alternator Series	Output Voltage	Output Amperage	Minimum Alternator	RPM
ALV 6400-8400-8500	28.0 28.0	53.0 88.0	3000 6000	
ALV 9400 & 9500	28.0 28.0	48.0 83.0	3000 6000	
Alternator	Approx. Weight	Orig. Equ [.] Regulator	ip.	Replacement Regulator
ALV-6403LS, RS ALV-6404 ALV-8402, L ALV-8511, R ALV-8512, R	20 Lb. 20 Lb. 21 Lb. 21 Lb. 20 Lb.	VSF-7403 VSF-7403	or 7404	VSF-7403S VSF-7403S VSF-7403S VSF-7403S VSF-7403S
ALV-9401, L, R ALV-9405L, R ALV-9406L, R ALV-9407, S ALV-9510, L, R	21 Lb. 10 Oz. 21 Lb. 10 Oz. 22 Lb. 10 Oz. 21 Lb. 10 Oz. 21 Lb. 10 Oz. 21 Lb. 10 Oz.	VSF-7403 VSF-7403 VSF-7403 VSF-7404 VSF-7403		VSF-7403S VSF-7403S VSF-7403S VSF-7403S VSF-7403S



Internal Wiring Diagram

Tech. Data





ALX SERIES

ALTERNATOR


ISSUED:10-19-79 (Rev.)

ORIG.EQUIP.ALTERNATOR	SERVICE ALTERNAT	OR VOLTS-12
ENG. NUMBER	ENG. NUMBER	APPLICATION
ALX-6408 USI ALX-6423 ALX-8403 USI ALX-8403G USI ALX-8403LS USI	ALX-6423 ALX-8421R ALX-8421R	Teledyne Continental Teledyne Continental Lycoming Lycoming Lycoming
ALX-8403LSG USF ALX-8403R USF ALX-8403RG USF ALX-8403RS USF ALX-8403RS USF	ALX-8421R ALX-8421R ALX-8421RS	Lycoming Service Service Service Service
ALX-8421 USE ALX-8421G USE ALX-8421LS USE ALX-8421LSG USE ALX-8421R	ALX-8421R I ALX-8421RS I ALX-8421RS I	Lycoming Lycoming Lycoming Lycoming Service
ALX-8421RG USE ALX-8421RS ALX-8421RSG USE ALX-9402 USE ALX-9404L USE	ALX-8421RS ALX-8421RS ALX-9425B	Service Service Service Feledyne Continental _ycoming
ALX-9404LGUSEALX-9404RUSEALX-9404RGUSEALX-9405USEALX-9422LUSE	ALX-9422R S ALX-9422R S ALX-9424 7	_ycoming Service Service Feledyne Continental _ycoming
ALX-9422LG USE ALX-9422R ALX-9422RG USE ALX-9424 ALX-9425 USE	ALX-9422R S ALX-9422R S ALX-9424 T	ycoming Service Service Feledyne Continental Feledyne Continental
ALX-9425A USE ALX-9425B		Feledyne Continental Feledyne Continental



File in the OE-A1 AIRCRAFT MANUAL

ALTERNATOR SECTION



2

ALX-6423 AL ALX-8403,R 9 ALX-8403G,RG 1 ALX-8403LS,RS 1 ALX-8403LS,RS 1 ALX-8403LS,RS 1 ALX-8403LS,RS 1 ALX-8403RSG 1 ALX-8403RSG 1 ALX-8421,R AL ALX-8421G,RG 1 ALX-8421LS,RS 1 ALX-8421RSG 1 ALX-9402 1 ALX-9404L,R 1 ALX-9404L,R 1 ALX-9405 1 ALX-9405 1 ALX-9422L,R AL	() 90-2399[e] LH-2128S-1 90-2399[e] " " " " LH-2128S-1 " "	2 ALE-1013AS " [c] [c] [c] [c] [c] ALE-1013AS "	(3) ALU-1045BS " ALU-1045BS[c] " " " ALU-1045BS	(4) * 90-2399[e] ALK-1132AS-1 90-2399[e] " "	5 90-2014[a] " " " "	6 ALE-1003R " ALE-1003K " "	(7) X-3416 " "
ALX-6423 AL ALX-8403,R 9 ALX-8403G,RG 9 ALX-8403LS,RS 9 ALX-8403LS,RS 9 ALX-8403LS,RS 9 ALX-8403LS,RS 9 ALX-8403RSG 9 ALX-8421,R AL ALX-8421G,RG 9 ALX-8421LS,RS 9 ALX-8421RSG 9 ALX-9402 9 ALX-9404L,R 9 ALX-9405 9 ALX-9422L,R AL ALX-9422L,R AL	LH-2128S-1 90-2399[e] " " LH-2128S-1 " "	" [c] [c] [c] [c] ALE-1013AS "	" ALU-1045BS[c] " " " ALU-1045BS	ALK-1132AS-1 90-2399[e] " "	11 11 11 11 11	" ALE-1003K "	0 0
ALX-8403,R ALX-8403G,RG ALX-8403LS,RS ALX-8403LSG ALX-8403RSG ALX-8403RSG ALX-8421,R ALX-8421G,RG ALX-8421LS,RS ALX-8421LSG ALX-8421RSG ALX-9402 ALX-9404L,R ALX-9404L,R ALX-9404L,R ALX-9405 ALX-9422L,R ALX-9422L,R ALX-9422L,R	90-2399[e] " " " " " LH-2128S-1 " "	[c] [c] [c] [c] [c] ALE-1013AS	ALU-1045BS[c] " " " ALU-1045BS	90-2399[e] " "	0 11 11 11	ALE-1003K "	11
ALX-8403G,RG ALX-8403LS,RS ALX-8403LSG ALX-8403RSG ALX-8421,R ALX-8421G,RG ALX-8421LS,RS ALX-8421LSG ALX-8421RSG ALX-9404L,R ALX-9404L,R ALX-9405 ALX-9422L,R ALX-9422L,R ALX-9422L,R	" " "LH-2128S-1 " "	[c] [c] [c] [c] ALE-1013AS	" " ALU-1045BS	 	11 11 11	U	н
ALX-8403LS,RS ALX-8403LSG ALX-8403RSG ALX-8403RSG ALX-8421,R ALX-8421G,RG ALX-8421LS,RS ALX-8421LSG ALX-9402 ALX-9404L,R ALX-9404L,R ALX-9405 ALX-9405 ALX-9422L,R ALX-9422L,R	" " ILH-2128S-1 " "	[c] [c] [c] ALE-1013AS "	" " ALU-1045BS	11	II H	n	
ALX-8403LSG ALX-8403RSG ALX-8403RSG ALX-8421,R AL ALX-8421G,RG ALX-8421LS,RS ALX-8421RSG ALX-9402 S ALX-9404L,R S ALX-9404LG,RG ALX-9405 S ALX-9422L,R AL	" LH-2128S-1 ' '	[c] [c] ALE-1013AS "	" ALU-1045BS	n	и		14
ALX-8403RSG ALX-8421,R AL ALX-8421G,RG ALX-8421LS,RS ALX-8421LSG ALX-9402 G ALX-9404L,R G ALX-9404LG,RG ALX-9405 AL ALX-9422L,R AL	" LH-2128S-1 " "	[c] ALE-1013AS "	" ALU-1045BS				
ALX-8421,R AL ALX-8421G,RG ALX-8421LS,RS ALX-8421LSG ALX-8421RSG ALX-9402 S ALX-9404L,R S ALX-9404LG,RG ALX-9405 ALX-9405 ALX-9422L,R AL	LH-2128S-1 " "	ALE-1013AS "	ALU-1045BS	н	1		11
ALX-8421G,RG ALX-8421LS,RS ALX-8421LSG ALX-8421RSG ALX-9402 ALX-9404L,R ALX-9404LG,RG ALX-9405 ALX-9422L,R ALX-9422L,R	и и п	н		1	11	11	u
ALX-8421LS,RS ALX-8421LSG ALX-8421RSG ALX-9402 5 ALX-9404L,R ALX-9404LG,RG ALX-9405 ALX-9422L,R AI ALX-9422LG,RG	n n			ALK-1132AS-1	н	u	u
ALX-8421LSG ALX-8421RSG ALX-9402 S ALX-9404L,R S ALX-9404LG.RG ALX-9405 S ALX-9422L,R AI ALX-9422LG.RG	н	0	н	n	н	н	н
ALX-8421RSG ALX-9402 S ALX-9404L,R S ALX-9404LG,RG ALX-9405 S ALX-9422L,R AI ALX-9422LG,RG			н	Ш	ii	H .	11
ALX-9402 S ALX-9404L,R S ALX-9404LG,RG ALX-9405 S ALX-9422L,R AI ALX-9422LG,RG	11	н	11	n	4F	н	u
ALX-9404L,R ALX-9404LG,RG ALX-9405 ALX-9422L,R ALX-9422LG,RG		н	n	п	н	"	u
ALX-9404LG,RG ALX-9405 ALX-9422L,R AI ALX-9422LG,RG	90-2409[e]	n	н	90-2409[e]	u	ALU-1003	11
ALX-9405 ALX-9422L,R AI ALX-9422LG,RG	90-2400[e]	[c]	ALU-1045BS[c]	90-2400[e]	n	ALU-1043[d]	X-4087
ALX-9422L,R AI ALX-9422LG,RG	н	[c]	11	n	88	11	н
ALX-9422LG,RG	90-2401[e]	[c]		90-2401[e]	88	н	н
	ALH-21385-1	ALE-1013AS	ALU-1045BS	ALE-1142AAS-1	U	11	Ð
ALX-9424 AI	н	u	0	н	18	u	н
	ALX-2138S-1	11	u	11	н	u	0 <u>,</u>
ALX-9425 A	ALH-2206S-1[b]	н	н	и	н	ALU-1003	X-5398
ALX-9425A	u	н	н	н	н	n	н
ALX-9425B	IF	11	п	u	11	U	11
Holder Assy.	ng & Fan Assemb Captive Brush & Ing this design If Brushes or	ly. Spring Set a Earlier un Springs are	also individuall its must replace required. v available if r	y available for the Complete B required.	1 (1 5))		
	& Rotor Pkg. Co Components(See	mplete Packag Sheet #3 for	ge <u>must</u> be used Contents of Pkg	at time of firs g.)maybe replace	t repair. d thereafter.		

OE-A1 AIRCRAFT MANUAL

Printed in U.S.A.

ALX SERIES ALTERNATOR PARTS LIST

ALX-6408 ALE-2008A8 ALE-1054A XA-9443 90-2043 [MA] ALA-2005 GR-32 ALX-6423 " " " " N[M] "	Assembly	Stator Assembly 8	Pos.Rect. & Plate Assembly	Negative Rectifier (Pkg.of 3)	Term. Stud Package (11)	S.R.E. Cover	Thru Bolt Package (13)	D.E. Retainer (14)
ALX-6423"""[NA]"ALX-8403.R"""90-2030ALU-1062A""ALX-8403.G,RG"""""""ALX-8403.L,RS"""""""ALX-8403.L,RS"""""""ALX-8403.L,RS"""""""ALX-8403.R,G"""""""ALX-8403.R,G"""""""ALX-8421.R,R"""""""ALX-8421.S,RS"""""""ALX-8421.S,RS"""""""ALX-8421.S,RS"""""""ALX-8421.S,RS"""""""ALX-8421.S,RS"""""""ALX-8421.S,RS"""""""ALX-9422.R""""""""ALX-9404.L,R""""""""ALX-9425."""""""""ALX-9425.""""""""""ALX-9425.""""" <td< td=""><td>ALX-6408</td><td>ALE-2008AB</td><td>ALE-1054A</td><td>XA-944JS</td><td>90-2043</td><td></td><td>ALA-20GS</td><td>+<u>-</u></td></td<>	ALX-6408	ALE-2008AB	ALE-1054A	XA-944JS	90-2043		ALA-20GS	+ <u>-</u>
ALX-8403,R " " 90-2030 ALU-1062A " " ALX-84036,R6 "	ALX-6423	h		н	н	1		
ALX-8403LS,RS " <	ALX-8403,R	н		н	90-2030		aı	u
ALX-8403LSG " " " " " " " " " " ALX-8403LSG " " " " " " " " " ALX-8403RSG " " " " " " " " " ALX-8421RG " " " " " " " " ALX-8421LS,RS " " " " " " " " ALX-8421LSG " " " " " " " " ALX-8421RSG " " " " " " " " ALX-8421RSG " " " " " " " ALX-8421RSG " " " " " " ALX-9402 " " " " " " ALX-9402 " " " [NA] " " ALX-9404L,R " " " [NA] " " ALX-9404LG,RG " " " [NA] " " ALX-9405 " "	ALX-8403G,RG	н	н	14	н		It	u
ALX-8403RSG " <td< td=""><td>ALX-8403LS,RS</td><td></td><td></td><td>н</td><td>a</td><td>н</td><td>н</td><td>11</td></td<>	ALX-8403LS,RS			н	a	н	н	11
ALX-8421,R "	ALX-8403LSG			u		14		н
ALX-8421G,RG " <t< td=""><td>ALX-8403RSG</td><td>a</td><td>n</td><td>n</td><td>п</td><td>11</td><td>, 11</td><td>18</td></t<>	ALX-8403RSG	a	n	n	п	11	, 11	18
ALX-8421LS,RS " <	ALX-8421,R		u	н	11	н	н	и
ALX-9421LSG "	ALX-8421G,RG	н	n	n	н	11	н	п
ALX-8421RSG " <th< td=""><td>ALX-8421LS,RS</td><td>н</td><td>0</td><td>Ш</td><td>н</td><td>a</td><td>н</td><td>u</td></th<>	ALX-8421LS,RS	н	0	Ш	н	a	н	u
ALX-9402 " " 90-2043 ALX-1062S " " ALX-9404L,R " " " [NA] " " ALX-9405 " " " " [NA] " " ALX-9405 " " " " [NA] " " ALX-9422L,R " " " " [NA] " " ALX-9422G,RG " " " " [NA] " " ALX-9425 " " " " ALX-1062S " " ALX-9425A " " " " " " </td <td>ALX-8421LSG</td> <td>ш</td> <td>п</td> <td>п</td> <td>u</td> <td>н</td> <td>II</td> <td>43</td>	ALX-8421LSG	ш	п	п	u	н	II	43
ALX-9402 " " 90-2043 ALX-1062S " " ALX-9404L,R " " " [NA] " " ALX-9405 " " " " [NA] " " ALX-9405 " " " " [NA] " " ALX-9422L,R " " " " [NA] " " ALX-9422G,RG " " " " [NA] " " ALX-9425 " " " " ALX-1062S " " ALX-9425A " " " " " " </td <td>ALX-8421RSG</td> <td>н</td> <td>н</td> <td></td> <td>и</td> <td>н</td> <td>н</td> <td>11</td>	ALX-8421RSG	н	н		и	н	н	11
ALX-9404L,R " " " [NA] " " ALX-9404LG,RG " " " [NA] " " ALX-9404LG,RG " " " [NA] " " ALX-9405 " " " [NA] " " ALX-9405 " " " [NA] " " ALX-9422L,R " " " [NA] " " ALX-9422L,R " " " [NA] " " ALX-9422L,R " " " " [NA] " " ALX-9422L,R " " " " [NA] " " ALX-9422L,R " " " " [NA] " " ALX-9424 " " " " ALX-1062S " " " ALX-9425A " " " " " " " " ALX-9425B " " " "	ALX-9402	н	н	U .	90-2043	ALX-1062S	ti	u
ALX-9404LG,RG " " [NA] " " ALX-9405 " " " [NA] " " ALX-9405 " " " [NA] " " ALX-9405 " " " [NA] " " ALX-9422L,R " " " [NA] " " ALX-9422L,R " " " [NA] " " ALX-9422L,R " " " " [NA] " " ALX-9422L,R " " " " [NA] " " ALX-9422L,R " " " " [NA] " " ALX-9425,R " " " " [NA] " " ALX-9425 " " " " ALX-1062S " " ALX-9425B " " " " " " " "	ALX-9404L,R	10	11	41		-	u	u
ALX-9405 " " [NA] " " ALX-9422L,R " " " [NA] " " ALX-9422L,RG " " " [NA] " " ALX-9424 " " " [NA] " " ALX-9425 " " " " ALX-1062S " " ALX-9425A " " " " " " " ALX-9425B " " " " " " "	ALX- 9404 LG,RG	n	u	u	н		н	н
ALX-9422L,R " " " [NA] " " ALX-9422LG,RG " " " [NA] " " ALX-9424 " " " [NA] " " ALX-9425 " " " [NA] " " ALX-9425A " " " ALX-1062S " " ALX-9425B " " " " " " "	ALX-9405	II	u	п	и		n	Ш
ALX-9422LG,RG " " " IN	ALX-9422L,R	11	tt.		п		n	u
ALX-9424 " " " [NA] " [NA] " " ALX-9425 " " " ALX-1062S " " " ALX-9425A " " " " " ALX-1062S " " "	ALX-9422LG,RG	н	i ii	4	11		u	и
ALX-9425 " ' ' ALX-1062S " " ALX-9425A " ' ' ' ' ALX-1062S " " " ALX-9425B ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '	ALX-9424	11	16	н	н		н	П
ALX-9425A " " " " " " " " " " "		н	п		н		11	0
ALX-9425B " " " "	ALX-9425A	н	11	н	n		14	Ш
	ALX-9425B	11	н	n	н	н		

Accombly	"O" Ring	Eyelet Package	Nut Washe		Rotor Shaft	Vent Fan	Drive Pulley	Regulator
Assembly	Seal		Packag	je 🛛	Spacer			(21)
	15	(16)	(17	<u> </u>	(18)	(19)	(20)	
LX-6408	[NA]	90818	90-33		ALC-21F	90-2259[f]	[NA]	VSF-7203S
LX-6423	[NA]	u	11		п	н	[NA]	61
LX-8403,R	[NA]	0	н		ALD-21	90-2241[f]	PU-672A	11
LX-8403G,RG	[NA]		н		н	п	n	FVR-4011A
LX-8403LS,RS	[NA]		n		u	u	[NA]	VSF-7203S
LX-8403LSG	[NA]	11	u		H	u	[NA]	FVR-4011A
\LX-9403RSG	[NA]	11	n		"	μ	[NA]	u
LX-8421,R	[NA]	u	H		н	н	PU-672A	VSF-7203S
\LX-8421G,RG	[NA]	u	и		0	u	II .	FVR-4011A
LX-8421LS,RS	[NA]	н	u		н	11	[NA]	VSF-7203S
ALX-8421LSG	[NA]	н	и		н	11	[NA]	FVR-4011A
\LX-8421RSG	[NA]	n	н			н	[NA]	
ALX-9402	[NA]	n	[NA]		[NA]	ALP-1034[g]	[NA]	VSF-7204
ALX-9404L,R	XA-744AZ	n	8X-407	5[h]	ALU-23	[NA]	[NA]	VSF-7203S
ALX-9404LG,RG	н	H	11		п	[NA]	[NA]	FVR-4011A
ALX-9405	н	n	н		н	ALP-1034[g]	[NA]	VSF-7203S
ALX-9422L,R	n	н	0		п	[NA]	[NA]	
ALX-9422LG,RG	u	и	U U		н	[NA]	[NA]	FVR-4011A
ALX-9424	u	n			H	ALP-1034[g]	[NA]	VSF-72035
ALX-9425	[NA]	u	[NA]		[NA]	н	[NA]	и
ALX-9425A	[NA]	н	[NA]		[NA]		[NA]	н
ALX-9425B	[NA]	u	[NA]		[NA]	11	[NA]	11
		3						
[e] <u>Contents c</u>	f S.R.E. Head	& Rotor Pkg.	· 			-1		_
S. R. E.Head	& Rotor Pkg.	90-2399		90-240	D	90-2401	90-2409	
Bearing Pk	.g.	90-2014		90-2014	4	90-2014	90-2014	
Head Assy.	,S.R.E.	ALK-1132AS-	1	ALE-114	2AAS-1	ALE-1142AAS-1	ALE-1142AAS-1	
Rotor		ALH-21285-1		ALH-213	85-1	ALX-21385-1	ALH-2206S-1	
10201		1	- 1	I				
			-					

[NA] Not Available. [f] Two(2) Piece Fan Assy. [g] Also included with Rotor. [h] Nut only; Washer not required.





ALTERNATOR DESCRIPTION

RATED VOLTAGE 12

RATED OUTPUT 70 Amperes

ROTATION Bi-Directional

GROUNDED POLARITY Negative

APPROXIMATE WEIGHT See Tabulation

SERVICE INFORMATION

Detailed service procedures covering disassembly, component testing, component replacement, assembly and bench testing are contained in the service publications in the front of the Alternator Section. Refer to the following service publication when detailed service information is required.

ALTERNATOR SERIES	SERVICE PUBLICATION
ALX 6400 - 8400	L-655A
ALX 9400	L-663

SERVICE BULLETINS

Refer to the Service Bulletin Section of this manual for bulletins pertaining to the ALX series alternators.

SERVICE SPECIFICATIONS

DRIVE PULLEY

Torque the drive pulley retaining nut to 35 Ft. Lbs. minimum to 40 Ft. Lbs. maximum.

ROTOR OHMMETER TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Ohmmeter must be accurate and batteries must be fresh. Frequently check ohmmeter accuracy by measuring a known resistance such as 10.0 ohm resistor.
- 3. Ohmmeter must be checked to zero before and after rotor test.
- 4. Slip rings and ohmmeter test probes must be clean. Ohmmeter test probe leads must be in good condition.

ROTOR OHMMETER TEST SPECIFICATION

Rotor winding resistance - 3.5 to 5.0 ohms.



AI X

AIRCRAFT ALTERNATORS

Issued: 4/1/83

Page 2 of 4

ROTOR CURRENT DRAW TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Voltmeter and ammeter must be accurate.
- 3. Refer to service publication for test wiring diagram.

ROTOR CURRENT DRAW TEST SPECIFICATION

Current draw at 12.0 volts - 2.4 to 4.0 amperes.

SLIP RING REFINISHING

Minimum Diameter1.350"Total Indicator Runout.002" max. measure from bearing journalsSurface Finish50 microinch max.

prestolite.

SERVICE

INFORMATION

ALTERNATOR OUTPUT TEST CONDITIONS

- 1. Alternator to be room temperature 70° to 80° F. before beginning test.
- 2. Alternator connected so it is supplying its own field current. Refer to service publication for bench test wiring diagram.
- 3. Output voltage to be controlled by an adjustable load.
- 4. Alternator not to be run more than 2 minutes for each test point.

VENTILATION

The 8400 series alternators use a slip ring end cover that has a hose type connection for air pressure ventilation. Remove this cover when bench testing the alternator.

The 9400 series alternators are cooled entirely by air pressure through a hose type connection on the drive end head. When bench testing this type of alternator, make output tests as short as possible unless adequate air pressure for cooling is supplied.

ALTERNATOR OUTPUT TEST SPECIFICATIONS (Without Regulator)

Alternator	Output	Output	Minimum
Series	Voltage	Amperage	Alternator RPM
ALX 6400-8400	14.0	33.0	3000
and 9400	14.0	57.0	6000

restolite.... ALX AIRCRAFT ALTERNATORS

INFORMATION

SERVICE

Issued: 4/1/83

Page 3 of 4

Alternator	Approx. Weight	Orig. Equip. Regulator	Replacement Regulator
ALX 6406	11 Lb. 12 Oz.	VSF-7203S or VSF-7204	VSF-7203S
ALX 6408	11 Lb. 12 Oz.	VSF-7204	VSF-7203S
ALX 6423	11 Lb. 12 Oz.	VSF-7204	VSF-7203S
ALX 8403, LS, R, RS	12 Lb. 2 Oz.	VSF-7201 or VSF-7203	VSF-7203S
*ALX 8403G, LSG, RG, RSG	12 Lb. 2 Oz.	FVR-4004+	FVR-4011+
ALX 8421, LS, R, RS	12 Lb. 2 Oz.	VSF-7201 or VSF-7203	VSF-7203S
*ALX 8421G, LSG, RG, RSG	12 Lb. 2 Oz.	FVR-4004+	FVR-4011+
ALX 9402	11 Lb. 6 Oz.	VSF-7204	VSF-7203S
ALX 9404L, R	11 Lb. 6 Oz.	VSF-7201 or VSF-7203	VSF-7203S
*ALX 9404LG, RG	11 Lb. 6 Oz.	FVR-4004+	FVR-4011+
ALX 9405	11 Lb. 6 Oz.	VSF-7203 or VSF-7204	VSF-7203S
ALX 9422L, R	11 Lb. 6 Oz.	VSF-7203	VSF-7203S
*ALX 9422LG, RG	11 Lb. 6 Oz.	FVR-4004+	FVR-4011+
ALX 9424	11 Lb. 6 Oz.	VSF-7204	VSF-7203S
ALX 9425, A, B	11 Lb. 6 Oz.	VSF-7204	VSF-7203S

Internal wiring same as shown. Field terminal F-2 externally * grounded with a strap connector. Lycoming applications only.


Wico - Prestolite part number. +




ALX AIRCRAFT ALTERNATORS Issued: 4/1/83

Page 4 of 4









ALY-6403 TO 6427RG

ALTERNATOR


ISSUED: 3-3-75(Rev.)

0	RIG.EQUIP.ALTERNA	TOR	SERVICE ALTERNATOR	VOLTS-12	
	ENG. <u>NUMBER</u>		ENG. NUMBER	APPLICATION	
	ALY-6403	USE	ALY-6420R	Lycoming	
	ALY-6403G	USE	ALY-6420R	Lycoming	
	ALY-6403R	USE	ALY-6420R	Service	
	ALY-6403RG	USE	ALY-6420R	Service	
	ALY-6406	USE	ALY-6406R	Lycoming	
	ALY-6406G	USE	ALY-6406R	Lycoming	
	ALY-6406R		ALY-6406R	Service	
	ALY-6406RG	USE	ALY-6406R	Service	
	ALY-6408	USE	ALY-6421	Piper	
	ALY-6409	USE	ALY-6422	Piper	
	ALY-6412	USE	ALY-6425	Teledyne Continental	
	ALY-6420	USE	ALY-6420R	Lycoming	
	ALY-6420G	USE	ALY-6420R	Lycoming	
	ALY-6420R		ALY-6420R	Service	
	ALY-6420RG	USE	ALY-6420R	Service	
	ALY-6421		ALY-6421	Piper	
	ALY-6422		ALY-6422	Piper	
	ALY-6425		ALY-6425	Teledyne Continental	
	ALY-6427	USE	ALY-6427R	Lycoming	
	ALY-6427G	USE	ALY-6427R	Lycoming	
	ALY-6427R		ALY-6427R	Service	
	ALY-6427RG	USE	ALY-6427R	Service	



File in the OE-A1 AIRCRAFT MANUAL

ALTERNATOR SECTION



Assembly	Rotor Assembly	Brush Set	Br.,Holder & Spring Assembly (3)	Slip Ring End Head Assembly 4 *	S.R.E. Bearing & Seal Pkg.	Drive End Head Assembly 6	D.E. Bearing 7
				00.0306[0]	90-2014[a]	ALE-1003K	X-3416
ALY-6403,R	90-2396[c]	ALE-1013AS	ALU-1045BS	90-2396[c] "	90-2014[A]	ALE-TOUSK	N=3410
ALY-6403G,RG	ii H					16	
ALY-6406,R	11	[b]	ALU-1045BS[b]		11	11	
ALY-6406G,RG		[b]		0		41	ы
ALY-6408	"	[b]	ALE-1045BS[b]			и	
ALY-6409	90-2402[c]	[b]		90-2402[c]	н	ALE-1003R	
ALY-6412	90-2396[c]	[b]	ALU-1045BS[b]	90-2396[c]	1		п
ALY-6420,R	ALE-2173S-1	ALE-1013AS	ALU-1045BS	ALK-1132BS-1		ALE-1003K	н
ALY-6420G,RG	0	U U					u
ALY-6421	n		ALE-1045BS		1		
ALY-6422	ALE-2177S-1	u	u				
ALY-6425	ALE-2173S-1	n	ALU-1045BS	u u		ALE-1003R	
ALY-6427,R	86	11	83	11	. u	ALE-1003K	
[b] ALE-1013 units al Complete [c] S.R.E.He first re	AS Captive Brus ready having th Brush Holder A	h & Spring Set is design. Ear ssy. if Brushe complete Pack 1 Components(S) Also available h Rotor & S.R.E. also individual lier units must so r Springs are age <u>must</u> be used see Sheet #3 for	replace the required.			



Ś

ALY-6403 TO 6427RG ALTERNATOR PARTS LIST

Assembly	Stator Assembly 8	Pos.Rect. & Plate Assembly 9	Negative Rectifier (Pkg.of 3)	Terminal Stud Package	D.E. Retainer 12	Thru Bolt Package	Eyelet Package
ALY-6403,R	ALE-2008AE	ALE-1054A	XA-944JS	90-2030	GR-32	ALA-20JS	90-818
ALY-6403G,RG	Ð	0	11	n	и	н	
ALY-6406,R	н		II	u	u	i ii	н
ALY-6406G,RG	н	н	u	10		11	"
ALY-6408		н	и	90-2043	11	н	0
ALY-6409	0	u		11	U	u	41
ALY-6412	H	u	61	11	u	u	н
ALY-6420,R	н			90-2030	H	u	
ALY-6420G,RG	"	11	u	н	11	I	
ALY-6421	"	41	n	90-2043	п		н
ALY-6422	u		n	Ш.,	н	i n	
ALY-6425	n	II	11	31	н	н	
ALY-6427,R	u	н	U	90-2030	н		u
ALY-6427G,RG	u	и	- 41	61	н	'n	11

N

ALY-6403 TO 6427RG ALTERNATOR PARTS LIST

ISSUED: 11-6-79(Rev.) S

	IF	F	3
J	IL.		~

Ľ,

Assembly	S.R.E. Cover	Nut & Nut & Washer	Rotor Shaft	Vent. Fan (2 Pc.)	Drive Pulley	Regulator	
	(15)	Package	Spacer	(2 Pc.)	(19)	(20)	
			† <u>-</u>				<u></u>
ALY-6403,R	[NA]	90-33	ALD-21	90-2241	PU-672A	VSF-7203S	
ALY-6403G,RG	[NA]	11		11	n	FVR-4011A	
ALY-6406,R	[NA]	n	61	11	PU-676A	VSF-7203S	
ALY-6406G,RG	[NA]	11	и	63	0	FVR-4011A	
ALY-6408	[NA]	n		"	PU-672A	FVR-4024	
ALY-6409	[NA]	U N	ALD-21A	11	PU-692A	FVR-4324	
ALY-6412	[NA]	11	ALC-21F	90-2259	[NA]	VSF-7203S	
ALY-6420,R	[NA]	11	ALD-21	90-2241	PU-672A	VSF-7203S	
ALY-6420G,RG	[NA]	H	II	н	u	FVR-4011A	
ALY-6421	[NA]	U	u	a	u	FVR-4024	
ALY-6422	[NA]	11	ALD-21A	11	PU-692A	FVR-4324	
ALY-6425	[NA]	н	ALC-21F	902259	[NA]	VSF-7203S	
ALY-6427,R	[NA]	11	ALD-21	90-2241	PU-676A	VSF-7203S	
ALY-6427G,RG	[NA]	11	u			FVR-4011A	
[c] <u>Conten</u>	ts of S.R.E. He	ı ad & Rotor Pkg.	I		1	1 1	
S.R.E	.Head & Rotor P	kg. 90-239	90 90	-2402			
Beat	ring Pkg.	90-201	4 90	-2014			
Hea	d Assy.,S.R.E.	ALK-113	32BS-1 ALK	-1132BS-1			
Rot	or	ALE-217	3S-1 ALE	-21775-1			
[NA] Not Av	ailable.						
		File in the			r	RNATOR SECT	

OE-A1 AIRCRAFT MANUAL



ALY-8402 TO 8426RG

ALTERNATOR


ISSUED: 3-3-75(Rev.)

ORIG. EQUIP. ALTERNATOR		SERVICE ALTERN	ATOR	VOLTS-12
ENG.		ENG.	100	Land Million
NUMBER		NUMBER	A	PPLICATION
ALY-8402	USE	ALY-8411	Teledvne	Continental
ALY-8403	USE	ALY-8420R	Lycoming	
ALY-8403G	USE	ALY-8420R	Lycoming	
ALY-8403LS	USE	ALY-8403RS	Lycoming	
ALY-8403LSG	USE	ALY-8403RS	Lycoming	
AE1-8403230	USL	AL1-0403K3	Lycolining	
ALY-8403R	USE	ALY-8420R	Service	
ALY-8403RG	USE	ALY-8420R	Service	
ALY-8403RS		ALY-8403RS	Service	
ALY-8403RSG	USE	ALY-8403RS	Service	
ALY-8405	USE	ALY-8426R	Lycoming	
121 0400	UUL	ALT-OTLON	Lycoming	
ALY-8405G	USE	ALY-8426R	Lycoming	
ALY-8405R	USE	ALY-8426R	Service	
ALY-8405RG	USE	ALY-8426R	Service	
ALY-8410	USE	ALY-8423R	Lycoming	
ALY-8410R	USE	ALY-8423R	Service	
ALT-04TON	USL	AL1-0423K	Service	
ALY-8411		ALY-8411	Teledyne	Continental
ALY-8420	USE	ALY-8420R		Continental
ALY-8420G	USE	ALY-8420R	Lycoming	
ALY-8420LS	USE	ALY-8420RS	Lycoming	
ALY-8420LSG	USE	ALY-8420RS	Lycoming	
HET OTEOEDU	UUL	HET OFEORD	Lycoming	
ALY-8420R		ALY-8420R	Service	
ALY-8420RG	USE	ALY-8420R	Service	
ALY-8420RS		ALY-8420RS	Service	
ALY-8420RSG	USE	ALY-8420RS	Service	
ALY-8423	USE	ALY-8423R	Lycoming	
			Lycoming	
ALY-8423R		ALY-8423R	Service	
ALY-8424		ALY-8424		Continental
ALY-8426	USE	ALY-8426R	Lycoming	obli officitua i
ALY-8426G	USE	ALY-8426R	Lycoming	
ALY-8426R	001	ALY-8426R	Service	
The offering		HET OTEON	Service	
ALY-8426RG	USE	ALY-8426R	Service	



File in the OE-A1 AIRCRAFT MANUAL

ALTERNATOR SECTION



TO OUCCOC ALTERNATOR DARTE LICT

ISSUED + 11 - 6 - 79(REV)

SHEET 2

ALY-8402 TO	8426RG ALTE	RNATOR PARTS	LIST			-6-79(Rev.)	SHEET 2
Assembly	Rotor Assembly	Brush Set	Br.,Holder & Spring Ass <u>e</u> mbly	- Slip Ring End Head Assembly	S.R.E. Bearing & Seal Pkg.	Drive End Head Assembly	D.E. Bearing
		2	3	4 *	5	6	
ALY-8402	90-2396[c]	[b]	ALU-1045BS[b]	90-2396[c]	90-2014[a]	ALE-1003K	X-3416
ALY-8403,R	н	[b]	11	u	н	u	н
ALY-8403G,RG	н	[b]	п	18	U	u	
ALY-8403LS,RS	11	[b]	н	11	11	41	u
ALY-8403LSG	н	[b]	u	н	н	51	n
ALY-8403RSG	0	[b]	и	п	н	н	н
ALY-8405,R	11	[b]	11	н	н		41
ALY-8405G,RG	п	[b]	11	н	R	и .	ÅP.
ALY-8410,R	н	[b]	ALE-1045BS[b]	H	0		п
ALY-8411	н	[b]	ALU-1045BS	U	u		н
ALY-8420,R	ALE-2173S-1	ALE-1013AS	н	ALK-1132BS-1	н		ш
ALY-8420G,RG	Ü	н	ii -	н	н	11	u
ALY-8420LS,RS	н	u	u	u	11	u	11
ALY-8420LSG	11	u	11	н	н	н	п
ALY-8420RSG	н	п	н	15	11	п	
ALY-8423,R	11	11	ALE-1045BS	0	14	и	н
ALY-8424	n	. 11	ALU-1045BS	н	и	н	
ALY-8426,R	11	11	u	н	н	U U	U U
ALY-8426G,RG	Ш	н	u	11	н	II.	
[*] 35-781 ([a] Bearing	AS Cantive Bru	sh & Spring Set) Also ayailable h Rotor & S.R.E. also individual lier units must	ly available for			

File in the **OE-A1 AIRCRAFT MANUAL**



ALY-8402 TO 8426RG ALTERNATOR PARTS

Assembly	Stator Assembly	Pos.Rect. & Plate Assembly	Negative Rectifier (Pkg.of3)	Terminal Stud Package	D.E. Retainer	Thru Bolt Package	Eyelet Package
	8	(9)			(12)	13	(14)
ALY-8402	ALE-2008AE	ALE-1054A	XA-944JS	90-2043	GR-32	ALA-20JS	90-818
ALY-8403,R		п	н	90-2030	n	n n	u
ALY-8403G,RG	н		u		u	16	u
ALY-8403LS,RS	н		н	u	n	U U	, u
ALY-8403LSG	u	; n	u u	н	н	18	н
ALY-8403RSG			II	a		u	u
ALY-8405,R				u	u		н
ALY-8405G,RG		u	u	н	U	u	41
ALY-8410,R	н		it it	11	н	u	п
ALY-8411	n	n	li li	90-2043	11	н	u
ALY-8420,R	н	п	и .	90-2030	u	u	u
ALY-8420G,RG	u			n	18	11	14
ALY-8420LS,RS	n	a		u		u	8
ALY-8420LSG	u	n	n	н	u	lt.	11
ALY~8420RSG	II .	μ	i n	n	n .	11	н
ALY-8423,R	н	н		u	u u	, u	. u
ALY-8424	н	u	£1	90-2043	u	n	
ALY-8426,R	n	n	n	90-2030	n	0	, n
ALY-8426G,RG	IF	u	н		u	u	u
					-		
			, 				
						1	{

ALY-8402 TO 8426RG ALTERNATOR PARTS LIST

ISSUED: 11-6-79(Rev.) SHEET 3

Assembly	S.R.E. Cover	Nut & Washer	Rotor Shaft	Vent. Fan	Drive Pulley	Regualtor		
	15	Package	Spacer	(2 Pc.)	(19)	20		
ALY-8402	ALU-1062	90-33	ALC-21F	90-2259	[NA]	VSF-7203S		
ALY-8403,R	ALU-1062A	-	ALD-21	90-2241	PU-672A	VSF-7203S		
ALY-8403G,RG	a		u	н	u .	FVR-4011A		
ALY-8403LS,RS	II		"	н	[NA]	VSF-7203S		
ALY-8403LSG	15	u	u	u	[NA]	FVR-4011A		
ALY-8403RSG	u	11	0	u	[NA]	u		
ALY-8405,R	ALU-1062D	a		H	PU-672A	VSF-7203S		
ALY-8405G,RG	11	a	"	н	"	FVR-4011A		
ALY-8410,R	ALU-1062A	п	11		41	FVR-4324		
ALY-8411	ALU-1062	11	ALC-21F	90-2259	[NA]	VSF-7203S		
ALY-8420,R	ALU-1062A	ıı	ALD-21	90-2241	PU-672A	VSF-7203S		
ALY-8420G,RG	0	u	H	0	u	FVR-4011A		
ALY-8420LS,RS	u	u	u	u	[NA]	VSF-7203S		
ALY-8420LSG	H	н	u	12	[NA]	FVR-4011A		
ALY-8420RSG	11	89			[NA]	U		
ALY-8423,R	a	łł	н	u	PU-672A	FVR-4324		
ALY-8424	ALU-1062	u	ALC-21F	90-2259	[NA]	VSF-7203S		
ALY-8426,R	ALU-1062D	14	ALD-21	90-2241	PU-672A	VSF-7203S		
ALY-8426G,RG	н	u	ш	u		FVR-4011A		
	of S.R.E. Head							
	ad & Rotor Pkg.	90-239						
	ing Pkg.		90-2014					
	Assy.,S.R.E.	ALK-1132						
Roto [NA] Not Availa		ALE-2173	2-1					
Tend HAR UAULU								

File in the OE-A1 AIRCRAFT MANUAL





ALTERNATOR DESCRIPTION

RATED VOLTAGE 12

60 Amperes RATED OUTPUT

Bi-Directional ROTATION

GROUNDED POLARITY Negative

See Tabulation APPROXIMATE WEIGHT

SERVICE INFORMATION

Detailed service procedures covering disassembly, component testing, component replacement, assembly and bench testing are contained in the service publications in the front of the Alternator Section. Refer to the following service publication when detailed service information is required.

ALTERNATOR	SERVICE		
SERIES	PUBLICATION		
ALY 6400 - 8400	L-655A		

L-655A

SERVICE BULLETINS

Refer to the Service Bulletin Section of this manual for bulletins pertaining to the ALY series alternators.

SERVICE SPECIFICATIONS

DRIVE PULLEY

Torque the drive pulley retaining nut to 35 Ft. Lbs. minimum to 40 Ft. Lbs. maximum.

ROTOR OHMMETER TEST CONDITIONS

- Rotor to be room temperature 70° to 80° F. 1.
- 2. Ohmmeter must be accurate and batteries must be fresh. Frequently check ohmmeter accuracy by measuring a known resistance such as 10.0 ohm resistor.
- Ohmmeter must be checked to zero before and after rotor test. 3.
- 4. Slip rings and ohmmeter test probes must be clean. Ohmmeter test probe leads must be in good condition.

ROTOR OHMMETER TEST SPECIFICATION

File in the

Rotor winding resistance - 3.5 to 5.0 ohms.



ALY

AIRCRAFT ALTERNATORS

T 1 1/1/02

Issued: 4/1/83

Page 2 of 4

ROTOR CURRENT DRAW TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Voltmeter and ammeter must be accurate.
- 3. Refer to service publication for test wiring diagram.

ROTOR CURRENT DRAW TEST SPECIFICATION

Current draw at 12.0 volts - 2.4 to 4.0 amperes.

SLIP RING REFINISHING

Minimum Diameter	1.350"
Total Indicator Runout	.002" max. measure from bearing journals
Surface Finish	50 microinch max.

prestolite.

SERVICE

INFORMATION

ALTERNATOR OUTPUT TEST CONDITIONS

- 1. Alternator to be room temperature 70° to 80° F. before beginning test.
- 2. Alternator connected so it is supplying its own field current. Refer to service publication for bench test wiring diagram.
- 3. Output voltage to be controlled by an adjustable load.
- 4. Alternator not to be run more than 2 minutes for each test point.

VENTILATION

The 8400 series alternators use a slip ring end cover that has a hose type connection for air pressure ventilation. Remove this cover when bench testing the alternator.

ALTERNATOR OUTPUT TEST SPECIFICATIONS (Without Regulator)

Alternator	Output	Output	Minimum	
Series	Voltage	Amperage	Alternator RPM	
ALY 6400-8400	14.0	13.0	2000	
	14.0	47.0	4000	

ALY

Drestolite.___ SERVICE ____ INFORMATION ____

AIRCRAFT ALTERNATORS

Issued: 4/1/83

Page 3 of 4

Alternator	Approx. Weight	Internal Wiring	Orig. Equip. Regulator	Replacement Regulator
ALY 6403, R	10 Lb. 6 Oz.	Figure 1	VSF-7203	VSF-7203S
ALY 6403G, RG	10 Lb. 6 Oz.	Figure 1*	FVR-4004+	FVR-4011+
ALY 6406, R	10 Lb. 6 Oz.	Figure 1	VSF-7203	VSF-7203S
ALY 6406G, RG	10 Lb. 6 Oz.	Figure 1*	FVR-4004+	FVR-4011+
ALY 6408	10 Lb. 6 Oz.	Figure 2	X18150+	X18150+
ALY 6409	10 Lb. 6 Oz.	Figure 2	X16300B+	X16300B+
ALY 6412	10 Lb. 6 Oz.	Figure 1	VSF-7204	VSF-7203S
ALY 6420, R	10 Lb. 6 Oz.	Figure 1	VSF-7203	VSF-7203S
ALY 6420G, RG	10 Lb. 6 Oz.	Figure 1*	FVR-4004+	FVR-4011+
ALY 6421	10 Lb. 6 Oz.	Figure 2	X18150+	X18150+
ALY 6422	10 Lb. 6 Oz.	Figure 2	X16300B+	X16300B+
ALY 6425	10 Lb. 6 Oz.	Figure 1	VSF-7204	VSF-7203S
ALY 6427, R	10 Lb. 6 Oz.	Figure 1	VSF-7203	VSF-7203S
ALY 6427G, RG	10 Lb. 6 Oz.	Figure 1*	FVR-4004+	FVR-4011+
ALY 8402	10 Lb. 12 Oz.	Figure 1	VSF-7204	VSF-7203S
ALY 8403, LS,	10 Lb. 12 Oz.	Figure 1	VSF-7203	VSF-7203S
R, RS		Ū		
ALY 8403G, LSG,	10 Lb. 12 Oz.	Figure 1*	FVR-4004+	FVR-4011+
RG, RSG		•		
ALY 8405, R	10 Lb. 12 Oz.	Figure 1	VSF-7203	VSF-7203S
ALY 8405G, RG	10 Lb. 12 Oz.	Figure 1*	FVR-4004+	FVR-4011+
ALY 8410, R	10 Lb. 12 Oz.	Figure 2	X16300B+	X16300B+
ALY 8411	10 Lb. 12 Oz.	Figure 1	VSF-7204	VSF-7203S
ALY 8420, LS,	10 Lb. 12 Oz.	Figure 1	VSF-7203	VSF-7203S
R, RS		•		
ALY 8420G, LSG,	, 10 Lb. 12 Oz.	Figure 1*	FVR-4004+	FVR-4011+
RG, RSG		-		
ALY 8423, R	10 Lb. 12 Oz.	Figure 2	X16300B+	X16300B+
ALY 8424	10 Lb. 12 Oz.	Figure 1	VSF-7204	VSF-7203S
ALY 8426, R	10 Lb. 12 Oz.	Figure 1	VSF-7203	VSF-7203S
ALY 8426G, RG	10 Lb. 12 Oz.	Figure 1*	FVR-4004+	FVR-4011+


* Same as Figure 1 except field terminal F-2 externally grounded with a strap connector. Lycoming applications only.

+ Wico - Prestolite part number.



ALY
AIRCRAFT ALTERNATORS
Issued: 4/1/83
Page 4 of 4










Figure 2




ALZ SERIES

ALTERNATOR


ISSUED: 3-4-75(Rev.)

ORIG.EQUIP.ALTERNA	TOR	SERVICE ALTER	VOLTS-12	
ENG. <u>NUMBER</u>		ENG. <u>NUMBER</u>	AP	PLICATION
ALZ-8401 ALZ-8401G ALZ-8401R ALZ-8401RG ALZ-8423	USE USE USE USE USE	ALZ-8423R ALZ-8423R ALZ-8423R ALZ-8423R ALZ-8423R ALZ-8423R	Lycomin Lycomin Service Service Lycomin	g
ALZ-8423G ALZ-8423R ALZ-8423RG	USE USE	ALZ-8423R ALZ-8423R ALZ-8423R	Lycomin Service Service	





ALTERNATOR SECTION




18

DANTO LICT

٠

ALT SERIES	ALTERNATOR	PARIS LIST			ISSUED: 3-		SHEET
Assembly	Rotor Assembly	Brush Set	Br.,Holder & Spring	Slip Ring End Head	S.R.E.Bearing & Seal	Drive End Head Ass <u>e</u> mbly	D.E. Bearing
·		2	Assembly	Assembly 4 *	Package	ASSEMDTY 6	
ALZ-8401	90-2396[c]		ALU-1045BS[a]	90-2396[c]	90-2014[b]	ALE-1003K	X-3416
ALZ-8401G			н	u	н	n	п
ALZ-8401R	н		n	Ш	п	u u	u
ALZ-8401RG	п		n	n	п	н	ų
ALZ-8423	ALE-2173S-1	ALE-1013AS	ALU-1045BS	ALK-1132BS-1		U U	н
ALZ-8423G		п		н	u	н	п
ALZ-8423R	п	и	61	н		ш	u
ALZ-8423RG	41	Ð	II	n	41	n	11
						,	
						!	
						1	
[*] 35-781 ([a] ALE-1013	GJC-49BS) Cove AS Captive Brus	r Pkg. (10 Pcs. sh & Spring Set) Also available also individual	ly available fo	r units Pruch		
already Holder A	having this des	sign. Earlier u s or Springs ar	e required.	e the complete	DT US11		
[b] Bearing	& Seal Pkg. als	so included wit	h Rotor & S.K.E. age must be used	at time of the	st repair.		
Individu	al components	(See Sheet #3 f	or contents of P	kg.)maybe repla	ced thereafter.		





ALZ SERIES ALTERNATOR PARTS LIST

Assembly	Stator Assembly 8	Pos.Rect. & Plate Assembly	Negative Rectifier (Pkg.of 3)	S.R.E. Cover	D.E. Retainer	Term. Stud Package	Thru Bolt Package
ALZ-8401	ALE-2008AG	ALE-1054A	XA-944JS	ALU-1062A	GR-32	90-2030	ALA-20JS
LZ-8401G	11	, п	n.	н	н	н	п
LZ-8401R	H	н	11	11		u	
LZ-8401RG	a	н	н	u	11	, n	п
LZ-8423	н	, u	П	н	11	11	11
LZ-8423G	0	11			u	U U	u
LZ-8423R	U	11		н	н	11	
LZ-8423RG	11	II	11		u	u	n
ł							
					-		

 δ

ALZ SERIES ALTERNATOR PARTS LIST

ISSUED: 3-5-79 (Rev.) SHEET 3

Assembly	Eyelet Package	Nut & Washer Package	Rotor Shaft Spacer (17)	Vent. Fan (2 Pc.) 18	Drive Pulley (19)	Regulator	
ALZ-8401	.90-818	90-33	ALD-21	90-2241	PU-672A	VSF-7203S	
ALZ-8401G	11	11	10	н		FVR-4011A	
ALZ-8401R		U	н	H	н	VSF-7203S	
ALZ-8401RG	11	ш	11	n	11	FVR-4011A	
ALZ-8423	н	u	11	н	11	VSF-7203S	
ALZ-8423G	н		u	11	н	FVR-401 1A	
ALZ-8423R		u	u	H	44	VSF-7203S	
ALZ-8423RG	H	16		n	H	FVR-401 1A	
[c] Contents	of S.R.E. Head	& Rotor Pkg.					
	& Rotor Pkg.	90-23 96					
	Bearing Pkg. Head Assy.,S.R.E.						
Head A			ALK-1132BS-1				
Rotor		ALE-21735-1					
<u> </u>		Eile in the			r		





ALTERNATOR DESCRIPTION

RATED VOLTAGE 12

RATED OUTPUT 50 Amperes

ROTATION Bi-Directional

GROUNDED POLARITY Negative

APPROXIMATE WEIGHT 10 Lb. 12 Oz.

SERVICE INFORMATION

Detailed service procedures covering disassembly, component testing, component replacement, assembly, and bench testing are contained in the service publications in the front of the Alternator Section. Refer to the following service publication when detailed service information is required.

ALTERNATOR	SERVICE
SERIES	PUBLICATION
ALZ 8400	L-655A

SERVICE BULLETINS

Refer to the Service Bulletin Section of this manual for bulletins pertaining to the ALZ series alternators.

SERVICE SPECIFICATIONS

DRIVE PULLEY

Torque the drive pulley retaining nut to 35 Ft. Lbs. minimum to 40 Ft. Lbs. maximum.

ROTOR OHMMETER TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Ohmmeter must be accurate and batteries must be fresh. Frequently check ohmmeter accuracy by measuring a known resistance such as 10.0 ohm resistor.
- 3. Ohmmeter must be checked to zero before and after rotor test.
- 4. Slip rings and ohmmeter test probes must be clean. Ohmmeter test probe leads must be in good condition.



ALZ

AIRCRAFT ALTERNATORS

Issued 4/1/83

Page 2 of 3

SERVICE

ROTOR OHMMETER TEST SPECIFICATION

Rotor winding resistance - 3.5 to 5.0 ohms.

ROTOR CURRENT DRAW TEST CONDITIONS

- 1. Rotor to be room temperature 70° to 80° F.
- 2. Voltmeter and ammeter must be accurate.
- 3. Refer to service publication for test wiring diagram.

ROTOR CURRENT DRAW TEST SPECIFICATION

Current draw at 12.0 volts - 2.4 to 4.0 amperes.

SLIP RING REFINISHING

Minimum Diameter1.350"Total Indicator Runout.002" max. measure from bearing journalsSurface Finish50 microinch max.

ALTERNATOR OUTPUT TEST CONDITIONS

- 1. Alternator to be room temperature 70° to 80° F. before beginning test.
- 2. Alternator connected so it is supplying its own field current. Referto service publication for bench test wiring diagram.
- 3. Output voltage to be controlled by an adjustable load.
- 4. Alternator not to be run more than 2 minutes for each test point.

VENTILATION


The 8400 series alternators use a slip ring end cover that has a hose type connection for air pressure ventilation. Remove this cover when bench testing the alternator.



ALTERNATOR OUTPUT TEST	SPECIFICATIONS	(Without Regu	lator)
Alternator Series	Output Voltage	Output Amperage	Minimum Alternator RPM
ALZ 8400	14.0 14.0	17.0 41.0	2000 4000
Alternator	Orig. Regulator	Equip.	Replacement Regulator
ALZ 8401, R	VSF-7203		VSF-7203S
*ALZ 8401G, RG	FVR-4004 ⁺		FVR-4011 ⁺
ALZ 8423, R	VSF-7203		VSF-7203S
*ALZ 8423G, RG	FVR-4004	+	FVR-4011 ⁺

* Internal wiring same as shown. Field terminal F-2 externally grounded with a strap connector. Lycoming applications only.

+ Wico - Prestolite part number.



Internal Wiring Diagram

Tech.


Data

prestolite.	VSF-7200	
	AIRCRAFT VOLTAGE REGULATOR	
SERVICE	Issued: 10-5-72	
INFORMATION	Page 1 of 1	

- VOLTS 12 GROUND POLARITY Negative
- ADJUSTMENT These units have an external adjustment located under the plastic plug on top of the regulator. The regulator has an adjustment spread ranging from 13.0 volts to 15.0 volts. Output is increased by turning the adjustment clockwise.
- OPERATING VOLTAGE The regulator should be adjusted to 14.2 volts when controlling a load of 10 to 15 amps after 1 minute operation. These units are not affected by ambient temperatures. The voltmeter must be connected from the "I" or ignition terminal to ground.

CAUTION NOTES 1. Use only with insulated (ungrounded) field alternators.

- 2. Regulator base must have a good ground connection.
- 3. Do not (even momentarily) connect the two voltage regulator terminals together.
- Do not connect battery into system with polarity reversed.
- 5. Do not force the voltage adjustment screw.
- 6. This is a sealed unit and not repairable. Replace with a new unit.



Typical Schematic Circuit of Regulator



File in the

OE-A1 AIRCRAFT MANUAL




VOLTS 24 GROUND POLARITY Negative

- ADJUSTMENT These units have an external adjustment located under the plastic plug on top of the regulator. The regulator has an adjustment spread ranging from 26.0 volts to 30.0 volts. Output is increased by turning the adjustment clockwise.
- OPERATING VOLTAGE The regulator should be adjusted to 28.4 volts when controlling a load of 10 to 15 amps after 1 minute operation. These units are not affected by ambient temperatures. The voltmeter must be connected from the "I" or ignition terminal to ground.

CAUTION NOTES 1. Use only with insulated (ungrounded) field alternators.

- 2. Regulator base must have a good ground connection.
- 3. Do not (even momentarily) connect the two voltage regulator terminals together.
- 4. Do not connect battery into system with polarity reversed.
- 5. Do not force the voltage adjustment screw.
- 6. This is a sealed unit and not repairable. Replace with a new unit.



Typical Schematic Circuit of Regulator

Unit VSF-7401 VSF-7402 VSF-7403,S VSF-7404

