



FIGURE 32. ALTERNATOR (OPTIONAL EQUIPMENT)

FIG. & INDEX	PART NUMBER	DESCRIPTION	QUANTITY PER ASSEMBLY			
			ALL MODELS			
32- 1	631111	Alternator	1			
- 2	631094	Fan, Alternator	1			
- 3	630985	Sheave, Alternator Driven	1			
- 4	631000	Bracket Assembly	1			
- 4	634673	Bracket, Engine Mount and Alternator	1			
- 5	630989	Shaft, Alternator Mount	1			
- 6	631200	Bracket Assembly, Alternator Support, Lower	1			
- 7	631202	Idler, Kiss	1			
- 8	632312	Bracket, Alternator Adjusting Arm, Upper	1			
- 9	628730	Screw, Bracket at Alternator	1			
-10	537539	Washer, Bracket at Alternator	1			
-11	630988	Bushing, Rubber, Lower Support	1			
-12	633062	Washer, Lower Support	2			
-13	2439	Nut, Plain	2			
-14	2560	Palnut	2			
-15	630519	Bushing, Rubber	2			
-16	627281	Bushing	1			
-17	501868	Washer, Tab	1			
-18	537750	Screw	1			
-19	627673-2	Idler, Kiss	1			
-20	22661	Nut, Elastic Stop	1			
-21	539547-31.19	Belt	1			

Optional for all O-470/10-470 Models.  
See Section VI for customer specification.