

Figure 38. Nose Landing Gear (D-4866 thru D-6561)

FIG. & INDEX NO.	PART NO.		DESCRIPTION							UNITS PER ASSY	USABLE ON CODE
			1	2	3	4	5	6	7		
38	35-825001	GEAR INSTL,NOSE LANDING	NP	1
	35-825001-10	GEAR INSTL,NOSE LANDING	NP	2
	35-825001-2	• GEAR ASSY,NOSE WHEEL	1	1
	35-825001-8	• GEAR ASSY,NOSE WHEEL	1	2
		/ATTACHING PARTS/									
- 1	□AN6-23A	• BOLT	2	
- 2	□35-825029	• BUSHING,NOSE GEAR ATTACHING	2	
	□AN960-616	• WASHER	4	
	□100951X032YP	• WASHER	2	
	□AN365-624	• NUT	2	
		-----*									
- 3	□35-825175	• • GUARD ASSY,NOSE WHEEL SCRAPER	1	3
		/ATTACHING PARTS/									
- 4	AN525-10-6	• • SCREW	1	
	□AN960-10L	• • WASHER	1	
	MS20364-1032	• • NUT	1	
- 5	□AN4-5A	• • BOLT	1	
	□AN960-416L	• • WASHER	1	
	AN365-428	• • NUT	1	
	□AN960-416	• • WASHER	1	
- 6	AN4H3A	• • BOLT	1	
		-----*									
	□35-825100-6	• • STRUT ASSY,NOSE WHEEL SHOCK	1	3
		/SUPERSEDES 35-825100/									
- 7	□35-825110-4	• • • BRACE ASSY,NOSE WHEEL TOP	1	3
- 8	□35-820111	• • • BEARING,NOSE WHEEL TOP BRACE	2	3
- 9	□35-825112	• • • BEARING,NOSE WHEEL BRACE	2	3
- 10	□105740X-ZU1365	• • • BUSHING	1	3
- 11	□35-820113	• • • BEARING,TOP BRACE RETRACT LUG	1	3
- 12	□105740X-YN1458	• • • BUSHING	1	3
- 13	□17288	• • • FITTING,LUBRICATION /SUPERSEDES 1645/	4	3
- 14	35-825090	• • • BARREL ASSY,NOSE WHEEL STRUT	1	1
	□35-825090-10	• • • BARREL ASSY,NOSE WHEEL STRUT	1	2
	□35-825125-602	• • • AXLE & PISTON ASSY,NOSE WHEEL STRUT	1	3
		/SPARE ASSY,SEE ADDENDUM/									
- 15	35-825125	• • • AXLE & PISTON ASSY,NOSE WHEEL STRUT	NP	3
- 16	□35-825115	• • • CLIP,NOSE WHEEL SCRAPER	1	3
		/ATTACHING PARTS/									
- 17	□AN4-20A	• • • BOLT	1	
	□AN960-416	• • • WASHER	1	
	AN365-428	• • • NUT	1	
		-----*									
	□35-825102-2	• • • CONTROL ASSY,NOSE WHEEL REBOUND	1	3
		/SUPERSEDES 35-825102/									
		/ATTACHING PARTS/									
- 19	□AN6227-5	• • • PACKING	1	
- 20	□AN960-416	• • • WASHER	1	
- 21	AN363-428	• • • NUT	1	
		-----*									
	35-825025-4	• • • ORIFICE ASSY,REBOUND CONTROL	1	3
	35-825030	• • • TUBE ASSY,REBOUND CONTROL	1	3
- 22	□35-825032	• • • PIN ASSY,REBOUND CONTROL	1	3
- 23	□35-825100-4	• • • PAD,BARREL	2	3
- 24	□35-825092	• • • CAP,BARREL	1	3
		/ATTACHING PARTS/									
- 25	□AN960-1C	• • • WASHER	2	
- 26	AN960-A1CL	• • • WASHER	4	
- 27	□AN365-1032	• • • NUT	6	
		-----*									
- 28	□35-825101	• • • SHIM,BARREL CAP	1	3
	□35-825024	• • • ROLLER ASSY,NOSE WHEEL STRAIGHTENING	1	3

FIG. & INDEX NO.	PART NO.	1 2 3 4 5 6 7	DESCRIPTION	UNITS PER ASSY	USABLE ON CODE
38 - 29	35-825024-2	• • • •	BRACKET,ROLLER ASSY	1	3
- 30	=NAS505-4J	• • • •	BEARING,NOSE WHEEL STRAIGHTENING	1	3
		/ATTACHING PARTS/			
- 31	=AN24-13	• • • •	BOLT	1	
	=AN980-416	• • • •	WASHER	1	
	=AN310-4	• • • •	NUT	1	
	=AN380-2-2	• • • •	PIN,COTTER	1	

- 32	=AN6227-20	• • • •	PACKING,ORIFICE	1	3
- 33	=AN6227-24	• • • •	PACKING,BARREL	1	3
- 34	=AN6227-27	• • • •	PACKING,GLAND	1	3
- 35	=35-825100-2	• • • •	PAD,PISTON	1	3
- 36	=35-825153	• • • •	RING,PISTON WIPER	1	3
- 37	=111190-2	• • • •	RING,PISTON SCRAPER	1	3
- 38	=111200-2	• • • •	RING,SNAP	1	3
- 39	=35-825060	• • • •	KNEE ASSY,NOSE WHEEL STRUT	2	3
		/ATTACHING PARTS/			
- 40	=35-820027	• • • •	PIN,TORQUE KNEE UPPER	1	
- 41	=35-825106	• • • •	PIN,TORQUE KNEE LOWER	1	
- 42	=AN392-17	• • • •	PIN,FLAT HEAD	2	
	=AN380-2-1	• • • •	PIN,COTTER	2	
- 43	=AN4-12	• • • •	BOLT	1	
	=100951S063Z2	• • • •	WASHER	1	
- 44	=35-820026	• • • •	BUSHING,TORQUE KNEE GRIP	1	
	=100951S063YH	• • • •	WASHER	1	
	=AN310-4	• • • •	NUT	1	
	=AN380-2-2	• • • •	PIN,COTTER	1	

- 45	=35-820062	• • • •	BUSHING,TORQUE KNEE	2	3
- 46	=1729	• • • •	FITTING,LUBRICATION	3	3
- 47	=35-825145	• • • •	DAMPENER ASSY,SHIMMY /SEE FIG. 40/	1	3
		/ATTACHING PARTS/			
- 48	=AN6-31A	• • • •	BOLT	1	
	=100951X063YN	• • • •	WASHER	1	
- 49	=1057395-YP1483	• • • •	BUSHING	1	
	100951X031YM	• • • •	WASHER	1	
	=AN365-624	• • • •	NUT	1	
- 50	=AN3-6A	• • • •	BOLT	1	
	=AN960-1C	• • • •	WASHER	1	
- 51	=1057395-ZK0190	• • • •	BUSHING	1	
	=AN960-1CL	• • • •	WASHER	1	
	=AN365-1032	• • • •	NUT	1	

- 52	=35-825190	• • • •	BODY,BLEEDER VALVE	1	2
- 53	=AN6290-2	• • • •	RING,O	1	2
- 54	=302D	• • • •	CORE,BLEEDER VALVE	1	3
- 55	AN813-1A	• • • •	CAP,BLEEDER VALVE	1	3
- 56	35-825G64	• • • •	PLACARD,NOSE GEAR SHOCK STRUT MODEL	1	3
- 57	=35-825189	• • • •	PLACARD,NOSE WHEEL STRUT CAP	1	3
	35-825001-12	• • • •	KIT ASSY,BALANCED WHEEL	1	4
	35-825001-14	• • • •	KIT ASSY,BALANCED WHEEL	1	4
		/USE WITH TUBELESS TIRE/			
- 58	=500X5	• • • •	TIRE	1	5
	=500X5	• • • •	TIRE,4 PLY TUBELESS	1	4
		/USED WITH P/N 9532102 OR 9532669/			
- 59	=500X5	• • • •	TUBE	1	5
- 60	35-825001-6	• • • •	HOSE,NOSE WHEEL VALVE STEM	1	
	=9520653	• • • •	WHEEL ASSY,NOSE	1	5
	=9532669	• • • •	WHEEL ASSY,NOSE /ALTERNATE FOR 9520653/	1	5
		/ATTACHING PARTS/			
- 61	=35-825129	• • • •	WASHER,NOSE WHEEL AXLE	1	
- 62	=AN7502-20	• • • •	NUT	1	
	AN380-4-7	• • • •	PIN,COTTER	1	

FIG. & INDEX NO.	PART NO.		DESCRIPTION							UNITS PER ASSY	USABLE ON CODE	
			1	2	3	4	5	6	7			
38	9510186		• • • • WHEEL ASSY,MALE HALF /ATTACHING PARTS/	•	•	•	•	•	•	•	1	5
- 63	#9520206		• • • • BOLT	•	•	•	•	•	•	•	3	
- 64	NO NUMBER		• • • • WASHER,/SAE STANDARD STEEL 1/4 X 1/16/	•	•	•	•	•	•	•	6	
- 65	AN365-428		• • • • NUT	•	•	•	•	•	•	•	3	
			-----*									
- 66	9520651		• • • • WHEEL	•	•	•	•	•	•	•	1	5
- 67	#08231		• • • • CUP,BEARING	•	•	•	•	•	•	•	1	5
	9520925		• • • • WHEEL ASSY,FEMALE HALF	•	•	•	•	•	•	•	1	5
- 68	9530355		• • • • WHEEL	•	•	•	•	•	•	•	1	5
- 69	#08231		• • • • CUP,BEARING	•	•	•	•	•	•	•	1	5
- 70	#08125		• • • • CONE,BEARING	•	•	•	•	•	•	•	2	5
- 71	#9510236		• • • • RING,BEARING CLOSURE FLAT	•	•	•	•	•	•	•	4	5
- 72	510524-25		• • • • RING,FELT SEAL	•	•	•	•	•	•	•	2	5
- 73	A-60151		• • • • RING,BEARING CLOSURE RETAINING	•	•	•	•	•	•	•	2	5
			-----*									
	#9532569		• • • • WHEEL ASSY /SUPERSEDES 9532102/ /ATTACHING PARTS/	•	•	•	•	•	•	•	1	4
#95-820000-1			• • • • WASHER,NOSE WHEEL AXLE	•	•	•	•	•	•	•	1	
#95-820000-3			• • • • WASHER,NOSE WHEEL AXLE	•	•	•	•	•	•	•	1	
#AN7502-20			• • • • NUT	•	•	•	•	•	•	•	REF	
AN380-4-7			• • • • PIN,COTTER	•	•	•	•	•	•	•	REF	
			-----*									
9524193			• • • • SUB ASSY,NOSE WHEEL INSD HALF	•	•	•	•	•	•	•	1	4
#LM67010XL			• • • • CUP,BEARING	•	•	•	•	•	•	•	1	4
9524192			• • • • SUB ASSY,NOSE WHEEL OUTSD HALF	•	•	•	•	•	•	•	1	4
#LM67010XL			• • • • CUP,BEARING	•	•	•	•	•	•	•	1	4
#LM67048XL			• • • • CONE,BEARING	•	•	•	•	•	•	•	1	4
#AN6230820			• • • • SEAL,NOSE WHEEL O RING	•	•	•	•	•	•	•	1	4
#AN4-14A			• • • • BOLT,NOSE WHEEL	•	•	•	•	•	•	•	3	4
#AN960-416			• • • • WASHER,NOSE WHEEL	•	•	•	•	•	•	•	6	4
22FH-428			• • • • NUT,NOSE WHEEL	•	•	•	•	•	•	•	3	4

CODE EFFECTIVITY

CODE EFFECTIVITY

- | | |
|----------------------|----------------------|
| 1 D-4866 THRU D-5725 | 2 D-5726 THRU D-6561 |
| 3 D-4866 THRU D-6561 | 4 D-5986 THRU D-6561 |
| 5 D-5726 THRU D-5985 | |




Figure 38A. Nose Landing Gear (D-6562 And After)

FIG. & INDEX NO.	PART NO.	1 2 3 4 5 6 7	DESCRIPTION	UNITS	USABLE
				PER ASSY	ON CODE
38A-	35-825196-1	GEAR INSTL,NOSE /TUBELESS TIRE/		NP	8
	35-825196-11	GEAR INSTL,NOSE /TUBE TYPE TIRE/		NP	10
	35-825196-29	GEAR INSTL,NOSE /TUBE TYPE TIRE/		NP	9
	35-825196-27	GEAR INSTL,NOSE /TUBELESS TIRE/		NP	9
	35-825196-616	. . GEAR ASSY,NOSE		1	15
	35-825196-620	. . GEAR ASSY,NCSE		1	4
	35-825196-615	. . GEAR ASSY,NOSE		1	14
□	35-825196-691	. . GEAR ASSY,NOSE /LESS WHEEL ASSY/.		1	11
	35-825196-695	. . GEAR ASSY,NOSE /LESS WHEEL ASSY/.		1	12
	35-825196-605	. . GEAR ASSY,NOSE, /WITH WHEEL ASSY/.		1	13
	35-825195	. . ABSORBER ASSY,DIRECT ACTION SHOCK		1	8
	35-825195-55	. . ABSORBER ASSY,DIRECT ACTION SHOCK		1	9
		/ATTACHING PARTS/			
- 1	□NAS146-46	. . . BOLT		2	
- 2	□45-825011	. . . BUSHING,NOSE GEAR GRIP		2	
	□100951X032YP	. . . WASHER		4	
	□100951S016YP	. . . WASHER,/ALTERNATE FOR 100951X032YP/.		AR	
	□AN960-616	. . . WASHER		2	
	□NAS143-6C	. . . WASHER /SUPERSEDES MS20002C6/.		2	
	□MS20365-624	. . . NUT /SUPERSEDES AN365-624/.		2	
		/			
	□95-824005-601	. . . BRACE ASSY,NOSE LANDING GEAR		1	1
		/ATTACHING PARTS/			
- 3	□AN6-31A/M/	. . . BOLT		1	
- 4	□105739S-YP1483	. . . BUSHING		1	
	100951X032YM	. . . WASHER		1	
	□MS20365-624	. . . NUT /SUPERSEDES AN365-624/.		1	
		/			
- 5	□95-824005-1 BRACE,NOSE LANDING GEAR		1	1
- 5A	□35-820115 BEARING,BARREL		2	1
- 5B	□35-820135 BEARING,PIVOT		2	1
- 6	□35-825197 PLATE,NOSE GEAR SHOCK ABSORBER		1	1
		INSTRUCTIONS			
- 7	□45-825033 COLLAR,NOSE GEAR STEERING		1	1
		/ATTACHING PARTS/			
- 8	□45-825034 BOLT,NCSE GEAR COLLAR ATTACHING		2	
		/			
- 9	□NAS505-4J BEARING,NEEDLE		1	1
- 10	□NAS222-16 SCREW		1	1
	□AN960-416 WASHER		2	
- 11	□S1452-048 NUT,BARREL		1	1
- 12	□35-820125 BODY,NOSE STRUT FILLER VALVE		1	2
	□118642-1 BODY,NOSE STRUT FILLER VALVE		1	3
- 13	AN6227-6 RING,NOSE STRUT FILLER VALVE O		1	2
	□MS28778-5 PACKING,NOSE STRUT FILLER VALVE		1	3
- 14	□302D CORE,NOSE STRUT FILLER VALVE		1	1
- 15	□AN813-18 CAP,NOSE STRUT FILLER VALVE		1	1
- 16	□35-820134 SHIM,NOSE WHEEL STEERING COLLAR		1	1
- 17	□NAS50-187 RING,INTERNAL RETAINER		1	1
- 18	AN6230-1 RING,O		1	1
	□35-825195-21 BARREL ASSY,SHOCK ABSORBER		1	2
	□35-825195-31 BARREL ASSY,SHOCK ABSORBER		1	3
- 19	□35-825195-27 BRAZE ASSY,SHOCK ABSORBER BARREL		1	2
	35-825195-33 BRAZE ASSY,SHOCK ABSORBER BARREL		1	3
	35-825195-33 BRAZE ASSY,SHOCK ABSORBER BARREL		1	3
- 20	□45-825031 BEARING,LOWER PISTON NOSE GEAR		1	1
	35-825195-15 TUBE ASSY,SHOCK ABSORBER ORIFICE		1	1
- 21	35-825195-13 TUBE,SHOCK ABSORBER ORIFICE		1	1
- 22	AN6230-2 RING,O		1	1
- 23	□35-380020-3 RING,SHOCK ABSORBER PISTON		1	1
- 24	□111200-6 RING,SNAP		1	1
- 25	□45-825032 ADAPTER,NOSE GEAR PISTON SCRAPER		1	1
- 26	□AN6231A19 SCRAPER,NOSE GEAR PISTON		1	1
- 27	□35-820130-2 PAD,SHOCK ABSORBER		1	1
- 28	□35-825145 DAMPENER ASSY,NOSE GEAR SHIMMY		1	1
		/SEE FIG. 40/ /ATTACHING PARTS/			
- 29	□AN3-6A/M/ BOLT		1	
- 30	□105739S-ZK0190 BUSHING		1	
	□AN960-10 WASHER		1	
	□AN960-10L WASHER		1	
	□MS20365-1032 NUT /SUPERSEDES AN365-1032/.		1	

FIG. & INDEX NO.	PART NO.	1 2 3 4 5 6 7	DESCRIPTION	UNITS	USABLE
				PER ASSY	ON CODE
38A-	□35-820107		• • KNEE ASSY,NOSE SHOCK ABSORBER UPPER TORQUE. /ATTACHING PARTS/	1	1
- 31	□35-820108		• • • PIN,TORQUE KNEE	1	8
	35-825200		• • • PIN,TORQUE KNEE	1	9
- 32	□AN392-23		• • • PIN	1	
	□AN380-2-1		• • • PIN,COTTER.	1	
- 33	□35-820107-5		• • • KNEE,NOSE SHOCK ABSORBER UPPER TORQUE . /SUPERSEDES 35-820107-3/	1	1
- 34	□35-820123		• • • BUSHING,UPPER KNEE.	2	1
- 35	□MS15002-1		• • • FITTING,LUBRICATION	2	1
- 36	□1729		• • • FITTING,LUBRICATION	1	1
- 37	□AN4-12/M/		• • • BOLT	1	
- 38	□35-820028		• • • BUSHING,NOSE WHEEL TORQUE KNEE GRIP . . .	1	1
	□100951S063ZZ		• • • WASHER.	1	
	□100951S063YH		• • • WASHER.	1	
	□AN310-4/M/		• • • NUT	1	1
	□AN380-2-2		• • • PIN,COTTER.	1	1
	□35-825193		• • • KNEE ASSY,NOSE GEAR LOWER TORQUE . /ATTACHING PARTS/	1	1
- 39	□35-820132		• • • PIN,NOSE WHEEL LOWER TORQUE KNEE.	1	
- 40	□AN392-21		• • • PIM	1	
	□AN960-616		• • • WASHER.	2	
	□AN380-2-1		• • • PIN,COTTER.	1	
- 41	□35-825193-1		• • • KNEE,NOSE GEAR LOWER TORQUE	1	1
- 42	□35-820123		• • • BUSHING,LOWER KNEE.	2	1
- 43	□MS15002-1		• • • FITTING,LUBRICATION	2	1
- 44	□1729		• • • FITTING,LUBRICATION	1	1
- 45	□35-825195-601		• • • STRUT ASSY,SHOCK ABSORBER LOWER /WELDED/	1	11
	□35-825195-603		• • • STRUT ASSY,SHOCK ABSORBER LOWER /FORGED/	1	12
- 46	□35-820133		• • • CLIP,NOSE WHEEL SCRAPER ATTACHING . . .	1	1
- 47	□AN4-21A/M/ □AN960-416 □MS20365-428		• • • KNEE,NOSE GEAR LOWER TORQUE	1	1
- 48	□35-825175-12		• • • BOLT.	1	
- 49	□35-825196-25		• • • WASHER.	1	
- 50	□96-810013		• • • NUT /SUPERSEDES AN365-428/.	1	1
- 51	□AN4H3A/M/		• • • GUARD ASSY,NOSE WHEEL SCRAPER	1	1
- 52	□AN4H4A/M/ □AN960-416 □MS20365-428 □MS20364-428		• • • CABLE ASSY,GROUND /SUPERSEDES 45-361235/. . /ATTACHING PARTS/	1	1
- 53	35-825001-14 35-825196-17		• • • BOLT,LH SIDE /SUPERSEDES 96-820011/ . . .	1	
- 54	□35-825195-35		• • • BOLT,RH SIDE.	1	
- 55	□95-820000-3		• • • BOLT.	1	
- 56	□AN7502-20 □AN380-4-7		• • • WASHER.	6	
- 57	□9532669 □9532926 □95-32671		• • • NUT,LH SIDE /SUPERSEDES AN365-428/. . .	1	7
			• • • NUT,LH SIDE /SUPERSEDES AN364-428/. . .	1	6
- 58	□9541899		• • • KIT,BALANCED WHEEL ASSY /TUBELESS/. . .	1	1
- 59	□LM67010XL 9525676		• • • WHEEL ASSY,BALANCED /TUBE TYPE/. . .	1	5
- 60			• • • WASHER,NOSE WHEEL AXLE.	1	
			• • • /SUPERSEDES 95-820000-1/		
- 61			• • • WASHER,NOSE WHEEL AXLE.	1	
- 62			• • • NUT,WHEEL BEARING RETAINING	1	
- 63			• • • PIN,COTTER.	1	
- 64			• • • WHEEL ASSY,NOSE /SUPERSEDES 9532102/. . .	1	1
- 65			• • • WHEEL ASSY,NOSE	1	5
- 66			• • • SUB ASSY,NOSE WHEEL LH.	1	1
			• • • /SUPERSEDES 9524193/		
- 67			• • • SUB ASSY,NOSE WHEEL LH.	1	5
- 68			• • • CUP,NOSE WHEEL BEARING.	1	1
- 69			• • • PLATE,DATA.	1	5

MODEL 35 PARTS CATALOG

FIG. & INDEX NO.	PART NO.	1 2 3 4 5 6 7	DESCRIPTION	UNITS	USABLE
				PER ASSY	ON CODE
38A- 58	□9524192	- - - .	SUB ASSY,NOSE WHEEL RH.	1	1
	□9541898	- - - .	SUB ASSY,NOSE WHEEL RH.	1	5
- 59	□LM67010XL	- - - .	CUP,NOSE WHEEL BEARING	1	1
	9525675	- - - .	PLATE,DATA	1	5
- 60	□LM67048XL	- - - .	CONE,NOSE WHEEL BEARING	2	1
- 61	□AN6230820	- - - .	SEAL,NOSE WHEEL O RING	1	1
- 62	□AN4-14A/M/ □AN960-416	- - - .	BOLT,NOSE WHEEL	3	1
	□AN960-516L	- - - .	WASHER	6	1
	□MS20365-428C	- - - .	WASHER	1	5
	9534587	- - - .	NUT,FLEX LOC /SUPERSEDES. 22FH428/	3	1
- 63	□5.00X5 4PTT	- - - .	BUSHING,VALVE STEM	1	5
	□5.00X5	- - - .	TIRE,FOUR PLY TUBE TYPE	1	5
	□5.00X5 4PTT	- - - .	TUBE,TIRE	1	5
		- - - .	TIRE,FOUR PLY SIDE VALVE TUBELESS	1	1

CODE EFFECTIVITY

1 D-6562 AND AFTER
 3 D-6992 AND AFTER
 5 D-7662 AND AFTER
 7 D-6562 THRU D-7309
 9 D-8599 AND AFTER
 11 D-6562 THRU D-7251
 13 D-6562 THRU D-7280
 15 D-7654 THRU D-8598

CODE EFFECTIVITY

2 D-6562 THRU D-6991
 4 D-8599 AND AFTER
 6 D-7310 AND AFTER
 8 D-6562 THRU D-8598
 10 D-7662 THRU D-8598
 12 D-7252 AND AFTER
 14 D-7281 THRU D-7653